

REMAK



Control units

VCS

INSTALLATION AND OPERATING INSTRUCTIONS

10/2019

Table of Contents

Equipment characteristics.....	2
Design.....	3
Documentation and Safety Measures.....	4
Handling, Transport and Location.....	5
Commissioning.....	6
Control and Protection Functions.....	8
Basic Operating Modes.....	17
Additional Operating Modes and Functions.....	17
Temperature and Time Modes.....	19
Control (HMI-SG controller).....	20
List of Data Points (HMI-SG controller).....	27
List of Failures (HMI-SG controller).....	43
REMAK mobile app.....	47
Control (HMI-DM, HMI-TM and HMI@Web controllers).....	46
Control (HMI@Web – Installation and Connection to PC and LAN/WAN).....	51
SCADA (Supervisory Control and Data Acquisition).....	58
List of Data Points (HMI-DM, HMI-TM and HMI@Web controller).....	59
List of Failures (HMI-DM, HMI-TM and HMI@Web controller).....	68
Other Control.....	69
Connection to the Master System (LonWorks Standard).....	70
Connection to the Master System (ModBus Standard).....	75
Connection to the Master System (BacNet Standard).....	95
POOL UNITS – description of control.....	97
PLC Controller for Compressor Output Control.....	99
Electronic Expansion Valve Overheating Controller EC3-X33.....	104
KHD-S1_ _R Backup System Wiring Diagram.....	110
Unit Activation.....	111
Checks and Failures.....	113
Troubleshooting.....	114
Spare Parts and Service.....	115
Disposal and Recycling.....	115

Introduction

- The VCS control unit software is the intellectual property of REMAK a.s.
- VCS control units are manufactured in accordance with valid Czech and European regulations and technical standards.
- VCS control units must be installed and used only in accordance with this documentation.
- The manufacturer is not responsible for any damage resulting from use for purposes other than specified in this documentation, and the customer bears the risks of such use.
- The installation and operating documentation must be available for the operating and servicing staff. It is advisable to store this documentation close to the installed VCS control unit.
- When handling, installing, wiring, commissioning, repairing or servicing the air-handling units, it is necessary to observe valid safety rules, standards and generally recognized technical rules.
- All equipment connections must comply with the respective safety standards and regulations.
- Any changes or modifications to individual components of the VCS control unit which could affect its safe and proper functioning are forbidden.
- Before installing and using the air-handling units, it is necessary to familiarize yourself with and observe the directions and recommendations included in the following chapters.
- The VCS control units, including their individual parts, are not intended, due to their concept, for direct sale to end customers. Each installation must be performed in accordance with a professional project created by a qualified designer who is responsible for the proper selection and dimensioning of components concerning their suitability for a given application. Installation and commissioning may only be performed by an authorized company licensed in accordance with generally valid regulations.
- REMAK a.s. is not responsible for any damage, direct or indirect, caused by unauthorized or unqualified use of the software or hardware, or for any damage caused by ignoring the product's Operating Instructions.

Up-to-date version of this document is available at website www.remak.eu

Equipment characteristics

Application

VCS control units are compact control and power distributors used for the decentralized regulation and control of air-handling systems. They provide the equipment with high stability and safety while allowing easy control, including the viewing of operating states. (STOP - OPERATION - AUTO).

Main Features

The VCS control unit is intended for the following:

- Complex autonomous control of air-handling systems
- Supply or room air temperature control (cascade control)
- Supply and power actuation of air-handling systems
- Protection and safeguarding of connected components

This control unit provides air-handling systems with control and safety functions. It can be equipped with the necessary number of proportional inputs and outputs depending on the required functions.

Sophisticated control algorithms ensure system stability, user-friendly control and energy savings. Another advantage is that the control unit's features also contribute to energy savings in air-handling system operation:

- Option to set the unit to 2 temperature modes
 - Comfort
 - Economy
- Time schedule setting options (daily or weekly time schedules)
- Additional operating mode setting options:
 - Optimized start
 - Temperature start-up
 - Night chilling
- Precise drive control using data communications (Modbus RTU protocol)
- Superior antifreeze protection with moderate heating of the heat exchanger during standby mode
- Precise analogue control of controlled peripheral units (according to the controlled component)


Unit Design

These control units are designed in accordance with ČSN EN 60204-1. The unit's control and power parts are situated in a single box. The components, control and actuating elements, are fitted on the DIN bars inside the control unit. Depending on the version, the VCS control unit can be provided in plastic (plastic switchboard) or in sheet-steel (sheet-steel switchboard). Both designs are equipped with transparent doors. The controls are situated below these doors. Further, the VCS control unit can be produced as a built-in assembly and a part of an air-handling unit section, which must be designed for that purpose and meet specific requirements.

Controller HW and SW Concept

The core of the VCS system is created by a powerful Siemens Climatix series PLC controller. The control unit can be equipped with one of two POL4xx and POL6xx controller versions depending on the components used in the air-handling unit. Simultaneously, additional external input/output or communication modules can be connected to the POL6xx controller.

Figure 1 – VCS control unit design



For local control, the HMI-SG POL822/60 hand controller can be used. The control unit allows up to 8 basic control sequences to be used depending on the air-handling unit configuration. The order of some sequences can be changed (e.g. heating-mixing damper or cooling-fan cooling).

The heat pump or electric after-heater can be separated from basic sequences in the so-called extra sequences.

If this is the case, another sensor must be used in the air inlet, and a special set-point must be set for this type of control. This feature can only be used after prior consultation with the manufacturer. These units are delivered adapted to individual applications so they will provide exactly those features needed for the operation of a specific air-handling device.

Control

Local control

The basic VCS controllers are devices (manual controllers with bus connection) for so-called local control of the control unit (see fig. 2):

- a) Room controller - HMI-SG (POL822/60)
- b) Comfortable universal alphanumeric driver - HMI-DM nebo HMI-TM

Note: For details, see controllers instructions part of the manual.

Distant control

In addition to local VCS controllers, so-called remote control can be used. For this control, you need to connect VCS to LAN, WAN or Internet (For production, the control unit must be configured/ordered with the required functionality).

- a) **HMI@WEB** - You can use the HMI @ WEB controller via the web interface. The controller fully complies with the local HMI-DM and TM controls.
- b) **Mobile app** (see fig. 3) - You can use simple touch application for smartphones or tablets with Google Android (v. 4.1 and higher) or Apple iOS (v. 12.2 and higher).
- c) **SCADA web interface**

Monitoring and operation using the device's technological scheme with operating parameters, respectively using the tabular interface of an internet browser on a PC. For details, refer to page 58.

Control

Other controls (technological)

For basic control (triggering, mode switching) from a technology or a very simple manual button / switch control, you can use "Other Controls". External control via one or two non-voltage contacts.

Control from parent system

When integrating HVAC with the VCS control unit into complex building management systems (BMS), it is also possible to connect to these systems. Subsequently, it is possible to control and monitor the HVAC through them. The ModBus, LON, and BacNet standards can be used.


The different types of control must be designed when designing (configuring) VCS into the project and especially in production - the usability of remote control and connectivity to the BMS are dependent on the use of the corresponding controller.

Detailed descriptions of all controller types, control and their use - see separate sections / chapters of this manual.

Figure 2 – HMI-SG (-DM, -TM) controllers




Figure 3 – Mobile application



Power Part


The power part, like the control part, is always "tailored" for a specific air-handling unit.

Figure 4 – VCS control unit internal structure



Documentation

Figure 8 – Example of access to the unit



Control Unit Designation

The control unit designation is always created by a unique code (generated by the AeroCAD design program for the control unit calculation and design), which is only included in the accompanying technical documentation (not on the control unit), and by the serial number (for communication with the manufacturer).

Documentation

VCS control systems can be installed and used only in accordance with the delivered documentation.

Documentation List

- Product Installation and Operating Instructions
- Control system configuration (summary of connected components), terminal diagram and list of recommended cables – device printout from the AeroCAD design program

Additional – General Documentation

The system or device documentation also includes the operating and inspection documentation kept during the device service life and the Service Regulations, for which the user is responsible.

Service Regulations

Before putting the air-handling device into permanent operation, the device user in collaboration with the designer, or the supplier, must issue service regulations in accordance with local regulations.

We recommend including the following in these service regulations:

- Air-handling device assembly configuration, its intended use and a description of its operation in all operating modes
- Description of all safety and protective elements and their functions
- Summary of the health protection principles, safety and operating rules to be observed when operating the air-handling equipment
- List of requirements for operating staff qualifications and training, nomenclature list of personnel authorized to operate the air-handling device
- Detailed emergency and accident instructions to be followed by the operating staff

- Operating particularities in different climatic conditions (e. g. summer or winter operation)
- Inspection, checking and maintenance schedule, including a list of checking steps, and their recording

Documentation Availability

The documentation delivered with the control system (original) and operating documentation must be permanently available for the operating and service staff and stored near the air-handling equipment. The Installation and Operating Instructions are also available at the website: <https://www.remak.eu>

Warning

The manufacturer reserves the right to make changes and amend the documentation due to technical innovations and changes to legislation without prior notice. **Information on changes and updates are always available at the website <https://www.remak.eu>**

Safety Measures

- VCS control units are manufactured in accordance with valid regulations and technical standards.
- VCS control units must be installed and used only in accordance with this documentation.
- Any damage caused by improper use contrary to this documentation is the responsibility of the subject who failed to observe the instructions included in this documentation.
- When handling, installing, wiring, commissioning, repairing or servicing the air-handling units, it is necessary to observe valid safety rules, standards and generally recognized technical rules.
- In particular, it is necessary to use suitable tools and personal protective work aids (e. g. gloves) because of sharp edges and corners, respectively voltage, when performing any handling, installing, dismantling, repairing or checking.
- Any changes or modifications to individual components of the VCS control unit which could affect its safe and proper functioning are forbidden.
- The air-handling equipment configuration and documentation must not be changed without the prior consent of the manufacturer.
- **The VCS control units, including their individual parts, are not intended, due to their concept, for direct sale to end customers.** Each installation must be performed in accordance with a professional project created by a qualified designer who is responsible for the proper selection of equipment concerning its suitability for the given application.
- All connections of the equipment, including the VCS control unit, to the power mains must be performed in accordance with applicable local wiring standards and regulations.
- Wiring installation, commissioning, maintenance and repairs may only be performed by a specialized assembly company, respectively an authorized person duly qualified in accordance with generally valid regulations.
- Before installing and using the air-handling units, it is necessary to familiarize yourself with and observe the directions and recommendations included in the following chapters.

Manipulation, transport, location

- The air-handling equipment can only be operated in accordance with the applicable Service Regulations. The operating staff must comply with the requirements included in the Service Regulations, respectively with the manufacturer's requirements (authorisation for some service activities).
- To avoid unintentional unit start-up, the master switch must be switched off and locked when repairing the VCS unit.

Attention! in some cases, the main switch may not disconnect all circuits!

These are control circuits from foreign devices such as - switching of demand for condensing units and heat pumps, signaling of operation and faults, switching of the boiler room request and others. See the appropriate circuit diagram for specific VCS units.

Conditions for Handling

The device can only be commissioned, operated and serviced by qualified personnel.

- The VCS control unit can only be operated by personnel provably trained and warned about possible dangers (by the manufacturer or authorized representative of the manufacturer) in accordance with the applicable Service Regulations for the air-handling unit.
 - It is forbidden to remove, bypass or disconnect the safety equipment, safety functions and guards.
 - Only air-handling components in perfect condition can be used. Failures affecting the equipment safety must be removed immediately.
 - All safety measures against electrical accidents must be strictly observed. Any action resulting in restriction, even temporary, of the safety and protection functions must be avoided.
 - It is strictly forbidden to remove safety guards, casings or other safeguards, operate the equipment or its components if the safeguards are disabled or restricted.
 - Any action resulting in restriction of the prescribed insulation of the safety voltage must be avoided.
 - When changing fuses, it is necessary to ensure the non-voltage state of the control unit and use only the specified fuses and protection elements.
 - It is necessary to eliminate electromagnetic interference and the harmful effects of over-voltage on the signal, control and power cables, which could unintentionally initiate dangerous actions and functions or cause destruction of the electronic parts in individual components.
 - Never work on the connected equipment under voltage! Before starting work on the air-handling unit, switch off and lock the master switch to disconnect the supply voltage. Use protective and work aids in accordance with the Service Regulations and standards applicable in the country where the unit is installed.
 - If individual technical assemblies of the air-handling unit are equipped with service switches, and if allowed by the Service Regulations, installation conditions and characteristics, then such assembly (e.g. heater, fan, etc.) can be disconnected by switching off and locking the corresponding service switch.
 - Never use abrasive cleaners, cleaners unsuitable for plastics or acid or alkaline solutions to clean to unit.
 - Avoid splashing water, impacts and vibrations.
- Each air-handling equipment component must always be installed in accordance with the appropriate installation instructions.

The manufacturer recommends fully ensuring the flawless condition and functioning of all protective elements and equipment. After failures, such as short circuits, have been removed, check the functionality of the automatic circuit breakers and protective elements, and verify the condition of the protective wiring interconnection and grounding.

To ensure safe operation, it is necessary to verify the conditions of the water heating/cooling pumps – perform manual pump turning and set the output curve (over-design impairs the control quality).

Warning: If the remote control is used (including automatic schedule program), safety access must be ensured for each physical interference or entry into the air-handling unit (inspection, maintenance or repair) – i. e. disconnect the power supply by turning off the switch – avoid remote initiation of the unit by other users when work is being performed on the unit.

Transport and Storage Before Installation

VCS control units are packed in cardboard boxes or installed in the corresponding air-handling unit section, if they are integrated into the air-handling unit. Measures for handling fragile goods must be taken when handling the unit.

The units must be stored in rooms complying with the following conditions:

- Maximum relative air humidity must not exceed 85 %, without water condensation
 - Ambient temperature between –25 °C and +60 °C
- Dust, water, caustics, corrosive agents or other materials negatively affecting the structure or the unit's components (causing degradation of plastic parts and insulation) must not enter the unit.

Installation and Location

The VCS control unit location must provide good access for the operating personnel and easy connection of the cables. The installation site must be flat without rough spots.

When planning the air-handling unit location, it is necessary to keep sufficient space for maintenance, service and operating. Check the completeness and intactness of the delivery in accordance with the bill of delivery before installation.

These control units are designed for normal (indoor, dustless, dry, non-explosive) environments. They can be mounted on A and B combustibility grade materials in accordance with EN 13501-1.

Permissible ambient temperature: +0 °C to +40 °C (24h average must not exceed +35 °C)

The VCS control units in the switchboard boxes are mounted in the vertical position directly on the wall. The KAEDRA plastic switchboard box can also be partially embedded under plaster. The VCS unit installed in steel switchboard boxes can also be placed directly on the floor. The cables can be run along cable trenches, cable trays or under plaster.

The power cables are connected from below.

We recommend the wall-mounted units be fixed to the wall using dowels and screws suitable for the wall structure.

Commissioning

Note: As appropriate, the above-mentioned instructions apply also for control units integrated into the air-handling unit while observing the control unit installation and operating instructions delivered with the air-handling unit.

Check the completeness and intactness of the delivery in accordance with the bill of delivery before installation.

Commissioning

Fitting and Wiring Check

A careful check and verification of the wiring of all control system components in accordance with the attached unit wiring diagram must be performed before the first start-up. The system cannot be connected to the power supply until these checks have been performed.

First of all, it is necessary to check the presence, locations and connections of the temperature sensors, fan thermo-contacts and heaters in accordance with the M&C project. Further, the connections of all error inputs must be checked.

It is also essential to check the fans, electric heaters, heat exchangers, filters and other parts of the connected air-handling unit for correct fitting in accordance with the air-handling accompanying documentation.

The above-mentioned checks must include a functionality check of each component.

Special attention must be paid to the check of the conductive interconnection of all parts of the air-handling unit and associated devices.

Conditions for Connection

The connections must be performed in accordance with the applicable local wiring standards and regulations. Before putting the unit into operation, an initial wiring inspection must be performed in accordance with the national regulations.

Settings

The VCS control unit has been manufactured according to the customer's requirements (the project), and the basic parameters have been pre-set so that the unit is ready for operation. With these settings, the control unit will start and begin the control for the pre-set parameters providing the connection of the unit has been performed correctly.

However, the professionals performing the unit commissioning must always check or adapt the air-handling unit's operating parameters to the specific design and behaviour of the control system and operating or local conditions.

It is especially necessary to pay attention to the control constants and parameter, various correction values, temperature modes and time schedules, optional modes and functions.

The data points are accessible through the HMI control panel. Setting the user **access levels** is an important part of the settings procedure.

The default factory settings must be re-set according to the user and service company needs.

The Access passwords are the basic pre-set parameters which need to be reset when commissioning the unit, see the chapter *Control (HMI-SG)*.

Additional Settings:

- To optimize the interaction between the control unit and peripheral devices, it is necessary to set, using the HMI-SG controller (see the List of Data Points in the section Settings – Control Signal Characteristic), corresponding values of the analogue signals for heating, cooling, heat recovery and gas heating, optional from 0–10 V and 2–10 V (pre-set).
The values 2–10V are suitable for REMAK or Belimo actuators.

Room temperature Measuring Point Selection

- Up to two room temperature sensors can be installed in the air-conditioned room (HMI-SG controller with an integrated temperature sensor plus one additional temperature sensor, or two HMI-SG controllers with integrated temperature sensors). The final room temperature value for the control can be set as the minimum, maximum or average of both sensors (see the List of Data Points - Temperature Measuring Point Selection).

Selection of the specific point for adjusting or measuring the temperature value entering the control process results in more accurate setting of the room temperature.

Warning

The device parameters are structured and made available to users in accordance with their user roles (access levels). These roles must be assigned to the users according to their expertise and responsibility for device operation.

Basic Application Parameterization

- Default and common operation parameterization is described in the chapter *Control (see particular controller)*.

General Overview of Parameters

For a general overview of parameters available in the menu and access authorization of users, refer to the chapter VCS – Parameter Overview and Default Factory Settings. For the menu with HMI controller parameters and default values, refer to the chapter *Control (HMI-SG)*.

Important Notes

Correct assembly, installation, commissioning and proper control are the essential conditions for flawless and safe operation of the control unit. The components connected to the control unit must correspond with the specification in the control unit documentation.

The procedures specified by the manufacturer in the unit documentation and the Service Regulations measures must be observed throughout the unit service life.

Commissioning

Location of Control System Sensors

Inlet Air Temperature Sensor (NS 120)

Control and anti-freeze sensors must always be situated behind the heater, respectively cooler – to measure the supply air temperature. They must not be situated in the room.

VO antifreeze protection sensor (NS 130R)

The return water temperature sensor must be situated in the return water line from the water heater so that it will be sufficiently bathed in water. The heating water circuit must ensure all the required functions for the water heater control and safety when the unit is shut down (filling the system with antifreeze mixture) as specified in the air-handling device project documentation. A capillary tube can be used as additional antifreeze protection. If it is not installed on the air-handling unit by the manufacturer, the capillary tube must be run (meandering way) through the entire cross-section of the water heater's rear side.

Outdoor air temperature sensor (NS120)

Ideally, it should be situated in the outside environment – only then are the control system's functions ensured even in the STOP mode or immediately after unit start-up (e.g. moderate pre-heating of the exchanger based on the actual outside temperature, etc.). If the sensor is situated in the fresh air inlet duct inside the building, the measured temperature is only correct when the fans are switched on (air flows) and the starting conditions are negatively affected – which can endanger the air-handling device's safety and even result in the water heat exchanger breaking down.

Outdoor Temperature Sensor – installed outside (NS110A)

The sensor (as with any thermometer) must be installed so that objective outdoor temperature measurement will be achieved. It must be protected against negative effects like sunshine, rainfall, frost deposits, e.g. situating it under a building's roof, using outdoor VZT roofers, situating it in the inlet louvers, inlet ducts or separate covering roof.

Room Temperature Sensors

Optionally, a room (NS100), duct (NS120) or HMI-SG controller integrated sensor can be used by the designer.

- **The room sensor** or HMI-SG controller with integrated room sensor must be situated in a spot "representing" the room temperature, and they must not be affected by local effects (heaters, windows, vertical temperature distribution in the room, etc.)
- **The duct sensor** must be situated in the room outlet duct – the advantage in this is that the average temperature of the air flowing from the room is measured without being affected by local effects (and it is hidden).


Heat Exchanger's Antifreeze Protection Sensor (NS 130R)

The sensor must be situated in the outlet air duct behind the heat exchanger.

EO Pre-Heating Control Temperature Sensor (NS 120)

To ensure correct control, the sensor must be situated behind the electric pre-heater (EO) – before other temperature adjusting components.

Figure 9 – Room sensor installation



Flue Gas Temperature Sensor

The Pt 100 sensor is used to measure the flue gas temperature. The sensor must be situated in a representative place within the flue gas installation.

Inlet Air Humidity Sensor

This is a duct sensor which must always be situated in an inlet branch after the air-handling unit. The selected position must be representative enough for the measured value. It must not be situated in the room.

Room Humidity Sensor

Optionally, a room or duct sensor can be used by the designer.

- The room sensor must be situated in the room in a "representative" place so that it will not be influenced by local effects (windows, doors, etc.)
- The duct sensor must be situated in the outlet duct from the room – the advantage here is that the mean humidity of the room outlet air is measured.

TH 167 Gas Heating Safety Thermostat

The sensor must be situated before the gas heater section behind the fan section. The thermostat must be situated so that it will start the fans to protect the air-handling components situated in front of the gas heater chamber if back air flow occurs.

Air Quality Sensor – CO₂ (VOC, CO)

The air quality sensors are placed in the outlet air duct or in the "representative" spots, thus ensuring objective air quality value measuring.

VDK-10 Smoke sensor

The smoke sensor is installed in the piping of the inlet or outlet branch, depending on the purpose of use. The VDK-10 sensor must be oriented correctly to the air flow, on the upper or side straight side of the duct, according to the manufacturer's installation diagram.


Connection of the fan frequency inverters, heat exchanger to the Modbus bus

Safety Conditions

- Properly carried out transport, storage, installation, commissioning and careful handling is the main condition for correct and trouble-free operation.
- Protection, switching, wire routing and grounding must fully comply with the local regulations applicable for wiring.
- The 230/400 V AC power wiring must be strictly separated from the signal wiring (e.g. 24 V AC SELV)!

Control and Protection Functions

Figure 10 – Inverter connection to the Modbus RTU



Wiring

■ A shielded conductor must be used for the Modbus bus connection. The maximum conductor length depends on the communication speed. A maximum length of approx. 1000 m is recommended for the baud rate of 9600 Bd. The recommended conductors are included in the documentation created by the AeroCAD design program.

■ The controller is connected to two terminals marked A+ and B- and to the REF signal detection reference voltage terminal, which must always be interconnected with other participants on the bus.

■ To ensure correct functioning of the bus, the first and last device on the bus must be fitted with a terminal resistor. The first device, i.e. the master controller, terminal resistor setting is performed using the software (ensured by REMAK in the factory). The last device terminal resistor setting is performed on the last frequency inverter in the line connection. Refer to the Modbus bus wiring diagram. The setting procedure of the last terminal resistor is described in the documentation for a corresponding frequency inverter. A 120 Ohm resistor connected between the communication can also be used to terminate the wiring.

Fan Failure Detection

■ To detect any fan failure, the motor thermo-contact and differential pressure sensor are connected to the frequency inverter inputs. The information provided by these elements is transmitted through the Modbus communication line to the control system, where it is processed.

Modbus RTU Communication Settings

■ Each frequency inverter connected to the bus must be assigned a unique address as defined in the control system data points.

Pre-set Frequency Inverter Addresses – ModBus:

Inlet Fan

Inlet fan	address =1
Backup or twin fan	address =2
Backup twin fan 1	address =3
Backup twin fan 2	address =4

Outlet fan

Outlet fan	address =5
Backup or twin fan	address =6
Backup twin fan 1	address =7
Backup twin fan 2	address =8

Auxiliary Fan

Auxiliary fan	address =9
Twin fan	address =10

Rotary Heat Regenerator


RHR motor address =11

■ The data points of all frequency inverters for communication with the Modbus bus must be set in accordance with the VCS control unit:

- Baud rate (9600 Bd – pre-set)
- Parity (none – pre-set)
- Number of stop bits (2 stop bits – pre-set)
- Response time limit
- Number of data bits (as standard, 8 bits – pre-set)

All data points for the used frequency inverters are available on our website: www.remak.eu

Figure 11 – Inverter association with a corresponding section



Warning

Frequency inverters cannot be confused within different sections! Information on the assignment of a particular frequency inverter to the respective section is shown in the figure.

Control and Protection Functions

Note: This chapter describes only the basic control functions – the detailed design, respectively compatibility, of the entire device is ensured by the configuration performed using the AeroCAD design software. For more detailed information, contact the manufacture, REMAK a.s.

Main Control Features

The VCS control unit enables automatic control of the following basic functions for air temperature adjustment:

- Heating
- Cooling
- Mixing
- Recuperation (Heat Recovery)
- Dehumidification
- PID controllers with pre-set control constants are assigned for all the above-mentioned functions. Basic settings of parameters are performed in the factory. The parameters can be changed using the HMI controller in the List of Data Points menu, item Control Constants.
- A check, respectively optimization, of the unit settings must always be performed when commissioning the unit.
- Control ensures energy-saving operation. Cascade temperature control – room temperature control or supply air temperature control.
- The required temperature for the air-conditioned room can be set by selecting one of two temperature modes. Each mode has two pre-set temperature values to maintain the required temperature (an upper limit for heating and a lower limit for cooling). These values can be changed using the HMI controller in the List of Data Points, section Settings – Temperature Modes.
- First, the control algorithm will start to control the functions which don't require energy, i.e. heat-recovery and mixing (depending on the user option). If this is not enough to maintain the required parameters or these features are not included in the air-handling unit, heating and cooling functions will be applied. If the heating or cooling control is not effective enough, an air output control will be added (heating/cooling-dependent fan speed compensation – user option). This control does not allow heating and cooling to be used at the same time, only one control sequence can be used at a time. This does not apply for special control application with controlled humidification where a cooler can be used for dehumidification and a heater for after-heating to the required temperature.
- Heat pump, water and electric heater or gas heater functions can be connected to the heating control sequence. Heat pump, water cooler and condenser unit functions can be connected to the cooling control sequence.

Temperature Correction and Limitation

The control unit enables adjustment and settings of the restricting limits for maximum and minimum supply air temperatures. In addition, it is possible to set the supply air and room temperature limits, respectively other correction or comfort options (e.g. set-point value compensation or heating/cooling-dependent fan speed compensation).

Main Control Feature and Protection Description

Using the appropriate sensors, the VCS control unit can provide comprehensive protection of the air-handling unit, such as active antifreeze protection, fan state monitoring, filter fouling or over-temperature detection of the required temperature. Any deviations from the defined states or parameters are monitored and signalled and simultaneously, safety features are activated.

Depending on the failure consequence, the following happens:

- The failure is only signalled and safety features are automatically activated. Once the failure has ceased, the unit will return to the standard mode without interference from the operator.
- If a serious failure occurs, the unit will be switched to the STOP mode, and it can only be restarted after the failure has been removed and the operator's interference. The VCS control unit system enables the air-handling unit behaviour (fan action) to be set when fire is detected (external failure, inlet or outlet air high temperature). The settings can be as follows: the inlet or outlet fan is activated, both fans are activated or both fans are stopped (air-handling unit shutdown). The control unit is switched to the fire mode. The settings can be performed using the HMI controller in the List of Data Points, section Checks, System and Network Settings – Fire Alarm.

Heating Control

Control is based on the required temperature, i.e. the selected temperature mode and data from the supply air temperature sensors, outdoor temperature and the water heat exchanger return water temperature. Control can be affected by correction values, maximum and minimum limits or antifreeze protection.

Water heating

It is controlled by the SUMX mixing set actuator using a 0–10V continuous control signal (working range of 2–10V).

Heating Mixing Set Pump Control

The mixing set pump is controlled depending on the outdoor temperature value and valve position (required heater output).

- If the air-handling unit is in the STOP and Run mode, the pump is switched on when the outdoor temperature drops below 5°C and switched off when the outdoor temperature rises above 6°C. In this case, the pump is stopped without any run-down.
- If the air-handling unit is in the Run mode, the pump is controlled by the valve actuator control algorithm. The pump is switched on when the request for the valve opening is higher than 5%.
- If the pump has not been used for 168 hours, it will be switched on and turned for 60 seconds.
- Failures (electrical) of the pump are sensed by the pump circuit breaker's auxiliary contact even in the STOP mode.

Water Heater Antifreeze Protection Operation

The VCS control unit uses so-called active antifreeze protection. It uses a three-stage concept.

Antifreeze Protection Features:

Control and Protection Functions

- Switching of the unit to the STOP mode
- Switching off of the fans
- Closing of the dampers
- Freezing danger signalling
- Mixing set control
- Pump starting
- If the air-handling unit is in the Run mode, then antifreeze protection is activated when the outdoor temperature drops below 10 °C (factory settings) and the water heat exchanger return water temperature drops below 15 °C (factory settings). The extent of the mixing valve opening depends on the water heat exchanger's return water temperature value. Antifreeze protection will be deactivated when temperatures rise above the limit parameters.
- If the air-handling unit is in the STOP - STAND-BY mode, then antifreeze protection is activated when the outdoor temperature drops below 10 °C (factory settings) and the water heat exchanger's return water temperature drops below 30 °C (factory settings). The extent of the mixing valve opening depends on the water heat exchanger's return water temperature value. Antifreeze protection will be deactivated when temperatures rise above the limit parameters.
- The control unit continuously monitors the water heat exchanger's return water temperature. If the temperature is still falling and drops below 8°C (factory settings), the following protection actions will be immediately taken regardless of the outdoor temperature:
 - The air-handling unit will be shut down, the dampers will be closed, the fans will be switched off and the failure alarm will be activated.
 - The mixing valve will be opened depending on the water temperature, and the circulation pump will be switched on.
 - The above-mentioned state will last until the operator checks the air-handling system or removes the failure cause and confirms the air-handling system is free of failure and resets the failure.
 - The control unit simultaneously monitors the supply air temperature in the Run mode. If the supply air temperature drops below 6 °C (factory settings), the following protection actions will be immediately taken regardless of the outdoor temperature:
 - The air-handling unit will be shut down, the dampers will be closed, the fans will be switched off and the failure alarm will be activated.
 - The mixing valve will be opened depending on the water temperature, and the circulation pump will be switched on.

Pre-Start Unit Pre-Heating Functions

- To avoid false freezing danger assessment in winter or during transition seasons, especially when the air-handling unit is being started, the control unit features a heating circuit pre-heating.
- Pre-heating is dependent on the outdoor temperature value. If the outdoor temperature is higher than 10 °C, the value of the valve opening will be 0 %, and pre-heating will not be activated.
- Pre-heating will be activated when the outdoor temperature drops below 10 °C. The mixing set valve will be forced to open to the value which is derived from the outdoor temperature (factory settings: +10 °C = +10 %, -10 °C = 100 %) for 120

seconds. Once this time has elapsed, the valve will be closed, "ramped down", until the mixing set control signal for heating is reached.

- If the air-handling unit is restarted within 5 minutes of the moment the air-handling unit was shut down, pre-heating will not be activated.
- Antifreeze protection setting parameters can be accessed through the HMI controller in the List of Data Points menu, sections *Parameters and Control Constants*.

Electric Heating

Electric heating can be controlled using the following options:

- Switching of the full EO, EOS heater output
- Sequential switching of the EOSX electric heater's individual sections
- Sequential switching of the EO heaters
- Control of the EOS electric heaters using a PV valve (up to 45 kW)

Electric heater protection

- If electric heater overheating (failure) is signalled (the temperature inside the heater exceeds +80 °C) by opening the emergency thermostat contacts in the heater, this signal is interpreted by the control unit.
- Electric heater control in the REMAK unit is doubled – the heater thermostat failure signal is simultaneously sent to the controller and auxiliary module.
- The controller will interpret the failure signal and perform appropriate safety functions; first, the control signal for electric heating is blocked and then the heater contactor is disconnected.
- The auxiliary safety module will mechanically disconnect the EO/S/X circuit breaker (i.e. it will trip the under-voltage trigger of the circuit breaker).

At the same time, control logic will ensure safe cooling of the heater when the air-handling unit is being shut down – transition to the STOP mode. The controller will ensure run-down of the fans (optional) so that the heating core is cooled.

Gas heating

The gas heater is controlled using a burner output controller and a bypass damper (if the section is equipped with a BP damper). The required heating temperature is controlled depending on the required temperature (selected mode) and the readings from the inlet temperature, outdoor temperature and flue gas temperature sensors.

Gas Burner Output Control

- Single-stage ON/OFF control
- Two-stage control (two output stages)
- Modular (three-point), step-less control of the entire burner output range

Burner lighting is contingent on the fan operation.

At a 5 % request for heating, the 1st burner output stage is switched on. The minimum pre-set running time of this stage is 150 seconds. If the required temperature is not reached, the 2nd stage will be switched on at 70 % of the request for heating (two-stage output control). The second output stage is not restricted to the minimum running time, and will be switched off at 40 % of the request for heating.

Control and Protection Functions

Further re-lighting of the burner is possible once the protection time of 150 seconds has elapsed. Modular control of the burner is step-less based on the actual requirement (set point) within the Min to Max output range of the gas burner.

The bypass damper (if included in the section) is controlled by a 0-10V signal (the operating range is 2–10 V depending on the required flue gas temperature (160 °C pre-set). The regulating damper position controls the air flow coming through the gas section and bypass section so that a constant flue gas temperature is maintained. Accordingly:

- when $T_{\text{flue gas}} > T_{\text{flue gas required}}$ the bypass damper closes
(closed = **0 V**)
- when $T_{\text{flue gas}} < T_{\text{flue gas required}}$ the bypass damper opens
(open = **10 V**)

Protection and Safety Functions:

The control unit ensures fan run-down to cool down the gas sections (the pre-set run-out time is 180 s). The gas section (chamber) temperature for protection and safety functions outside the VCS control system is picked up by the ESD3J triple electronic safety thermostat (located on the chamber) while the temperature before the heater chamber is picked up by the TH167 stem thermostat (it is necessary to install this thermostat when connecting the control system and set it to 50 °C). The system of safety thermostats along with the control unit provides the following functions:

- If a temperature of 50 °C (T3) is exceeded, even in the STOP mode, forced switching of fans (and opening of dampers) is activated in order to cool down the chamber.
- If a temperature of 80 °C (T2) is exceeded in the Operating mode, the heater output control signal is switched off. When the temperature falls, this signal is switched on again. This is an operation safety function with no signalling of the failure.
- If a temperature of 110 °C (T1) is exceeded, forced disconnection of the burner from the supply voltage is performed and this state is maintained until the thermostat is reset by the button located on its body. The reset cannot be performed until the chamber has cooled down to below the temperature evaluating threshold. Before the burner can be reset or restarted, it is necessary to evaluate and remove the reason for overheating (by-pass cannot be closed, insufficient air flow through the heat exchanger, exhaust gas temperature setting, etc.). The T1 stage of the triple thermostat is detected by the control unit (including/in series with the burner failure when it is not disconnected from the power supply) which initialises the Burner (heater) failure message and switching off of the unit (STOP) with run-out of fans to cool down the chamber.
- If the air back draught (chimney effect) occurs during the STOP mode and the air temperature in front of the gas section rises above 50°C, the TH 167 thermostat will close and switch on the fans, open the inlet and outlet dampers, and thus the gas heater will be cooled down.
- Fan failure – the unit is immediately switched to the STOP mode without fan run-out (evaluated also during the STOP mode).
- The control unit monitors the states of the control sensors and evaluates exhaust gas overheating as well as failures of sensors.

Heating and Cooling using Heat Pump

Two general control options are available for heat pumps. Control is not fixed to a specific heat pump type. The control option selection depends on the designer's consideration and heat pump type. Two control contacts and an analogue output are used for control.

Option A

The first digital contact is used to define the air temperature adjustment type – cooling/heating. The second digital contact is used to define the process activation – off/on. The analogue output 0..10 V represents the proportion of the request for heating or cooling.

Option B

The first digital contact is used to define the heating process – heating off/heating on. The second digital contact is used to define the cooling process – cooling off/cooling on.

Analogue output 0..10 V represents the proportion of the request for heating or cooling.

The heat pump control is equipped with an outdoor temperature-dependent blocking. The blocking alert is only informative and is not a failure state. The heat pump will be shut down if the outdoor temperature is equal to or lower than the reference temperature (see the Data Points). The heat pump will be started if the outdoor temperature is higher than the reference temperature (with hysteresis of 3 °C). Frequent switching of the heat pump is eliminated by blocking of the cooling/heating restart for 120 seconds. The minimum operating time of the heat pump can also be set. When cooling/heating is required, the heat pump will be switched on at 20% of the control signal and switched off at 10% of the control signal (hysteresis of 10%). The low reference signal on the analogue output (0-10V) can be set in a range from 0% to 50 % of the control signal (pre-set 30 %, i.e. a 3-10 V control). The unit can be equipped with a function blocking the air-handling unit operation when defrosting the heat pump. The shut-off state of the air-handling unit is indicated on controllers. After the heat pump defrosting process has been completed, the air-handling unit operation will automatically be resumed.

Furthermore, it is possible changing behaviour of different control signals, e.g. AO signal inversion (see Data Points).

Cooling Control

All cooling sources can be disabled depending on the outdoor temperature. Cooling is not disabled if the outdoor temperature is higher than the pre-set cooling enable temperature (pre-set 12 °C).

Water Cooling

It is controlled the same way as water heating. The mixing set pump is switched depending on the control signal for the cooling valve. If the air-handling unit is in the Run mode, the pump will be switched on when the control signal for the cooling valve is higher than 5% and switched off when the control signal for the cooling valve is lower than 1%.

- Pump turning for 60 seconds is performed after every 168 hours of pump inactivity.

Direct Cooling

Direct cooling is controlled by switching the condensing unit output or by step-less control of the inverter condensing unit.

Control and Protection Functions

If a single-circuit condensing unit is used, it will be switched on when 20% of the control signal is required and switched off at 10% (10% hysteresis) of the control signal. If a double-circuit condensing unit, respectively two single-circuit condensing units are used, two stages will be switched. The first stage will be switched on when 20% of the control signal is required and switched off at 10% (10% hysteresis) of the control signal. The second stage will be switched on when 70% of the control signal is required and switched off at 60% (10% hysteresis) of the control signal. Frequent switching of the single-stage condensing unit is eliminated by repeated cooling blocking for a certain time depending on the setting.

To eliminate the simultaneous switching of both stages at a sudden control signal increase, the timing (duration of the first stage) is set.

Inverter Cooling Unit

It is controlled using the start enable signal and step-less compressor output control signal. The minimum operating time can also be set. The condensing unit will be switched on when 20% of the control signal is required and switched off at 10% (10% hysteresis) of the control signal. The unit compressor speed is controlled using a 0–10 V control signal.

Inverter Unit and Single-Stage Condensing Unit Combination

When cooling is required, the inverter will be switched on first and then the output will be raised to the maximum. Consequently, the single-stage condensing unit is switched on while the inverter output is lowered to 30% of the control signal. If the request for cooling is still rising, the inverter output will be increased from 30% up to the maximum level of the control signal.

If the request for cooling is decreasing, the inverter output will start to decrease and will be switched off at 0% of the control signal. The single-stage condensing unit is still in operation. In this phase of control, time blocking of the inverter is applied and simultaneously the single-stage condensing unit is prevented from being switched off. If the request for cooling is still decreasing once this time has elapsed, the inverter will be switched on with a maximum control signal and the single-stage condensing unit will be switched off. When the single-stage condensing unit is switched off, the inverter output will be at the maximum. Then the inverter output is reduced in accordance with the request. Thus step-less control is ensured in the entire cooling capacity range.

Direct Evaporator Protection

This protection is ensured using the CAP 2M capillary thermostat, which disconnects the control signal in the event of ice build-up on the evaporator. If two evaporators are used, each of them will have its own thermostat.

Heat Recovery Control

Heat Recovery control of the rotary heat regenerator is ensured by step-less control using the heat exchanger frequency inverter through the Modbus communication bus. The plate heat exchanger, respectively plate heat exchanger bypass, is controlled using a 0–10 V (2–10 V) continuous signal. 100% of the step-less control signal equals 100% heat recovery, i.e. maximum speed of the rotary heat regenerator or closed

bypass of the plate heat exchanger. A digital output for two-point control (ON/OFF) is another option – thus, for example, the glycol circuit pump can be switched.

Heat Exchanger Antifreeze Protection

- Rotary heat regenerator protection is ensured using the NS 120 temperature sensor situated in the outlet air duct behind the heat exchanger. If the temperature drops below the pre-set ice build-up threshold, the speed of the rotary heat regenerator will be reduced. If the speed reduction is not enough to de-freeze the heat exchanger, the heat exchanger will be stopped. The heat exchanger speed reduction depends on the PID controller's constant setting.

- Similarly as the rotary heat regenerator, control of the plate heat exchanger is ensured using the NS 120 temperature sensor and bypass actuator control. If the temperature behind the plate heat exchanger drops below the pre-set ice build-up threshold, the bypass damper actuator will be activated and the damper will stay open until the ice build-up melts from the heat exchanger. A pressure loss sensor or a CAP 3M capillary probe can also be used in some cases.

Protection of the plate heat exchangers without bypass can be ensured by a fan speed reduction.

Plate heat exchanger – air-handling unit run-out

In some cases, the run-out will be performed when the air-handling unit is stopped. This will ensure drying of the heat-exchanger and prevent the creation of conditions for the growth of microorganism. Temperature and humidity sequences are active during this run-out. This feature is conditioned by previous operation of the heat recovery and the outside air temperature. As default, this feature is switched off. For the change in all values, refer to List of Data Points – Fans.

Mixing Damper Control

It is ensured by step-less control of the mixing damper actuators using a 0–10V (2–10V) continuous signal. The signal is directly proportional to the air circulation, i.e. 100% of the signal corresponds to 100% of the required air circulation (0% of fresh air).

The maximum level of air recirculation (when the fans are running) is limited by the minimum (hygienic) request for fresh air. If the device is in the STOP mode, the inlet and outlet duct dampers are closed and the circulation damper is open.

Heat Recovery and Mixing Economy Control

If the temperature in the room (in the outlet duct) is lower than the outdoor temperature and a request for cooling simultaneously exists, the heat recovery and air recirculation functions will be automatically switched on at the maximum level to minimize the energy demand for cooling. This happens if the temperature difference reaches 3 °C (the room temperature is lower than the outdoor temperature) while the temperature in the room (in the outlet duct) is higher than the required temperature and the difference between these two temperatures is at least 2 °C.

Heat recovery and mixing functions will be switched off when the outdoor temperature is lower or equal to the room (outlet air) temperature, or the room (outlet air) temperature is higher

Control and Protection Functions

or equal to the required room temperature. Heat Exchanger control function activation settings are described in the chapter *Additional Operating Mode and Function Setting Options*.

Heat Recovery and Mixing Control at Air-Handling Unit Start-Up

The starting outdoor temperature and time are set for heat recovery and mixing (see Data Points). If the outdoor temperature is lower than the pre-set value at the air-handling unit start-up, the heat recovery and mixing functions will be switched on at the maximum level.

Mixing Sequence Selection

The mixing sequence for heating control is optional – the pre-set sequence for heating is as follows: first, the mixing function is applied and if the request for heating still increases, then the heating function will be applied (pre-set). This sequence can be changed according to user needs, see the chapter *Additional Operating Mode and Function Setting Options*.

Humidity Control

The control unit evaluates the control signal for humidification or dehumidification depending on the room and inlet humidity sensors and the required humidity selected by the user.

Humidification

Humidification control can be ensured by two methods. Depending on the technology used, control for the required humidity can be performed by the VCS control unit or by an autonomous control (e.g., integrated into the humidifier).

In the first case, humidity control is ensured by the VCS control unit. Settings of humidity set-points and control parameters are included in the VCS control unit. The same applies for dehumidification. Thus, full accord of dehumidification and humidification control is ensured and unsuitable settings of set-points cannot be made. Furthermore, all the necessary parameters and information can be found in the control unit controllers. The control unit sends the start command, the request for humidification output to the humidifier, and monitors humidifier failures.

If autonomous control is used, the control unit sends information on the air-handling unit operation to the humidifier. In this case, control for the desired humidity is fully ensured autonomously by a specific humidifier. The control unit has no information about the state or output of the humidifier.

Dehumidification

Air dehumidification is ensured by water or direct cooling. In case of dehumidification, after-heating is ensured by the heater, which is situated after the cooler. The control unit evaluates the control signal for the air cooler and heater depending on the room sensors and the required humidity selected by the user. The humidity in the room can be set from 20% to 95%. If the air-handling unit is equipped with a water cooler or a condensing unit with an inverter, the humidification process can be controlled using 0–10 V (2–10 V) step-less control. If the air-handling unit is equipped with a one-stage or a two-stage condensing unit, the humidification process is controlled using step control. When cooling is active due to a request for dehumidification, air after-heating is allowed (exceptionally) using the heater situated after the cooler.

If the request for heating is increased above 90 %, the request for dehumidification cooling is gradually reduced until the required inlet air temperature, respectively zero value of the request for cooling (at 100 % request for heating), is achieved – temperature control is prioritised to humidification.

Auxiliary Control Functions

Pre-heating function

Pre-heating is switched ON/OFF depending on the pre-set outdoor temperature value (pre-set 5 °C).

The electric pre-heater (EO) is switched using a contactor. It is controlled according to the pre-set (required) temperature and compared with the temperature behind the preheater (measured by the NS 120 sensor). If the air-handling unit is switched off when the EO pre-heater is active, run-down of the fans will be performed. Failures are evaluated similarly as with EO heaters but the system is not shut down.

Water pre-heating is controlled by switching the pump (not included in the REMAK delivery) depending on the request for pre-heating. Antifreeze protection is ensured by a temperature sensor (NS130R) situated in the water heat exchanger return line. If the water temperature in the water heat exchanger's return line drops below the pre-set value, the freezing alarm will be activated, including safety functions, and the air-handling unit will be stopped.

Auxiliary After-Heating Function with EOS

This function is applied when the main heater output is not sufficient (e.g. when water heating is shut down during transition seasons, etc.) It is possible to restrict the maximum electric after-heater output for each output stage. Thus correct cooling of the heating rods is ensured (see the Data Points). The electric after-heating function can also work as an independent sequence with its own settings of required temperatures. The electric after-heating function is disabled in the following cases:

- When night chilling is active
- During temperature start-up

Heating Water Source Switching

If this auxiliary function is active and the controller detects the need for heating water (request for air heating), the output for the heating water source (boiler) will be switched on – if the device is started in advance before the fans have been switched on. This function will only be applied if the outdoor temperature is higher than the pre-set value (factory settings: 15 °C) otherwise the output is switched on permanently. Correct operation of the assembly must be ensured by suitable settings of the device start-up sequence parameters. To enable the heating water source switching function's correct operation, the outdoor temperature sensor must be installed so it will be able to read the actual outdoor temperature.

Heating cable switching

In cases where a heating cable is used as a frost protection for condensate drain siphons, the control unit ensures its switching according to the outside temperature. The preset switching temperature is 2 °C (hysteresis 1 K), the power according to the cable used is self-regulated.

Control and Protection Functions

Figure 12 – Actual set-points with compensation (shift)





Figure 13 – Set-Point Compensation (Shift) Description and Settings



Temperature Required Value Compensation

Temperature compensation is actually a correction (shift) of the required value (set point) of the controlled (room) temperature according to the outdoor temperature sensor reading, which adjusts (in addition to other correction values) the temperature specified in the temperature mode settings. It is mainly used to reduce differences between outdoor and indoor temperatures (to eliminate thermal shocks) and the energy demand of device operation. On the other hand, it can increase differences ("aggressiveness") in control, if adjusted reversely.

Note: The data point values on the controller are described in full text (not using abbreviations like TH1, TC1, etc.). Generally, minus control is also possible.

Fan Speed Compensation

The VCS control unit system enables the pre-set fan speed to be adjusted depending on the air temperature, air quality or mixing damper position using fan speed compensations. The sum of individual compensations creates a so-called total compensation which affects the fan speed change.

Outdoor Temperature-Dependent Fan Speed Compensation

The compensation adjusts the fan speed in regards to high or low outdoor temperatures. The fan speed is adjusted depending on the maximum heating or cooling compensation settings. A positive compensation value represents a fan speed increase. A negative compensation value represents a fan speed reduction.

Note: To make the compensation effective, it is necessary to set a suitable maximum compensation value if only one compensation is used.

Room (Outlet) Temperature-Dependent Fan Speed Compensation

The fan output is adjusted depending on the required room temperature and the measured room (supply air) temperature. The compensation will be activated if the measured temperature is lower than the required temperature. Using the compensation function, the fan speed can either be increased or reduced.

Heating/Cooling-Dependent Fan Speed Compensation

The request for heating or cooling is evaluated by measuring the supply air temperature and comparing it with the required supply air temperature and then followed by fan output compensation. The compensation will be activated if the difference between the required supply air temperature and the actual supply air temperature is greater than the pre-set temperature hysteresis. The actual correction extent is related to the settings of the PID controller constants.

■ **Heating Compensation:** It reduces the fan output and thus sufficient supply air heating is achieved based on the smaller air volume (used to eliminate insufficient output of the heat exchanger).


■ **Cooling Compensation:** It increases the fan output (higher air-flow rate) and thus makes the room environment more comfortable, if cooling is insufficient.

This type of compensation also enables a change to the priority cooling – fan. So the change in the fan speed is applied first and then active cooling is applied as the request for cooling is rising. The settings can be performed using the HMI controller, refer to the chapter Additional Operating Mode and Function Setting Options.

Air Quality-Dependent Fan Speed Compensation

The fan output can be adjusted depending on the measured CO₂ (VOC, CO) content and the pre-set required value. If the CO₂ (VOC, CO) content is higher than the pre-set (permissible) value, the fan speed will be increased. The compensation extent is affected by the settings of the PID controller constants. The measured value range must be set depending on the sensor used. Further, the sensor characteristic (Normal ascending for CO₂ and VOC or Inverse descending for CO) must be set. For the settings, refer to the Data Points.

Figure 14 – Fan Speed Compensation Description



Control and Protection Functions

Air Quality-Dependent Damper Position Compensation

Functionality is similar and the settings are common with the air quality-dependent fan speed compensation. The fan output or mixing damper position can be affected by the difference between the measured and pre-set required CO₂ (VOC, CO) concentration in the room. The volume of fresh air will be increased if the measured value is higher than the required value. The volume of circulated air will be decreased. The compensation extent is affected by the settings of the PID controller constants.

Humidity-dependent Damper Position Compensation

If dehumidification using cooling is not sufficient (or not available), humidity-dependent mixing damper position compensation is the next step. This is adjusted depending on the required humidity and measured humidity in the room. If the measured humidity is higher than the required humidity in the room, the compensation will be activated.

Humidity-dependent Fan Speed Compensation

The fan output is controlled depending on the required humidity and measured humidity in the room. If the measured humidity is higher than the required humidity in the room, the compensation will be activated. The compensation function can either be set to increase or reduce the fan output.

The compensation functions can be enabled using the HMI controller, refer to the chapter *Additional Operating Mode and Function Setting Options*.

Fan Speed Control

The VCS control unit enables either software or manual air output control, i.e. the speed of the following fans:

- Single-speed fans (ON/OFF control)
- Two-speed fans (two-stage control)
- Single-speed fans' backup (ON/OFF control)
- Five-stage TRN voltage controllers
- Fan frequency inverters using the Modbus bus – five-stage control

A standard control can be completed with a 3rd auxiliary fan which is controlled from the outlet or inlet fan depending on the control unit configuration.

Two-Speed Fans

The two-speed fans are always started using the first stage at the air-handling unit start-up. The transition time from the first to second stage can be adjusted. The transition time can also be adjusted for the reverse transition from the second to the first stage.

TRN Voltage Controllers

The control unit enables the voltage controllers to be connected and controlled in five output stages. Depending on the request, inlet and outlet control can be common or independent. The required output stage is always set in common. If the fans are controlled independently, it is possible to set the outlet controller correction against the inlet controller (see the Data Point Settings – TRN Correction). However, the control unit must be specially manufactured for this function (depending on the customer request). Either the same cor-

rection can be set for all the speed stages or for each speed stage independently. For the correction settings, refer to the chapter *Optional Function and Mode Settings*.

Frequency Inverters

For five-stage control devices, the request for the inlet and outlet fan speed is set in common. However, for frequency inverters, the request for the inlet and outlet fan output (0-100%) can be set separately for each stage (1 to 5) (see the Data Point Settings – Fans).

Single-Speed Fan Backups (ON/OFF Control)

The backup motor is started if the main motor fails. The backup is used either for the inlet or outlet fan, respectively for both. The motors are equipped with thermal protection (thermo-contact) and current protection. If the backup motor has been started, it is not possible to restart the main motor without resetting the failure. The main and backup motor current protection has a delay pre-set. Switching from the main to backup motor is immediate without delay if the main motor fails.

Backup fan control via Modbus communication bus

Using the Modbus communication bus, the five-stage fan control enables a backup fan or a pair of backup fans to start up if the main fan fails. If the backup fan or pair of backup fans fails, the air-handling unit will be shut down. Information about air-flow failures and motor overheating is sent via the Modbus communication bus and signalled accordingly.


Constant Air Flow/Pressure Control

When designing constant flow, pressure, overpressure and underpressure control, it is advisable to consider the overall design of the air-handling unit, respectively application of the mixing damper, and how the control behaviour can affect the measured pressure value.

Constant Air Flow Control

Fan speed is controlled depending on the desired air flow rate (m³/h). The air flow rate (air pressure in the diffuser recalculated to the air flow rate using the "k-factor") is measured by a sensor; the control system evaluates this value and compares it with the required value. The resulting fan speed is controlled so that the required air flow rate will be reached at the point of measurement (fan diffuser).

Figure 15 – Constant Airflow Control



Control and Protection Functions

It is necessary to set the following pressure sensor parameters (see the Sensor Operating Manual):

- Mode (for CPG = Mode 5.00)
- Measuring range: As needed

The correct range can be determined using a formula:

$$\Delta p_{\max} = \frac{V_{\max}^2}{k^2}$$

(where k = "k-factor", Vmax = designed air flow rate of the device). The correct sensor range is then set according to the calculated pmax value.

- K-factor of the respective fan

It is necessary to set the following parameters of the VCS control Unit (see List of HMI Data Points):

- Air flow sensor measuring range – (maximum value from the CPG air flow sensor in m³/h)
- This can be calculated using the formula or read from the CPG sensor menu (see the Sensor Operating Manual).
- The maximum measured air flow rate can be calculated according to the following formula:

$$V_{\max} = k \times \sqrt{\Delta P_{\max}}$$

Example: K-factor = 308, Maximum sensor range Pmax = 2000 Pa, Vmax = 13774 m³/h. This value is then entered as the maximum range of the sensor in the VCS using HMI.

Note: In AC, the "Max. Air Flow Rate" is stated for the fan assemblies. Attention! This is not the maximum range of the air flow sensor to be entered in the VCS control unit.

- Number of fans (for twins = 2). The air flow rate of one fan is measured and is then multiplied by the number of fans.
- Required values (separately for the inlet and outlet fans) 5 required values are available for selection.

Constant pressure control

Fan speed is controlled depending on the desired air pressure (Pa). The air pressure is measured by a sensor; the control system evaluates this value and compares it with the required value. The resulting fan speed is controlled so that the required air pressure will be reached at the point of measurement.

It is necessary to set the following air flow sensor parameters (see the Sensor Operating Manual):

- Mode (for CPG = Mode 4.00)
- Measuring range: As needed (200 Pa, resp. 1000 Pa)

It is necessary to set the following parameters of the VCS control Unit (see List of HMI Data Points):

- Air pressure sensor measuring range – (maximum value from the CPG air pressure sensor in Pa)
- Required values (separately for the inlet and outlet fans). 5 required values are available for selection.

Constant Air Flow + Overpressure in the Room Control

The inlet branch (fan) is adjusted to the constant air flow so that the required air volume is delivered to the room. The outlet branch is adjusted to the required difference in overpressure in the room. Thus, the outlet fan is adjusted to the required pressure (overpressure) depending on the pressure sensor location.

Application: Preventing dirt from entering the room.

Constant Air Flow + Underpressure in the Room Control

The outlet branch (fan) is adjusted to the constant air flow. The inlet branch (fan) is adjusted to the difference in underpressure in the room. Thus, the inlet fan is adjusted to the required pressure (underpressure) depending on the pressure sensor location.

Application: Preventing dirty air from entering the adjacent rooms

Note: When commissioning the system, it is necessary to perform the settings and regulation of the device (PID constants, FI ramp, etc.)

Basic Information on VCS Operating Modes

Operating states

There are three operating states defined for VCS control units (Stop, Run, Auto):

Stop – The device is in standstill mode (fans stopped). Important safety features like antifreeze protection and moderate pre-heating of the water heater are retained.

Run – The device is started in accordance with the pre-set temperature mode and fan speed.


Auto – Control is switched to the next operating mode with a lower priority. The Auto operating state cannot be set in the time schedule mode because it is a control type with the lowest priority.

The operating mode determines which operating state will be active according to priorities (see Operating Modes).

Operating Modes


The control unit's operating state (i.e. whether the air-handling unit is in the Stop or Run state) is determined by one of the operating modes (manual control, external control, HMI-SG controller, BMS or time schedule modes). HMI-DM or HMI-TM controllers affect control in the manual control mode. External control is performed by single- or two-contact control. BMS control enables control of the control unit by the higher level control device (e.g. smart building control systems; Note: pending). To control air handling systems, the HMI-SG controller is connected to the control unit.

Figure 16 – Constant pressure control



Additional Operating Modes

Figure 17 – Operating modes



The operating mode which will determine the device's operating state (Run or Stop) is determined by the priority. Each operating mode is assigned a priority, i.e. the first option to control the control unit, to eliminate mutual interference. The operating modes are prioritized as follows, from the lowest to highest priority:

- Manual control
- External control
- Local HMI-SG controller
- BMS (pending)
- Time schedule
- Additional operating modes

The priorities and entire control system are shown in the diagram (Figure 17).

The fan speed control parameters are available through the HMI controller in the List of Data Points in the section Settings – Fans (inlet fan backup, outlet fan backup, TRN correction).

Air-Handling Unit Additional Operating Modes

If no operating mode is applied and the time schedule mode is in the Stop state, the air-handling unit can be started from additional operating modes. The user can use the following additional operating modes to start the air-handling unit:

- Night chilling
- Temperature start-up
- Optimized start

Additional operating modes can be activated by the HMI-SG controller in the List of Data Points in the section Settings – Additional Operating Modes, Functions.

Control Application Starting Algorithm

Air-handling system operation safety is assessed first (fire detection and operational safety of the air-handling devices). Then the operating modes and their priorities are assessed (Manual, External, HMI-SG controller, BMS and time modes). If no control mode is currently used, the air-handling unit can, but may not, be put into one of the additional operating modes depending on the user's option. All the operating modes and their correlation are shown in the figure # 10 - "Operating modes". The current operating mode can be monitored through the HMI controller in the List of Data Points in the section Monitor – Current Modes.

When the fans run and the air-handling unit is in operation, two basic groups of parameters are used to control operation:

- Temperature mode
- Fan output (speed)

The fan output or speed can be set directly at levels corresponding to the air-handling system configuration:

- Single-speed motor fans:
 - >> Stage 1
- Two-speed motor fans:
 - >> Stage 1 / Stage 2
- All five-stage controlled fans:
 - >> Stage 1 / Stage 2 / Stage 3 / Stage 4 / Stage 5

See the chapter Fan Speed Control.

Additional Operating Modes

Night Chilling

During night chilling, cold outdoor air is used to cool internal rooms of the buildings, thus excess heat accumulated in buildings during the day in summer months is removed. Night chilling minimizes the use of cooling devices and reduces the energy demand for temperature control day hours. During night chilling, the inlet and outlet dampers are fully open and fans run in the highest output stage. Night chilling start-up is enabled 12 hours before activation of the selected time schedule.

Activation

When the following conditions are fulfilled simultaneously:

- $T_{VEN} > T_{MIN}$
- $T_{VEN} < T_{PRO} - \Delta$
- $T_{PRO} > T_{ZAD} + T_{HYS}$

Termination

If one of the following conditions is fulfilled:

- Once minimum operating time has elapsed while no time mode is active (Stop mode)

- $T_{VEN} > T_{PRO} - 1$
- $T_{PRO} \leq T_{ZAD}$

T_{MIN}	Minimum outdoor temperature;
T_{VEN}	Outdoor air temperature;
Δ	Outdoor and indoor temperature difference
T_{ZAD}	Required room temperature
T_{HYS}	Temperature hysteresis

Temperature Start-Up

This feature prevents the building from overheating or overcooling. The energy used to maintain a constant temperature range and system temperature oscillations are lower than the energy consumption for overheated or overcooled room control. Air from the room is re-circulated through the air mixing section (mixing damper fully open). The fan speed is set to the highest output stage. During temperature start-up, it is possible to select whether the inlet and outlet dampers or dampers along with the outlet fan will be blocked. This can be performed using the HMI controller, refer to the chapter Additional Operating Mode and Function Setting Options.

Cooling

Activation

When the following conditions are fulfilled simultaneously:

- $T_{PRO} > T_{S,CH}$
- Once the t_{BL} time interval has elapsed

Termination

If the following condition is fulfilled:

- $T_{PRO} < T_{S,CH} - T_{HYS}$

Heating

Activation

When the following conditions are fulfilled simultaneously:

- $T_{PRO} < T_{S,O}$
- Once the t_{BL} time interval has elapsed

Termination

If the following condition is fulfilled:

- $T_{PRO} > T_{S,O} + T_{HYS}$

T_{PRO}	Required room temperature
$T_{S,CH}$	Starting temperature for cooling
$T_{S,O}$	Starting temperature for heating
T_{HYS}	Temperature hysteresis at the stop
t_{BL}	Heating blocking time
t_{BEH}	Time remaining to start the time schedule

Optimized Start

This feature is used to ensure the comfortable temperature to be reached before the time schedule has been activated. Thus possible initial temperature non-conformities after the time schedule activation are removed. This feature includes the setting for the room ventilation to have the room temperature controlled as soon as possible. This is based on air recirculation within the room along with cooling or heating adjustment. The mixing damper is fully open.

It is possible to select whether the inlet and outlet dampers will only be blocked or whether the outlet fan will be blocked as well.

Cooling

Activation

When the following conditions are fulfilled simultaneously:

- $T_{PRO} > T_{S,CH} + T_{HYS}$
- $t_{ATP} < t_{KOM}$

Termination

If the following condition is fulfilled:

- $T_{PRO} < T_{S,CH}$

Heating

Activation

When the following conditions are fulfilled simultaneously:

- $T_{PRO} < T_{S,O} - T_{HYS}$
- $t_{ATP} < t_{KOM}$

Termination

If the following condition is fulfilled:

- $T_{PRO} > T_{S,O}$

T_{PRO}	Required room temperature
$T_{S,CH}$	Required temperature set-point for cooling
$T_{S,O}$	Required temperature set-point for heating
T_{HYS}	Temperature hysteresis
t_{KOM}	Pre-set interval before time program start-up
t_{ATP}	Time remaining to the time program start-up

Night Turning Feature

When the supply air temperature sensor is not present, the outlet air temperature is evaluated. As the temperature is measured in the outlet, the fans are started at specified time intervals and air from the room is drawn into the outlet duct. The night turning feature is used along with the night chilling or temperature start-up modes. Night turning can be specified by the turning start time, time remaining to next turning and turning duration time.

Temperature modes

The VCS control unit system offers the possibility to maintain the controlled room or supply air temperature using two user adjustable temperature modes:

- Comfortable (normal mode usually used for temperature control)
- Economy (e.g. night moderate heating)

Temperature modes are defined by the levels and staging of the required temperature set-points, respectively the temperature difference (systems with heating and cooling) – i.e. according to the environment comfort. They also affect the operating energy demand. Each temperature mode is defined by the temperature settings for heating (lower environment temperature limit – minimum temperature) and the temperature settings for cooling (upper limit – maximum temperature). The area of maintained controlled temperature ("dead zone") lies between these temperature set-points. Of course, maintaining the pre-set temperatures is dependent on the correct dimensioning of heating or cooling systems. Temperature modes are correlated so that the less comfortable mode has the required temperature:

- For heating, the required temperature (lower limit) is always lower than (or the same as) the more comfortable mode.
- For cooling, the required temperature (upper limit) is always greater than (or the same as) the more comfortable mode

For more comfortable modes in systems with both heating and cooling, the environment temperature "dead zone" is always narrower (or the same). Temperature modes are pre-set, see Data Points, Setting – Temperature Modes.

Note: The system automatically monitors the above-mentioned temperature correlation and immediately adjusts the information about the possible maximum and minimum of each value depending on the user settings.

Warning

Settings, respectively the control process, also affect the correction values.

Time modes

The VCS control unit system provides the possibility to control operation depending on pre-set time schedules (modes).

- Daily schedule – allows max. 6 changes per day (mode with the lowest priority)
- Weekly schedule – allows max. 7 changes per week
- Exception schedule – allows max. 10 changes per week
- Switch-off schedule – allows max. 10 changes (mode with the highest priority)

These modes interact, applying the system priorities. At any time, the air-handling operation is always controlled by the time schedule with the highest priority provided that it has an active time interval for that moment. The weekly and daily schedules can be overridden by the exception schedule or switch-off schedule at any time. The daily schedule is arranged for each day of the week.

The weekly schedule is the same for each week of the year. Requirements for specific days (e.g. holidays) must be scheduled within the exception time schedule.

The following parameters are set for the weekly and daily schedules:

- Start time (= end of previous interval)
- Fan output (speed) stages
- Temperature mode

The exception and switch-off schedules can be set for:

- Date – day of the week
- Range of days – a period (e.g. holiday)
- Week – days of the week (Monday, Tuesday,...)

Warning!

A time interval of 00:00 must be set for the start of each day. The default interval for that day.

The default setting is weekly and daily time schedule.

Temperature modes in weekly and daily time schedules can be set using the HMI-SG controller in List of Data Points in the Settings section – Temperature modes, the chapter Control (HMI-SG controller). The exception and switch-off schedules can be set using HMI-DM, HMI-TM or HMI@Web controllers.

Time Schedule Operating Settings

Date	
Starting day: *01.01.12	1st January 2012 is the specific day of operation.
Starting day: Mo,**	Every Monday is the specific day of operation.
Starting day: *,*Even.**	Every even month (February, April, June,...) is the specific month of operation in each year.
Range of Days	
Starting day: *23.06.12 End: *12.07.12	Days from 23rd June 2012 to 12th July 2012 are the specific days of operation in the year.
Starting day: *23.12.** End: *31.12.**	Days from 23rd to 31st December are the specific days of operation in each year.
Starting day: *23.12.11 End: *01.01.12	Days from 23rd December 2011 to 1st January 2012 are the specific days of operation.
Starting day: *,*.*.** End: *,*.*.**	An exception time schedule or a switching off schedule is permanently active and the weekly program will not be applied!
Week	
Day of the week: *fri,*	Every Friday is the specific day of operation
Day of the week: *Fri,Even	Every Friday in an even month (February, April, June,...) is the specific day of operation
Day of the week: *,*,*	When the starting day is entered in this way, an exception time schedule or a switching off schedule is permanently active and the weekly program will not be applied!
Day of the week: 2.,*,*	The second week of every month is the specific day of operation.

Control (HMI-SG)

Local HMI-SG controller



The HMI-SG (Human Machine Interface) enables full control and monitoring of the equipment's operating parameters. The air-handling unit parameters can be accessed through the List of Data Points, which is protected by the password applicable for the corresponding access level.

HMI-SG controller enables the following items to be reviewed:

- Room (outlet) temperature
- Current air-conditioning process (cooling, heat recovery, mixing or heating)
- Temperature mode (Economy, Comfort)
- Current system time and day of the week
- Fan output stage

Other information is available via the List of Data Points, see the chapter Data Point List Access and Editing. The HMI-SG POL822.60/STD hand controller is used to control air-handling devices. This controller can be connected to the POL 4xx or POL 6xx master controller (respective to the terminals ready in the control unit).

Operating conditions

Degree of protection: IP 30 Permissible ambient temperature: 5 °C to 40 °C Relative humidity < 85 %


Warning:

To avoid unintentional unit start-up, the master switch must be switched off and locked when repairing the VCS unit.

Wiring and Installation

The HMI-SG controller is connected to the Process Bus (KNX). A twin cable or a twisted pair of leads can be used to perform the connection to the KNX bus.


Figure 14 – Connection to the control unit



The controller can be installed using a wall wiring box or embedded in plaster. The maximum distance between the control unit and room controller is up to 700 m. HMI-SG controllers are connected to the master controller in series and wiring is always performed to one point.

Note: The Installation Instructions are part of the HMI-SG controller delivery.


Figure 18 – Wiring box installation



Function Buttons

The room unit consists of the face plate and back cover, which can be separated. There are 8 function buttons on the controller's face plate.

Figure 19 – HMI-SG controller



Controller Description

Table 3 – Function Buttons description

Button number	Icon	Name	Function description
T1		Power	Air-handling unit start or stop
T2		Presence	not used
T3		Program	The time schedule button: by holding this button, you can set the date; by pressing this button, you can set the desired temperature mode timing and required fan output stage
T4	-	Minus	Temperature correction – pre-set depending on the selected temperature mode
T5	+	Plus	Temperature correction – pre-set depending on the selected temperature mode
T6		OK	Confirmation of the date or time schedule settings
T7		Fan	Fan output (speed) stage setting; each button cyclically increases the setting by one stage. The current output stage is displayed on the display
T8		Mode	Temperature mode selection (Auto, Comfort and Economy). By pressing the button, the modes can be cycled. The currently selected temperature mode is indicated by an icon on the display

Control (HMI-SG)

Table 4 – Display description

Icon	Display	Description
I1		Indication of room temperature or correction of the required temperature in °C or °F
		Room temperature in °C (increment 0.1 °C)
		Room temperature in °F (increment 0.5 °F)
		Required temperature correction in °C or °F
I2		Time
I3		Fan output (speed) stage
I4		Days of the week
I5		On/Off
I6		Mode Auto
I7		Temperature mode <i>Economy</i>
I8		Temperature mode <i>Comfort</i>
I9		Cooling sequence
I10		Heating sequence
I11		Humidification
I12		Fan Speed Compensation
I13		Mode <i>Presence</i> (this mode is not used as standard)
I14		Recovery and mixing sequences – energy savings
I15		Alarm
I16		Data point editing

User Roles and General Specification

The device parameters (data points) are structured and made available to users in accordance with their user roles (access levels). These roles must be assigned to the users by the system administrator according to their expertise and responsibility for device operation.

- **Guest** – allows only common parameters to be viewed.
- **User** – allows common parameters to be viewed and controlled, as well as start and stop of the device.
- **Administrator** – allows the system administrator to view and control common and some special parameters, pre-set operating parameters and modes for the user.
- **Service** – an access level recommended only for the supplier or authorized service provider. In addition to the administrator's level, it allows the user to adjust highly specialised configuration parameters related to the air-handling system and its instrumentation, control constants, water heater protection parameters, etc.

HMI to VCS System Access Default (factory) Settings

A control using the HMI controller uses an access right structure in accordance with the concept of structured access of the air-handling device, refer to the chapter *Overview and List of Date Points, Factory Settings*.

The HMI controller allows only four passwords (always four-digit and numerical) to be set, each for a different access level. Factory set default rights to access the VCS control unit using the HMI controller:

Table 5 – access levels

Designation	Level	Password (factory setting)
S	SERVICE	4444
A	ADMINISTRATOR	3333
U	USER	2222
G	HOST	0000


Warning:

- When commissioning the device, we strongly recommend changing the factory settings according to user needs to maintain the safety of the device itself as well as the controlled process.
- It is advisable to note and store the Service and Administrator passwords in a suitable (confidential) place (or update them upon each change to settings) to have easy access to them and thus maintain access to the system at the Service and Administrator levels.
- If the Service password changed from the factory setting is lost (forgotten), it is necessary to contact the manufacturer's representative. The lost Administrator level password can be retrieved by the user of the Service level (usually the supplier, installer or M&C service company).
- The changed password settings cannot be automatically restored (reset, etc.) to the factory settings.
- The user of the SERVICE level can change the passwords of all other user levels, the user of the ADMINISTRATOR level can change the passwords of the GUEST and USER levels while users of the USER or GUEST levels are not allowed to change any passwords.

Control (HMI-SG)


Data Point List Access and Editing

An overview of the structure of parameters accessible via the HMI-SG controller is available in the List of Data Points upon logging in using the appropriate access right level. The data points for writing and reading are assigned different access right levels. The procedure for access for editing and reading of data points is as follows:




1) The edit mode is signalled by an icon (I16). This mode can be accessed by pressing the Plus (T5), Minus (T4) and Mode (T8) buttons simultaneously. The cursor flashes in the first position from the left, ready for the 1st password digit to be entered. Change the value of the digit by pressing the Plus (T5) or Minus (T4) button and confirm by pressing the Mode (T8) button and the cursor will move to the next position. The password is activated after entering and confirming the last digit of the password by pressing the T8 button.

pressing the **Mode (T8)** button and the cursor will move to the next position. The password is activated after entering and confirming the last digit of the password by pressing the T8 button.



2) Upon entering the correct password, the **data points** for the respective access level (password) are displayed.

Note: If the entered password is wrong, "----" will be displayed.



3) Using the Plus (T5) or Minus (T4) buttons, select the first number of the data point group and confirm the selection by pressing the mode (T8) button. Then select a desired data point within the group in the same way as the first number of the data point group. The number on the first line represents a data point code while the number on the second line represents its value.

4) If the parameter value is highlighted, the data point is only for reading. If the parameter value flashes, the data point can be edited in accordance with the access level you logged in at.

5) The value can be edited by the Plus (T5) or Minus (T4) buttons. To confirm changes to the value, press the Mode (T8) button. Upon confirming the changes, the data point cursor will start to flash, and you can move to the next parameter in the group. Another group of parameters, i.e. return to a higher level, can be made by pressing the **Power (T1)** button.

Note: If no change is made within 1 minute, the data point editing mode will be exited.

Communication Settings

Once the HMI-SG controller has been connected to the control unit, the communication between both devices will be set automatically. If two HMI-SG controllers have been connected to the control unit, it is necessary to set a new address for one of the controllers. An interface for the communication settings will be displayed on the controller, and then parameter #7 must be changed.

1) The interface for the communication settings is displayed by pressing and holding the **Power (T1)**, **Mode (T8)**, **Minus (T4)** and **Plus (T5)** buttons simultaneously. The cursor flashes in the first position from the left, ready for the 1st password digit to be entered. Change the value of the digit by pressing the Plus or Minus (T4) button and confirm by pressing the Mode (T8) button and the cursor will move to the next position. Changes to the parameter settings can only be made by the ADMINISTRATOR, SERVICE or USER role users.

2) After a correct password has been entered, press the **Mode (T8)** button to enter the interface for changes to parameter settings.

3) Use the Plus (T5) or Minus (T4) buttons to browse the communication parameters. Press the Mode (T8) button to confirm selection of the desired parameter (parameters for communication settings are listed in the following table).

Table 6 – Communication settings

Parameter number/Description	
001	KNX connection state <ul style="list-style-type: none"> • OK – bus communication is OK • NF – no bus communication
002	Physical address (X.1.1) X...value range 0 to 15; generated automatically
003	Physical address (1.X.1) X...value range 0 to 15; generated automatically
004	Physical address (1.1.X) X...value range 0 to 252; generated automatically
005	Byte (program) address (X.1.1) X...value range 0–126 (pre-set value is 5) This value needs to be changed if several master controllers are connected to the KNX bus by several controllers
006	Room (program) address (1.X.1) X...value range 1 to 14 (pre-set value is 1)
007	Zone (program) address (1.1.X) X...value range 1 to 15 (pre-set value is 1) This value must be changed from 1 to 2 if 2 controllers are connected to the same master controller.
008	Network failure detection enabled Network failure detection enabled or disabled; network failure is indicated by the word "NET".
009	Physical address automatic assignment (pre-set value is 1) 0...Room unit uses firmly defined physical address 1...automatic generation of the controller's address

Control (HMI-SG)

4) The cursor with the communication parameter value will start to flash. The parameter value can be changed by pressing the Plus or Minus (T4) buttons. Press the **Power** (T1) button to confirm the change to the communication parameter value.

5) To return to a higher level, press the **Power** (T1) button. If no change is made within 1 minute, the interface will be exited. *Note: If the air-handling unit is controlled by two HMI-SG controllers, the last change made from one of the controllers will be valid.*

System Date and Time Settings

Here, the actual VCS system date and time can be set – these settings are required for correct functioning of the time schedule programs. The procedure for system date and time setting is as follows:

After long hold the **Program** (T3) button to set the date and time. Press the Plus (T5) and Minus (T4) buttons to change the date and time values. Press the **OK** (T6) button to confirm the changes and the cursor will move to the next item. The cursor cycles through the following items:

Hour → Minute → Month → Day → Year

Default Application Parameterization

To ensure comfortable and economy operation requiring minimum attendance, it is necessary to perform the main settings defining the parameters and air output, respectively the temperature control, and stability in the ventilated/air-conditioned room. Data points must be set for all the relevant parameters:

- Temperature modes
- Time schedules
- Control parameters
- Correction values
- Antifreeze Protection
- Control constants
- Optional modes and functions

The parameters are described in the chapter *List of Data Points, Factory Settings*.

Operating the HMI-SG controller

If only one HMI-SG controller is connected to the control unit, it then serves as an operating controller for full setting and control of the control unit. During the first start-up of the air-handling unit, the manual operating mode (the highest priority) is set to the Stop state, and the HMI-SG controller does not interfere with control of the control unit. In the Manual operating mode, it is necessary to change the state from Stop to Auto using data point #125 and thus move the priority from the control unit to the HMI-SG controller's operating mode.

First Control Unit Start-Up Using HMI-SG Controller


1) Press the Plus (T5), Minus (T4) and Mode (T8) buttons simultaneously to display the log-in screen for the 4-digit password. Change the value of the digit by pressing the Plus (T5) or Minus (T4) button. Press the Mode (T8) button to confirm the entered digit and the cursor will move to the next position. Once the correct password has been entered, the data point screen will be displayed. Press the Power (T1) button to leave the log-in interface.

2) The first digit "0-" will be displayed. To change the first digit value, press the Plus (T5) or Minus (T4) button. To confirm the entered value, press the Mode (T8) button.

Use the Plus (T5) and Minus (T4) buttons to set the last two digits to get the string "125". To confirm the entered value, press the Mode (T8) button. To return to the previous step, press the Power (T1) button.

3) The flashing number on the second line represents a data

Figure 20 – HMI-SG controller LCD display



point value. Use the Minus (T4) buttons to change the data point value from "1" to "0" and confirm by pressing the Mode (T8) button. To return to the previous step, press the Power (T1) button.

The situation before initiating the control unit from the HMI-SG controller is illustrated in figure 16. The Stop operating mode is indicated by the Auto icon (16). Current temperature (11) and system time (12) are displayed. The fans are not running (13). The day of the week is indicated by digits (1–7) in the lower part of the display.

Note: 12h/24h system time format can be changed using data point 898. The source of the displayed temperature can be selected using data point 887.

Control (HMI-SG)


Operating Screen (Examples)

After making the HMI-SG controller a service controller, it is possible to change the control unit settings. Use the Mode (T8) button to manually switch between the Run state with temperature modes (Comfort or Economy) and the Auto state. Use the Power (T1) button to put the air-handling unit into the Stop operating state, the display in the HMI-SG operating mode will only display the **ON/OFF** icon (I5).

Operating State Auto


The fan speed and temperature mode are set depending on the time schedule compilation. It is possible to set a correction to the required temperature, see the chapter Required Temperature Correction. It is also possible to adjust the time schedule, see the chapter Daily (Weekly) Time Schedule.

The figure shows the Auto operating state display. The state is signalled by an icon (I6). The air-handling unit is controlled in accordance with the time schedule. The moderate heating temperature mode (I7) with a cooling sequence (I9) is active. The fans are set to the second speed stage (I3). Apart from the cooling sequence, the heating (I10), heat recovery and mixing (I14) icons can be displayed.



(I14) icons can be displayed.

The figure shows the situation where a time schedule controlled air-handling unit is in the Stop operating state. The fans are not running (I3). No temperature modes or heating or cooling sequences are active.




section Monitor – Current Modes – Current Modes – Current operating Mode.

Warning: Current additional operating mode stats are not displayed but can be monitored in the List of Data Points in the

Manual Operating Mode (Run)

In Manual operating mode, it is possible to select the required temperature mode, set any fan speed output stage and the required temperature correction.

This display shows the manually selected Comfort temperature mode (I8) with a heating sequence (I10) and the fourth fan speed stage. In Manual mode, the fan speed can be set using the Fan button (T7). To manually switch between the temperature modes, use the Mode (T8) button.




Failure Detection

If a failure of external components

connected to the device failure detection inputs (incorrect state of the contact) occurs, the VCS control unit will automatically put out an alarm in accordance with an internal algorithm – indicating the faulty object and in case of severe failures stopping the air-handling unit. Each failure is more closely specified by a failure class. The failure class determines the severity of the failure. A class failures will shut down the air-handling unit. B class failures will deactivate some system functions (e.g. compensation if the temperature sensor fails) but they will not shut down the air-handling unit. Numerical failure codes specifying the failure events are listed in the chapter Failures. If more failure events occur, the number of the failure with the highest priority (the most serious failure) will be displayed.

Failure Screen (example)

If a failure occurs, the air-handling unit is put in the STOP state (previously the Run mode is retained, B class failure). This is indicated by flashing Auto (I6) and Alarm (I15) icons on the display. The failure class (I18) and number (I19) are displayed below the temperature indication. Indication of the alarm will cease shortly after all failure events have been removed. The number shown on the display can also be accessed via data point **824**.



Failure Reset

Failure reset can only be performed once the cause of the failure has been identified and removed. The failures are reset using data point **825**.

Required Temperature Settings in Temperature Modes

Required temperature settings for the Comfort and Economy temperature modes are performed in the List of Data Points – Temperature Modes:

- 101 – Comfort cooling
- 103 – Comfort heating
- 105 – Economy cooling
- 107 – Economy heating

Required Temperature Correction

The pre-set required temperatures in each temperature mode can be changed within ± 3 °C directly from the HMI-SG controller. Use the Plus (T5) button to increase the required temperature or use the Minus (T4) button to decrease the required temperature. The one button pressing increment or decrement value can be set in data point 897. This temperature adjustment is only valid for a current mode. Upon transition between modes, this correction will be reset.

Control (HMI-SG)

Time Schedule Compilation Procedure

1) Press the Program (T3) button to enter the time schedule configuration menu for each day of the week.

BHMI SG displays the first day of the week, i.e. Monday. Up to 6 time windows (1-1 to 1-6) can be set for each day.

3) The Mode (T8) button enables you to select a day by cycling through the week days (1-2-3-4-5-6-7-A). The "A" option is used to set the time schedule for business days (1 – 5) simultaneously. If you make any change to the "A" time schedule, the settings of the "A" day will be copied to all business days.

4) The Power (T1) button is used to assign the selected time window with an operating mode (Stop-Economy-Comfort).

5) The Fan (T7) button is used to set the fan operation speed stage (st. 1 – st. 5).

6) The Minus (T4) and Plus (T5) buttons are used to set the beginning of the time window; to confirm the time setting, press the OK (T6) button.

7) Once the beginning of the time window has been set, move to the next settings in the time window.

8) If you set the beginning of the time window to "--:--", the window will be disabled.


9) Press and hold the OK (T6) button to go back one step in the time schedule settings within the set time.

10) Press and hold the Fan (T7) button to go back one step in the time schedule settings within the fan speed stage settings.

11) Press and hold the Mode (T8) button to move one step back (a weekday selection).

12) Press the Program (T3) or Presence (T2) button to exit the Time Schedule Settings menu.

13) If no settings are performed in the time schedule within 1 minute, the menu will be automatically left..



Quick Menu:

This enables quick access to the temperature and selected value monitoring without editing.



Use the Minus (T4) and Plus (T5) to switch between the temperature values.

Use the Program (T3) or Presence (T2) buttons to exit the Quick Menu. Only those values which are included within the given version of the VCS unit are displayed.

Briefly press the OK (T6) button to display the values listed below:



- Inlet temperature (Sply)
- Outlet temperature (Out)

- Return water temperature (Htr)
- Outlet temperature (Rtrn)
- Room temperature (Room)





Press and hold the OK (T6) button to display the values listed below:

- Comfort temperature mode (heating)
- Economy temperature mode (heating)
- Comfort temperature mode (cooling)
- Economy temperature mode (cooling)



Lock/Unlock the SG II buttons

Press and hold the Presence (T2) button to lock/unlock the SG II controller in order to prevent unauthorised access to the device control.



Control (HMI-SG)

Additional Operating Modes and Function Settings

Additional operating modes and functions can be activated in the List of Data Points in the section Settings – Additional Operating Modes, Functions. Once the respective mode or function has been set, it is necessary to perform SW reset using a specific data point **211** (Reset after the configuration of additional modes/functions).

Optional Additional Operating Modes

- Night Chilling
- Temperature start-Up
- Time mode start optimization

Optional additional functions

- Outdoor Temperature-Dependent Fan Speed Compensation
 - Heating/cooling dependent fan speed compensation
 - Room (Outlet) Temperature-Dependent Fan Speed Compensation
 - Humidity-dependent Fan Speed Compensation
 - Air Quality-Dependent Damper Position Compensation
 - Heating/cooling-dependent fan speed compensation – cooling sequence
 - Cooling using heat recovery with rotary regenerator option or using mixing damper
 - Heating and mixing sequence order
 - Outlet fan correction – using five-stage control (TRN controllers)
 - Difference between required and actual temperature monitoring
 - Damper and outlet fan blocking
 - Room temperature measuring point selection

User Settings Backup and Recovery

It is advisable to perform backups especially before significant changes in control parameter settings (PID controller factors, temperature setting for compensations or starting of the optional additional modes), or always when the control works optimally. Data backup or recovery can be performed using the HMI controller in the List of Data Points, section Checks – User Settings.

List of Data Points, Factory Settings**Warning:**

The device parameters are structured and made available to users in accordance with their user roles (access levels). These roles must be assigned to users by the system administrator according to their expertise and responsibility for device operation. Access to the data points is also limited by the user role level – for levels lower than Service, not all parameters (data points) are displayed, respectively, they can be read without being able to change (save) them. The Parameter List with a combination of all possible air-handling unit applications is included in the List of data points under the highest access right.

List of Data Points (HMI-SG controller)

Menu HMI-SG								
Parameter				Meaning	Factory Settings			
Notation		Reading			Value	Min	Max	
code	level	code	level					
Monitor								
Temperature								
		001	G	Temperature in the inlet				°C
		002	G	Temperature in the room 1				°C
		003	G	Temperature in the room 2				°C
		004	G	Room unit 1				°C
		005	G	Room unit 2				°C
		006	G	Temperature in the outlet				°C
		007	G	Outdoor temperature				°C
		008	G	Return water temperature				°C
		009	G	Heat exchanger freezing temperature				°C
		010	G	Electric preheater temperature				°C
		011	G	Water preheater temperature				°C
		012	G	Electric reheater temperature				°C
		013	G	Flue gas temperature				°C
		014	G	Final room temperature (controlled)				°C
Humidity								
		015	G	Inlet air relative humidity				%r.H.
		016	G	Room air relative humidity				%r.H.
		017	G	Outdoor air relative humidity				%r.H.
		018	G	Pressure in the inlet				Pa
		019	G	Pressure in the outlet				Pa
		020	G	Air flow rate in the inlet				m ³ /h
		021	G	Air flow rate in the outlet				m ³ /h
CO₂ (VOC, CO)								
		022	G	CO ₂ (VOC, CO) concentration				ppm
Performances								
		023	G	Inlet fan output				% (m ³ /h, Pa)
		024	G	Outlet fan output				% (m ³ /h, Pa)
		025	G	3rd fan output				%
		026	G	Outlet level for the electric reheater				%
		027	G	Heating mixing set valve position				%
		028	G	Outlet level for cooling				%
		029	G	Cooling output (stage)				%
		030	G	Electric preheater position				%
		031	G	Outlet level for the electric heater				%
		032	G	Heat pump output				%
		033	G	Outlet position to the mixing damper				%
		034	G	Heat exchanger control outlet position				%
		035	G	Modulation burner outlet position				%
		036	G	By-pass damper outlet position				%
Operating states								
		037	G	Fan state	0	-		
					1	Stage 1		
					2	Stage 2		
					3	Stage 3		
					4	Stage 4		
					5	Stage 5		
		038	G	Electric pre-heater state	1	off		
					2	on		
		039	G	Water pre-heater state	0	off		
					1	on		
		040	G	Electric re-heater state	1	off		
					2	on		
		041	G	Water heater pump state	0	off		
					1	on		
		042	G	Pre-heating function of water heating	0	off		

List of Data Points (HMI-SG controller)

Menu HMI-SG								
Parameter				Meaning	Factory Settings			
Notation		Reading			Value	Min	Max	
code	level	code	level					
		043	G	Water cooler pump state	1 on 0 off			
		044	G	Evaporator cooling stage	1 on 1 off 2 Stage 1 3 Stage 2			
		045	G	Inverter cooling stage (inverter)	0 off 1 on			
		046	G	Inverter cooling stage (step1+inverter)	0 off 1 on			
		047	G	Heat pump operating state	0 out of operation 1 cooling 2 heating			
		048	G	Electric heater operating state	1 off 2 on			
		049	G	Gas Burner operating states (stages)	1 off 2 Stage 1 3 Stage 2			
		050	G	Current modes Fan output stages (external equipment)	0 Auto 1 off 2 Stage 1 3 Stage 2 4 Stage 3 5 Stage 4 6 Stage 5			
		051	G	AHU current operating mode	0 Stop 1 Comfort 2 Economy 3 - 4 Optimized start 5 Night chilling 6 Temperature start-up 7 Night turning 8 9 Fire mode 10 Safety stop 11 Fan run-out 12 Start			
		052	G	Current temperature control values Calculated required temperature for heating with cascade control				°C
		053	G	Calculated required temperature for cooling with cascade control				°C
		054	G	Calculated required temperature for heating				°C
		055	G	Calculated required temperature for cooling				°C
		056	G	Current temperature-dependent control (inlet, room, outlet)	0 room 1 outlet 2 inlet			
				Current humidity values				
		058	G	Calculated absolute inlet air humidity				g/kg
		059	G	Calculated inlet air humidity enthalpy				kJ/kg
		060	G	Calculated absolute room air humidity				g/kg
		061	G	Calculated room air humidity enthalpy				kJ/kg
		062	G	Calculated absolute outdoor air humidity				g/kg
		063	G	Calculated outdoor air humidity enthalpy				kJ/kg
		064	G	Request for dehumidification				%
		065	G	Request for humidification				%

List of Data Points (HMI-SG controller)

Menu HMI-SG									
Parameter				Meaning	Factory Settings				
Notation	Reading				Value	Min	Max		
code	level	code	level						
		066	G	Humidifier state	0 off				
					1 on				
				Settings					
				Temperature modes					
101	A	102	G	Comfort - cooling		24.6	0	99	°C
103	A	104	G	Comfort - heating		22.6	0	99	°C
105	A	106	G	Economy - cooling		28	0	99	°C
107	A	108	G	Economy - heating		20.6	0	99	°C
109	A	110	G	Required temperature for cooling, Temperature start-up		15	-64	64	°C
111	A	112	G	Required temperature for heating, Temperature start-up		25	-64	64	°C
113	A	114	G	Required room temperature , Night chilling (control for inlet)		22	-64	64	°C
115	A	116	G	Required room temperature , Boost (control for inlet)		20	-64	64	°C
117	A	118	G	Required temperature for cooling, Boost		15	-64	64	°C
119	A	120	G	Required temperature for heating, Boost		25	-64	64	°C
				Cascade control limitation - limiter					
121	S	122	A	Max. difference between room temperature and inlet temperature		10	0	64	°C
123	S	124	A	Min. difference between room temperature and inlet temperature		10	0	64	°C
				Operation mode					
125	A	126	G	AHU manual control (Temperature mode, fan output stage)	0 Auto	Stop			
					1 Stop				
					2 Economy; St1				
					3 Comfort; St1				
					4 Economy; St2				
					5 Comfort; St2				
					6 Economy; St3				
					7 Comfort; St3				
					8 Economy; St4				
					9 Comfort; St4				
					10 Economy; St5				
					11 Comfort; St5				
127	A	128	G	AHU start-up time-out after power supply failure		10	0	9999	s
				External control					
129	U	130	G	External contact function definition (Ext. control 1 contact)	0 Start function	0			
					1 Start and Stop function				
131	U	132	G	Transition time from ext. control mode to AUTO mode (Ext. control 1 contact)		0	0	23	h
133	U	134	G	Fan output stage setting (Ext. control 1 contact or 2 contacts)	0 Auto	2			
					1 off				
					2 Stage 1				
					3 Stage 2				
					4 Stage 3				
					5 Stage 4				
					6 Stage 5				
135	U	136	G	Temperature mode setting (Ext. control 1 contact or 2 contacts)	0 Comfort	0			
					1 Economy				
137	U	138	G	Fan output stage setting "Higher" (Ext. control 2 contacts)	0 Auto	5			
					1 off				
					2 Stage 1				
					3 Stage 2				
					4 Stage 3				
					5 Stage 4				
					6 Stage 5				
139	U	140	G	Temperature mode setting "Higher" (Ext. control 2 contacts)	0 Comfort	0			
					1 Economy				
				Fans - Modbus					
141	A			Inlet fan output St1 setting		Control limits			
						0.1			% (m ³ /h, Pa)

List of Data Points (HMI-SG controller)

Menu HMI-SG									
Parameter				Meaning	Factory Settings				
Notation		Reading			Value	Min	Max		
code	level	code	level						
142	A			Inlet fan output St1 setting (a factor of 10)					% (m ³ /h, Pa)
143	A			Inlet fan output St2 setting		25			% (m ³ /h, Pa)
144	A			Inlet fan output St2 setting (a factor of 10)					% (m ³ /h, Pa)
145	A			Inlet fan output St3 setting		50			% (m ³ /h, Pa)
146	A			Inlet fan output St3 setting (a factor of 10)					% (m ³ /h, Pa)
147	A			Inlet fan output St4 setting		75			% (m ³ /h, Pa)
148	A			Inlet fan output St4 setting (a factor of 10)					% (m ³ /h, Pa)
149	A			Inlet fan output St5 setting		100			% (m ³ /h, Pa)
150	A			Inlet fan output St5 setting (a factor of 10)					% (m ³ /h, Pa)
151	A			Outlet fan output St1 setting		0.1			% (m ³ /h, Pa)
152	A			Outlet fan output St1 setting (a factor of 10)					% (m ³ /h, Pa)
153	A			Outlet fan output St2 setting		25			% (m ³ /h, Pa)
154	A			Outlet fan output St2 setting (a factor of 10)					% (m ³ /h, Pa)
155	A			Outlet fan output St3 setting		50			% (m ³ /h, Pa)
156	A			Outlet fan output St3 setting (a factor of 10)					% (m ³ /h, Pa)
157	A			Outlet fan output St4 setting		75			% (m ³ /h, Pa)
158	A			Outlet fan output St4 setting (a factor of 10)					% (m ³ /h, Pa)
159	A			Outlet fan output St5 setting		100			% (m ³ /h, Pa)
160	A			Outlet fan output St5 setting (a factor of 10)					% (m ³ /h, Pa)
161	A	162	U	3rd fan output St1 setting		0.1	0.1	100	%
163	A	164	U	3rd fan output St2 setting		25	0.1	100	%
165	A	166	U	3rd fan output St3 setting		50	0.1	100	%
167	A	168	U	3rd fan output St4 setting		75	0.1	100	%
169	A	170	U	3rd fan output St5 setting		100	0.1	100	%
171	A	172	U	Fan run-out after unit stop shut-down		180	0	9999	s
570	A			Enabling the fan run-out according to DEV	0	No	1		
					1	Yes			
571	A			Unit run-out – blocking by the minimum outside temperature		-15	-64	64	°C
572	A			Unit run-out – blocking by the maximum outside temperature		5	-64	64	°C
573	A			Unit run-out – time		5	1	60	Min
Inlet backup – single-speed motors									
173	A	174	U	Failure flow evaluation time-out after main fan start-up		180	0	9999	s
175	A	176	U	Failure flow evaluation time-out after backup fan start-up		180	0	9999	s
		181	U	Information – backup activation	0	non-activated			
					1	activated			
				Outlet backup - single-speed motors					
177	A	178	U	Failure flow evaluation time-out after main fan start-up		180	0	9999	s
179	A	180	U	Failure flow evaluation time-out after backup fan start-up		180	0	9999	s
		182	U	Information - backup activation	0	non-activated			
					1	activated			
TRN correction									
183	A	183	A	Common for all operating stages St	0	-4 stages	0		
					1	-3 stages			
					2	-2 stages			
					3	-1 stage			
					4	0			
					5	+1 stage			
					6	+2 stages			
					7	+3 stages			
					8	+4 stages			
184	A	184	A	For operating stage St1	0	-4 stage	0		
					1	-3 stage			
					2	-2 stage			
					3	-1 stage			
					4	0			

List of Data Points (HMI-SG controller)

Menu HMI-SG									
Parameter				Meaning	Factory Settings				
Notation		Reading			Value	Min	Max		
code	level	code	level						
				5	+ 1 stage				
				6	+ 2 stages				
				7	+ 3 stages				
				8	+ 4 stages				
185	A	185	A	0	- 4 stage	0			
				1	- 3 stage				
				2	- 2 stage				
				3	- 1 stage				
				4	0				
				5	+ 1 stage				
				6	+ 2 stages				
				7	+ 3 stages				
				8	+ 4 stages				
186	A	186	A	0	- 4 stage	0			
				1	- 3 stage				
				2	- 2 stage				
				3	- 1 stage				
				4	0				
				5	+ 1 stage				
				6	+ 2 stages				
				7	+ 3 stages				
				8	+ 4 stages				
187	A	187	A	0	- 4 stage	0			
				1	- 3 stage				
				2	- 2 stage				
				3	- 1 stage				
				4	0				
				5	+ 1 stage				
				6	+ 2 stages				
				7	+ 3 stages				
				8	+ 4 stages				
188	A	188	A	0	- 4 stage	0			
				1	- 3 stage				
				2	- 2 stage				
				3	- 1 stage				
				4	0				
				5	+ 1 stage				
				6	+ 2 stages				
				7	+ 3 stages				
				8	+ 4 stages				
					TRN – fan start-up (without outlet for dampers)				
189	S	189	S		Forced fan start-up time setting to Stage 1	20	0	99	s
					Two-speed motors				
190	A	191	U		Transition time interval from speed 1 to speed 2	15	0	999	s
192	A	193	U		Transition time-out from speed 2 to speed 1	12	0	99	s
					Inlet temperature limitation				
194	S	194	S		Minimum inlet air temperature	15	0	64	°C
195	S	195	S		Maximum inlet air temperature	35	0	64	°C
					Additional operating modes, functions				
196	S	196	S		Outdoor temperature dependent fan speed compensation				
				0	No	0			
				1	Yes				
197	S	197	S		Heating/cooling dependent fan speed compensation				
				0	No	0			
				1	Heating				
				2	Cooling				

List of Data Points (HMI-SG controller)

Parameter				Menu HMI-SG		Factory Settings			
Notation		Reading		Meaning		Value	Min	Max	
code	level	code	level						
					3 Heating + Cooling				
198	S	198	S	Air quality dependent fan speed compensation	0 No	1			
					1 Yes				
199	S	199	S	Room (outlet) temperature dependent fan speed compensation	0 No	0			
					1 Yes				
230	S	230	S	Humidity-dependent fan speed compensation	0 No	0			
					1 Yes				
231	S	231	S	Limitation of dehumidification during heating	0 No	0			
					1 Yes				
201	S	201	S	Difference between required and actual temperature monitoring	0 No	0			
					1 inlet				
					2 room				
					3 Inlet+room				
202	S	202	S	Air quality dependent damper position compensation	0 No	0			
					1 Yes				
246	S	246	S	Humidity-dependent mixing damper position compensation	0 No	0			
					1 Yes				
247	S	247	S	Max. limit of fresh air according to T outdoor (ventilation unit)	0 No	0			
					1 Yes				
203	S	203	S	Cooling using HR (RHE, BP PE, mixing damper)	0 without HR cooling	3			
					1 RHE, BP PE				
					2 mixing damper				
					3 RHE+ damper				
204	S	204	S	Heating/cooling dependent fan speed compensation-cooling sequence (fan, cooler)	0 fan+cooler	1			
					1 cooler+fan				
205	S	205	S	Mixing heating sequence (damper, heater)	0 damper+heater	0			
					1 heater+damper				
206	S	206	S	Night cooling	0 without chilling				
					1 with chilling				
207	S	207	S	Temperature start-up	0 N/A	0			
					1 heating				
					2 cooling				
					3 heating + cooling				
208	S	208	S	Time mode start optimization	0 N/A	0			
					1 heating				
					2 cooling				
					3 heating + cooling				
209	S	209	S	Damper and outlet fan blocking	0 N/A	0			
					1 dampers				
					2 dampers+fan				
210	S	210	S	Outlet fan correction type (TRN controllers)	0 separate stages	0			
					1 shared stages				
211	S	211	S	Reset after configuration of additional modes/functions	0 without reset				
					1 reset				
212	S	212	S	Room temperature measuring point selection	0 average	3			
					1 minimum				
					2 maximum				
					3 room temp. sensor 1				
					4 room temp. sensor 2				
					5 HMI-SG 1 controller				
					6 HMI-SG 2 controller				
				Control signal characteristic					
213	A	213	A	Control signal 0-10 V or 2-10 V, heating	0 0-10V				
					1 2-10V	1			
214	A	214	A	Control signal 0-10 V or 2-10 V, cooling	0 0-10V				
					1 2-10V	1			
215	A	215	A	Control signal 0-10 V or 2-10 V, mixing damper	0 0-10V				
					1 2-10V	1			

List of Data Points (HMI-SG controller)

Menu HMI-SG									
Parameter				Meaning	Factory Settings				
Notation		Reading			Value	Min	Max		
code	level	code	level						
216	A	216	A	Control signal 0-10 V or 2-10 V, heat exchanger by-pass damper	0	0-10V			
					1	2-10V	1		
217	A	217	A	Control signal 0-10 V or 2-10 V, chamber by-pass damper	0	0-10V			
					1	2-10V	1		
218	A	219	G	Required inlet temperature extra set-point Required inlet temperature extra set-point (applied when el. re-heating or heat pump is removed from the main sequence)			20	0	99 °C
220	S	220	S	Fan start-up delay (after damper)			20	0	9999 s
221	S	221	S	Outdoor-dependent fan speed interlocking Control – Flow (Pressure)			-60	-64	64 °C
222	A	223	U	Setting range of flow sensor - inlet (a factor of 100)			8000	0	2*105 m3/h
224	A	225	U	Setting range of flow sensor - outlet (a factor of 100)			8000	0	2*105 m3/h
226	A	227	U	Setting range of pressure sensor - inlet (a factor of 100)			6000	0	7000 Pa
228	A	229	U	Setting range of pressure sensor - outlet (a factor of 100)			6000	0	7000 Pa
232	A	233	U	K factor – inlet			95	0	9999
234	A	235	U	K factor – outlet			95	0	9999
236	A	237	U	NumberInletFan			1	1	100
238	A	239	U	NumberOutletFan			1	1	100
		240	S	K Factor - Enabled	0	No			
					1	Yes	1		
		241	S	Inputs configuration Reverse function of fault input for Cooling or Heat Pump	0	Normal	0		
					1	Reversed			
		270	U	Device configuration Regulation supply fan	0	none			
					1	1 stage			
					2	5 stage (TRN)			
					3	V10			
					4	V100			
					5	V10 + back-up			
					6	V100 + back-up			
					7	2xV10			
					8	2xV100			
					9	2xV10 + back-up			
					10	2xV100 + back-up			
		271	U	Regulation exhaust fan	0	none			
					1	1 stage			
					2	5 stage (TRN)			
					3	V10			
					4	V100			
					5	V10 + back-up			
					6	V100 + back-up			
					7	2xV10			
					8	2xV100			
					9	2xV10 + back-up			
					10	2xV100 + back-up			
		272	U	Regulation additional fan	0	none			
					1	1 stage			
					2	5 stage (TRN)			
					3	V10			
					4	V100			
					7	2xV10			
					8	2xV100			
		273	U	Heating	0	no			
					1	water			
					2	electric			
					3	gas			

List of Data Points (HMI-SG controller)

Menu HMI-SG									
Parameter				Meaning	Factory Settings				
Notation		Reading			Value	Min	Max		
code	level	code	level						
		274	U	Heat pump	0 no				
					1 variation A				
					2 variation B				
		275	U	Type of gas heating	0 1 stage				
					1 2 stage				
					2 modulation				
		276	U	Byppas damper gas heater	0 no				
					1 yes				
		277	U	Cooling	0 no				
					1 water				
					2 1 step				
					3 2 step				
					4 inverter				
					5 inverter + 1 step				
		278	U	Heat recovery	0 no				
					1 plate				
					2 wheel				
					3 glycol				
		279	U	Mixing	0 no				
					1 yes				
		280	U	Preheating	0 no				
					1 water				
					2 electric				
		281	U	Extra heating	0 no				
					1 electric				
		282	U	Temperature control mode	0 supply				
					1 cascade - room				
					2 cascade - return				
		283	U	Humidity control mode	0 no				
					1 room				
					2 supply				
					3 cascade - room				
				Control parameters					
				Temperature start-up					
301	A	302	U	Cooling trigger temperature		30	-64	64	°C
303	A	304	U	Heating trigger temperature		25	-64	64	°C
305	A	306	U	Hysteresis		1	0.1	64	°C
307	A	308	U	Heating and cooling blocking time		30	0	999	min
309	A	310	U	Operating time		0	0	999	min
				Night colling					
311	A	312	U	Temperature hysteresis		3	0	64	°C
313	A	314	U	Minimum outdoor temperature setting		12	-64	64	°C
315	A	316	U	Outdoor temperature and room temperature difference		5	1	64	°C
317	A	318	U	Minimum night chilling operating time		30	0	999	min
				Boost function					
319	A	320	U	Pre-set interval before time program start-up		60	0	999	min
321	A	322	U	Temperature hysteresis		0.5	-64	64	°C
				Required temperature compensation					
323	A	324	U	Cooling initial point (outdoor temperature)		25	-64	64	°C
325	A	326	U	Cooling end point (outdoor temperature)		30	-64	64	°C
327	A	328	U	Maximum cooling compensation (required value)		2	-64	64	dK
329	A	330	U	Heating initial point (outdoor temperature)		5	-64	64	°C
331	A	332	U	Heating end point (outdoor temperature)		-20	-64	64	°C
333	A	334	U	Maximum heating compensation (required value)		-1	-64	64	dK
		335	U	Required cooling value current shift			-64	64	°C
		336	U	Required heating value current shift			-64	64	°C
				Outdoor temperature dependent fan speed compensation					
337	A	338	U	Cooling initial point (outdoor temperature)		25	-64	64	°C

List of Data Points (HMI-SG controller)

Menu HMI-SG									
Parameter				Meaning	Factory Settings				
Notation		Reading			Value	Min	Max		
code	level	code	level						
339	A	340	U	Cooling end point (outdoor temperature)		30	-64	64	°C
341	A	342	U	Maximum cooling compensation (speed)		0	-100	100	%
343	A	344	U	Heating initial point (outdoor temperature)		5	-64	64	°C
345	A	346	U	Heating end point (outdoor temperature)		-20	-64	64	°C
347	A	348	U	Maximum heating compensation (speed)		0	-100	100	%
		349	U	Current cooling speed compensation			-100	100	%
		350	U	Current heating speed compensation			-100	100	%
				Room (outlet) temperature dependent fan speed compensation					
351	A	351	A	Compensation function setting	0 increase 1 decrease	0			
		352	U	Actual compensation			0	100	%
353	A	353	A	Required room temperature		20	0	99	°C
				Heating/cooling dependent fan speed compensation					
354	A	354	A	Heating temperature hysteresis		1	0	20	°C
355	A	355	A	Cooling temperature hysteresis		1	0	20	°C
		356	U	Heating compensation display			0	100	%
		357	U	Cooling compensation display			0	100	%
				Air quality dependent compensation (damper position/fan speed)					
358	A	359	U	Compensation function setting (according to the sensor characteristics)	0 Normal 1 Inverted	0			
360	A	361	U	Required (allowable) value of the CO ₂ , VOC, (CO) concentration		800(50)	0	3000	ppm
362	A	363	U	CO ₂ , VOC, (CO) sensor range setting		2000(300)	0	3000	ppm
		364	U	CO ₂ , VOC (CO) compensation rate display			0	100	%
				Sequence					
				Heat pump - heating					
365	A	366	U	Outdoor temperature dependent heat pump blocking		-8	-45	35	°C
367	A	368	U	Temp. hysteresis applied for outdoor temperature dependent heat pump unblocking		3	1	10	°C
369	A	370	U	Minimum operating time for heat pump heating		60	0	9999	s
371	A	372	U	Re-heating blocking		120	5	600	s
373	A	374	U	Heat pump switching on		20	0	100	%
375	A	376	U	Digital output opening hysteresis		10	1	100	%
		377	U	Information - outdoor temperature dependent heat pump heating blocking	0 inactive 1 active				
				Heat pump - cooling					
378	A	379	U	Outdoor temperature dependent heat pump blocking		14	-45	35	°C
380	A	381	U	Temp. hysteresis applied for outdoor temperature dependent heat pump unblocking		3	1	10	°C
382	A	383	U	Minimum operating time for heat pump cooling		60	0	9999	s
384	A	385	U	Re-cooling blocking		120	5	600	s
386	A	387	U	Heat pump switching on		20	0	100	%
388	A	389	U	Digital output opening hysteresis		10	1	100	%
390	A	391	U	Heat pump low reference signal setting for A output		30	0	50	%
		392	U	Information - outdoor temperature dependent heat pump cooling blocking	0 inactive 1 active				
				Heat Pump - Special					
		260	S	Inversion signal for Heat Pump – heating	0 Off 1 On				
		261	S	Inversion signal for Heat Pump – cooling	0 Off 1 On				
		262	S	Special signal 0-10V (Daikin) switchover	0 Off 1 On				
		263	S	The difference between the demand and the real signal to determine St2		40	0	100	%
		264	S	Time needed to pass from 0 to 100%		120	0	500	s
		265	S	The signal voltage request of heating (Toshiba)		3.25	0	10	V
		266	S	The signal voltage request of cooling (Toshiba)		6.25	0	10	V
		267	S	The signal voltage request of STOP (Toshiba)		0	0	10	V

List of Data Points (HMI-SG controller)

Menu HMI-SG									
Parameter				Meaning	Factory Settings				
Notation		Reading			Value	Min	Max		
code	level	code	level						
		268	S	The signal voltage request of START (Toshiba)		8	0	10	V
Cooling									
393	A	394	U	Outdoor temperature to enable cooling – all versions		12	-64	64	°C
395	A	396	U	Minimum pump operating time – water version		180	0	9999	s
397	A	398	U	Pump downtime to the pump turning activation – water version		168	0	9999	h
399	A	401	U	Active pump turning time – water version		60	0	9999	s
397	A	398	U	Minimum operating time, single-stage condensing unit – version with single-stage condensing unit		60	0	9999	s
399	A	401	U	Re-cooling blocking time – versions with single-, two-stage condensing units		120	5	600	s
402	A	403	U	Retention time during transition from Stage 1 to Stage 2 – version with two-stage condensing unit		360	5	600	s
404	A	405	U	Cooling request dependent evaporator Stage 1 switch-on – version with two-stage condensing unit		20	0	100	%
406	A	407	U	Cooling request dependent evaporator Stage 2 ^o switch-on – version with two-stage condensing unit		70	0	100	%
408	A	409	U	Hysteresis for transition from Stage 1 to Stage 2, two-stage condensing unit		10	0	20	%
410	A	411	U	Minimum inverter operating time – version with inverter		10	0	9999	s
412	A	413	U	Inverter re-start blocking time – version with single-stage condensing unit + inverter		60	0	300	s
413	A			AO cooling signal inversion	0 Switched OFF 1 Switched ON				
Water heating with pre-heating function									
414	A	415	U	Outdoor temperature-dependent pump start-up in the AHU Stop and Run mode		5	-64	64	°C
416	A	417	U	Minimum pump run time		180	0	9999	s
418	A	419	U	Pump downtime to the pump turning activation		168	0	9999	h
420	A	421	U	Active pump turning time		60	0	9999	s
422	A	423	U	Active function preheating of water operation time		120	0	600	s
424	A	425	U	Pre-heating function blocking time between AHU unit shut-down and restart		5	0	30	min
426	A	427	U	Water heater circuit heating curve setting at the AHU start-up X1		-10	-30	5	°C
428	A	429	U	Water heater circuit heating curve setting at the AHU start-up Y1		100	0	100	%
430	A	431	U	Water heater circuit heating curve setting at the AHU start-up X2		10	0	50	°C
432	A	433	U	Water heater circuit heating curve setting at the AHU start-up Y2		10	0	100	%
434	A	435	U	Stop to Run mode switching delay AP trigger value		60	0	600	s
436	A	437	U	Water heat exchanger dependent AP trigger value – AHU in Run mode		15	0	50	°C
438	A	439	U	Water heat exchanger dependent AP trigger value - AHU in Stop mode		30	0	50	°C
440	A	441	U	Inlet air dependent AP evaluation enabling delay after the unit start-up		60	0	600	s
442	A	443	U	Inlet air temperature dependent AP start-up – failure alarm A		6	-64	64	°C
444	A	445	U	Inlet air temperature dependent AP start-up		8	-64	64	°C
446	A	447	U	Maximum return water temperature		70	20	140	°C
Water pre-heating									
448	A	449	U	Outdoor dependent pre-heating (pump) start-up		5	-50	15	°C
450	A	451	U	Pump downtime to the pump turning activation		168	0	9999	h
452	A	453	U	Active pump turning time		30	0	9999	s
454	A	455	U	Minimum pump run time		30	0	9999	s
Heating water source switching									
456	A	457	U	Limit value for heating		15	5	25	°C
458	A	459	U	Start-up sequence delay		120	10	600	s
Gas heating									
460	A	461	U	Cooling sequence enabling	0 without cooling 1 with cooling				
462	A	463	U	Minimum burner run time		150	0	600	s
464	A	465	U	Minimum burner downtime		150	0	600	s
466	A	467	U	Burner restart protection time (burner Stage 1)		150	0	600	s
468	A	469	U	Modulation burner opening/closing speed (burner Stage 1)		5	0	20	%/s
470	A	471	U	Heating request value for the burner Stage 2 switch-off		40	10	100	%
472	A	473	U	Maximum flue-gas temperature setting for alarm		230	210	400	°C
474	A	475	U	Maximum flue-gas temperature		210	160	p.472	°C
476	A	477	U	Requested flue-gas temperature		160	150	210	°C
478	A	479	U	Minimum flue-gas temperature		150	100	160	°C
Electric heating									
480	A	481	U	Electric heating switching on – request for heating		20	0	100	%
482	A	483	U	Electric heating hysteresis		10	1	100	%

List of Data Points (HMI-SG controller)

Menu HMI-SG									
Parameter				Meaning	Factory Settings				
Notation		Reading			Value	Min	Max		
code	level	code	level						
Mixing									
484	A	484	U	Minimum fresh air value setting		20	0	100	%
484	A	484	U	Minimum fresh air value setting – Comfort mode (pool unit)		20	0	100	%
485	A	485	A	Minimum fresh air value setting – Economy mode (pool unit)		20	0	100	%
484	A	485	U	Minimum fresh air flow rate setting		20	0	100	%
486	A	487	U	Starting temperature for mixing damper wide-open position		15	-64	64	°C
488	A	489	U	Starting time for mixing damper wide-open position		60	0	600	s
		490	U	Mixing damper control signal recurrence vale (normal/inverse)		100	0	100	%
Max. limit of fresh air function (ventilation unit)									
563	A	564	U	Max. limit of fresh air according to T outdoor		40	0	100	%
565	A	566	U	T outdoor from which the Max. limit of fresh air is activated		-10	-100	100	°C
		567	U	Information about the Max. limit of fresh air activation	0				
					1				
491	A	492	U	Required temperature for pre-heating		-20	-50	10	°C
493	A	494	U	Outdoor dependent electric pre-heating blocking		-30	-50	10	°C
495	A	496	U	Heating request dependent el. –pre-heating switch-on		20	0	100	%
497	A	498	U	Hysteresis for electric pre-heater switch-off		10	0	100	%
				Electric reheating					
502	A	503	U	Heating request dependent electric re-heating start-up for Stage 1		20	0	100	%
504	A	505	U	Hysteresis for electric re-heating switch-off		10	1	100	%
506	A	507	U	Fan stage dependent outlet limitation ST1		100	0	100	%
508	A	509	U	Fan stage dependent outlet limitation ST2		100	0	100	%
510	A	511	U	Fan stage dependent outlet limitation ST3		100	0	100	%
512	A	513	U	Fan stage dependent outlet limitation ST4		100	0	100	%
514	A	515	U	Fan stage dependent outlet limitation ST5		100	0	100	%
Heat recovery									
516	A	517	U	Freezing determination temperature exchanger		1	-64	64	°C
518	A	519	U	Start temperature for maximum - HRE speed/volume open BP PE		15	-64	64	°C
520	A	521	U	Start time for maximum - HRE speed/volume open BP PE		60	0	600	s
522	A	523	U	Heat recovery request dependent HRE run enabling		38	0	100	%
524	A	525	U	Hysteresis for HRE run stop		5	0	100	%
		526	U	Information - antifreeze protection start-up	0				
					1				
Night turning									
527	A	528	U	Time to next turning		3	0	9999	h
529	A	530	U	Active turning time		300	0	9999	s
Humidification									
531	A	532	U	Relative set-point of relative humidity - Comfort		40	0	100	%r.H.
535	A	536	U	Relative set-point of humidity - Economy		30	0	100	%r.H.
541	A	542	U	Humidification blocking in summer	0				
					1				
		545	U	Humidification output					%
		550	G	Calculated current humidification set-point in the cascade					
Dehumidification									
533	A	534	U	Dehumidification relative set-point - Comfort		60	0	100	%r.H.
537	A	538	U	Dehumidification relative set-point - Economy		70	0	100	%r.H.
533	A	534	U	Dehumidification required relative value		60	0	100	%r.H.
537	A	538	U	Dehumidification required absolute value		12	0	100	g/kg
539	A	540	U	Maximum humidity required value		80	0	100	%r.H.
		543	U	Current humidity value					
		544	U	Maximum humidity					%
		546	U	Dehumidification output					%
		547	U	Dew point					°C
548	A	549	U	Dew point deviation		1	-64	64	°C
		551	G	Calculated current dehumidification required value for cascade control					%r.H.
				Humidity-dependent fan speed compensation					
552	A	553	U	Humidity required value for compensation		50	0	100	%r.H.
554	A	555	U	Fan speed compensation function	0				
									increase

List of Data Points (HMI-SG controller)

Parameter				Menu HMI-SG		Factory Settings				
Notation		Reading		Meaning		Value	Min	Max		
code	level	code	level							
		556	U	Compensation display	1	decrease				%
		Humidity-dependent mixing damper position compensation								
560	A	561	U	Fan speed compensation function	0	Increase	0			
					1	Decrease				
		562	U	Compensation display						%
		Control constants								
		Cooling factors (all versions)								
601	S	602	A	Proportional factor			-5			
603	S	604	A	Integrating factor			60			s
605	S	606	A	Derivative factor			0			s
		Heat pump factors - heating								
607	S	608	A	Proportional factor			5			
609	S	610	A	Integrating factor			300			s
611	S	612	A	Derivative factor			0			s
		Heat pump factors - cooling								
613	S	614	A	Proportional factor			-5			
615	S	616	A	Integrating factor			300			s
617	S	618	A	Derivative factor			0			s
		Room (outlet) temperature dependent fan speed compensation								
619	S	620	A	Proportional factor			20			
621	S	622	A	Integrating factor			0			s
623	S	624	A	Derivative factor			0			s
		Heating dependent fan speed compensation								
625	S	626	A	Proportional factor			5			
627	S	628	A	Integrating factor			120			s
629	S	630	A	Derivative factor			0			s
		Cooling dependent fan speed compensation								
631	S	632	A	Proportional factor			-10			
633	S	634	A	Integrating factor			120			s
635	S	636	A	Derivative factor			0			s
		Air quality CO ₂ (VOC,CO) dependent compensation (damper position/ fan speed)								
637	S	638	A	Proportional factor			-0.3			
639	S	640	A	Integrating factor			300			s
641	S	642	A	Derivative factor			0			s
		Mixing								
643	S	644	A	Proportional factor			7			
645	S	646	A	Integrating factor			45			s
647	S	648	A	Derivative factor			15			s
		Heat recovery RHE/BP PE								
649	S	650	A	Proportional factor			3			
651	S	652	A	Integrating factor			60			s
653	S	654	A	Derivative factor			1			s
		Heat recovery – antifreeze protection								
655	S	656	A	Proportional factor			20			
657	S	658	A	Integrating factor			150			s
659	S	660	A	Derivative factor			0			s
		Electric reheating								
661	S	662	A	Proportional factor			1			
663	S	664	A	Integrating factor			60			s
665	S	666	A	Derivative factor			0			s
		Electric pre-heating								
667	S	668	A	Proportional factor			5			
669	S	670	A	Integrating factor			120			s
671	S	672	A	Derivative factor			0			s
		Water heating with pre-heating function								
673	S	674	A	Proportional factor – AP from return water			20			
675	S	676	A	Integrating factor - AP from return water			90			s

List of Data Points (HMI-SG controller)

Menu HMI-SG						Factory Settings			
Parameter		Meaning				Value	Min	Max	
Notation	Reading								
code	level	code	level						
677	S	678	A	Derivative factor - AP from return water	0			S	
679	S	680	A	Proportional factor - AP from inlet air	50				
681	S	682	A	Integrating factor - AP from inlet air	0			S	
683	S	684	A	Derivative factor - AP from inlet air	0			S	
685	S	686	A	Proportional factor - AP from max. return water temperature	-3				
687	S	688	A	Integrating factor - AP from max. return water temperature	300			S	
689	S	690	A	Derivative factor - AP from max. return water temperature	0			S	
691	S	692	A	Proportional factor - from temperature request	5				
693	S	694	A	Integrating factor - from temperature request	150			S	
695	S	696	A	Derivative factor - from temperature request	0			S	
				Electric heating					
697	S	698	A	Proportional factor	2				
699	S	701	A	Integrating factor	60			S	
702	S	703	A	Derivative factor	0			S	
				Gas heating					
704	S	705	A	Proportional factor - burner	5				
706	S	707	A	Integrating factor - burner	60			S	
708	S	709	A	Derivative factor - burner	0			S	
710	S	711	A	Proportional factor - bypass damper	-5				
712	S	713	A	Integrating factor - bypass damper	120			S	
714	S	715	A	Derivative factor - bypass damper	0			S	
716	S	717	A	Proportional factor - maximum temperature of flue gas	10				
718	S	719	A	Integrating factor - maximum temperature of flue gas	120			S	
720	S	721	A	Derivative factor - maximum temperature of flue gas	0			S	
722	S	723	A	Proportional factor - minimum temperature of flue gas	-10				
724	S	725	A	Integrating factor - minimum temperature of flue gas	120			S	
726	S	727	A	Derivative factor - minimum temperature of flue gas	0			S	
				Cascade temperature control					
728	S	729	A	Proportional factor	10				
730	S	731	A	Integrating factor	1200			S	
				Cascade humidity control					
732	S	733	A	Proportional factor	4				
734	S	735	A	Integrating factor	0			S	
				Humidification					
736	S	737	A	Proportional factor	5				
738	S	739	A	Integrating factor	120			S	
740	S	741	A	Derivative factor	0			S	
732	S	733	A	Proportional factor	4				
734	S	735	A	Integrating factor	0			S	
				Dehumidification					
742	S	743	A	Proportional factor	-2				
744	S	745	A	Integrating factor	240			S	
746	S	747	A	Derivative factor	0			S	
				Humidity-dependent fan speed compensation					
748	S	749	A	Proportional factor	-5				
750	S	751	A	Integrating factor	0			S	
752	S	753	A	Derivative factor	0			S	
				Constant Air Flow/Pressure Control - inlet					
754	S	755	A	Proportional factor	0.3				
756	S	757	A	Integration factor	30			S	
758	S	759	A	Differentiation factor	0			S	
				Constant Air Flow/Pressure Control - outlet					
760	S	761	A	Proportional factor	0.3				
762	S	763	A	Integration factor	30			S	
764	S	765	A	Differentiation factor	0			S	
				Checks, system and network settings					
				Humidity-dependent mixing damper position compensation					
766	S	767	A	Proportional factor	-2				
768	S	769	A	Integrating factor	45			S	

Menu HMI-SG									
Parameter				Meaning	Factory Settings				
Notation		Reading			Value	Min	Max		
code	level	code	level						
770	S	771	A	Derivative factor					s
				Difference between required and inlet temperature monitoring					
801	A	802	G	Maximum difference (±°C)		10	0	99	°C
803	A	804	G	Minimum limit (°C)		10	0	99	°C
805	A	806	G	Time delay after AHU start-up (s)		60	0	9999	s
				Difference between required and room (outlet) temperature monitoring					
807	A	808	G	Maximum difference (±°C)		10	0	99	°C
809	A	810	G	Minimum limit (°C)		10	0	99	°C
811	A	812	G	Time delay after AHU start-up (s)		600	0	9999	s
				Remote fault					
813	A	814	G	Failure class selection to digital output	0	1			
					1				
		815	G	Alarm message (generated depending on priorities)	0				
					1				
				Fire mode					
816	A	817	G	Fan behaviour during fire selection	0	0			
					1				
					2				
					3				
818	A	819	G	Fan output during fire selection		80	0	100	%
820	A	821	G	Fire alarm activation inlet temperature		70	0	99	°C
822	A	823	G	Fire alarm activation outlet temperature		50	0	99	°C
				Alarm number for HMI					
		824	U	Alarm number					
				System settings - control unit					
825	A	825	A	Failure acknowledgement (reset of all failures after they have been removed)	0				
					1				
826	S	826	S	Software reset of the controller	0				
					1				
827	S	827	S	Control unit location building physical address		0	0	15	
828	S	828	S	Control unit location floor physical address		0	0	15	
829	S	829	S	Control unit device address		0	0	250	
				SD card					
830	S			Application load from SD card	0				
					1				
834	S			Parameter save to SD card	0				
					1				
		835	S	Parameter save to SD card - successful	0				
					1				
836	S			Parameter load from SD card	0				
					1				
		837	S	Parameter load SD card - successful	0				
					1				
831	S	831	S	Data point recovery (factory settings)	0				
					1				
				User settings					
832	A	832	A	Data point saving (user settings)	0				
					1				
833	A	833	A	Data point recovery (user settings)	0				
					1				
				ModBus					
		838	S	Alarm	0				
					1				
839	S	839	S	Failure flow activation delay (at fan start-up)		45	0	600	s
840	S	840	S	Failure flow activation delay (during fan run)		5	0	600	s
841	S	841	S	Thermo-contact (TK) failure activation delay (fans)		2	0	600	s
842	S	842	S	Frequency inverter failure activation delay		2	0	600	s

Menu HMI-SG										
Parameter				Meaning	Factory Settings					
Notation		Reading			Value	Min	Max			
code	level	code	level							
843	S	843	S	Number of message repeating during error transfers				2		
844	S	844	S	Number of error transfers for communication failure evaluation				6		
845	S	845	S	Frequency inverter 1 address, inlet fan				1		
846	S	846	S	Frequency inverter 2 address, inlet fan backup or second inlet fan				2		
847	S	847	S	Frequency inverter 3 address, inlet fan twin backup				3		
848	S	848	S	Frequency inverter 4 address, inlet fan twin backup				4		
849	S	849	S	Frequency inverter 5 address, outlet fan				5		
850	S	850	S	Frequency inverter 6 address, outlet fan backup or second outlet fan				6		
851	S	851	S	Frequency inverter 7 address, outlet fan twin backup				7		
852	S	852	S	Frequency inverter 8 address, outlet fan twin backup				8		
853	S	853	S	Frequency inverter 9 address, 3rd auxiliary fan				9		
854	S	854	S	Frequency inverter 10 address, second 3rd auxiliary fan				10		
857	S	857	S	Frequency inverter 11 address, rotary heat exchanger				11		
858	S	858	S	Control unit Modbus resistance terminal	0	inactive				
					1	active				
				Network connection configuration						
				(After setting – the reset is required !!)						
859	A			DHCP	0	passive				
					1	active				
860	A			Settings IP[w]				192	0	255
861	A			Settings IP[x]				168	0	255
862	A			Settings IP[y]				1	0	255
862	A			Settings IP[z]				199	0	255
		864	U	Actual IP[w]						
		865	U	Actual IP[x]						
		866	U	Actual IP[y]						
		867	U	Actual IP[z]						
868	A			Settings mask [w]				255	0	255
869	A			Settings mask [x]				255	0	255
870	A			Settings mask [y]				255	0	255
871	A			Settings mask [z]				0	0	255
		872	U	Actual mask [w]						
		873	U	Actual mask [x]						
		874	U	Actual mask [y]						
		875	U	Actual mask [z]						
876	A			Settings gateway [w]				0	0	255
877	A			Settings gateway[x]				0	0	255
878	A			Settings gateway [y]				0	0	255
879	A			Settings gateway [z]				0	0	255
		880	U	Actual gateway [w]						
		881	U	Actual gateway [x]						
		882	U	Actual gateway [y]						
		883	U	Actual gateway [z]						
				System settings - room unit						
884	S	884	S	Transition to time program delay				1	0	23
885	A	885	A	Byte address, Diagnostic mode – byte address				5		
886	A	886	A	Alarm mode	0	N/A		2		
					1	only after alarm				
					2	constantly				
887	S	887	S	Room temperature display, combined or inlet temperature	0	Temp. from HMI-SG		0		
					1	Temperature average				
					2	Outlet Temperature				
					3	Temperature in the inlet				
895	U	895	U	Temperature unit display settings °C/°F	0	°C		0		
					1	°F				
896	A	896	A	Required value compensation setting +/-				3	0	12
897	A	897	A	Required value increment	0	Increment per 0.1		0		°C
					1	Increment per 0.5				°C

Menu HMI-SG									
Parameter				Meaning	Factory Settings				
Notation		Reading			Value	Min	Max		
code	level	code	level						
898	A	898	A	Displayed time format - 12h/24h	0	24 h			
					1	12 h			
Passwords									
899	S	899	S	Password for Service level access			0	9999	
901	A	901	A	Password for Admin level access			0	9999	
902	U	902	U	Password for User level access			0	9999	
903	G	903	G	Password for Guest level access			0	9999	
Communication with Building management system (BMS) - (After settings - reset required !!)									
LON									
921	S	921	S	Send heart beat (s)		2700	0	9999	s
922	S	922	S	Receive heart beat (s)		3600	0	9999	s
923	S	923	S	Min send intervall (s)		5	0	9999	s
924	S	924	S	Service pin	0	inactive			
					1	active			
925	S	925	S	Out temperature value	0	of application	0		
					1	of communication			
926	S	926	S	Fire alarm (external)	0	of application	0		
					1	of communication			
Modbus RTU - Slave (BMS)									
925	S	925	S	Out temperature value	0	of application			
					1	of communication			
926	S	926	S	Fire alarm (external)	0	of application			
					1	of communication			
931	S	931	S	Modbud Slave1	0	inactive			
					1	active			
932	S	932	S	Address Slave1			1		
933	S	933	S	Baud rate Slave1		default	9600		b/s
				2400 (factor 10)					
				4800 (factor 10)					
				9600 (factor 10)					
				19200 (factor 10)					
				38400 (factor 10)					
934	S	934	S	Stop bits Slave1	0	One stop bit	1		
					1	Two stop bits			
935	S	935	S	Parity Slave1	0	Even	2		
					1	Odd			
					2	None			
936	S	936	S	Termination (resistor) Slave1	0	inactive	0		
					1	active			
937	S	937	S	Response timeout Slave1			5	0	3600
									s

List of Failures (HMI-SG controller)

Failure Description	Class	Failure Number	Failure Causes
Reduced humidification output	B	10	Reduced humidification output due to the temperature priority (swimming-pool unit) – an information message.
Auxiliary Fan	B	15	1.) Communication error between control unit and the auxiliary fan frequency inverter (Modbus data bus) – inverter internal error; wrong settings of the frequency inverter data points – bus communication protocol, data transfer rate, parity, number of stop-bits, communication timeout; poor connection of the bus cable to the frequency inverter terminals; bus terminal resistance settings on the last frequency inverter has not been performed. 2.) Auxiliary fan failure (Modbus data bus) - thermo-contact, flow sensor
Auxiliary Fan - twin	B	16	1.) Communication error between control unit and the auxiliary fan twin frequency inverter (Modbus data bus) – inverter internal error; wrong settings of the frequency inverter data points - bus communication protocol, data transfer rate, parity, number of stop-bits, communication timeout; poor connection of the bus cable to the frequency inverter terminals; bus terminal resistance settings on the last frequency inverter has not been performed. 2.) Auxiliary fan twin failure (Modbus data bus) - thermo-contact, flow sensor
Backup fans in the inlet	B	18	Main inlet fan failure (backup fan activated) - thermo-contact, flow sensor A Class failure – inlet backup fan shutdown
Backup fans in the outlet	B	19	Main outlet fan failure (backup fan activated) - thermo-contact, flow sensor A Class failure - outlet backup fan shutdown
Communication, Modbus	B	23	Communication error between control unit and the fan or ROV frequency inverter (Modbus data bus) - inverter internal error; wrong settings of the frequency inverter data points – bus communication protocol, data transfer rate, parity, number of stop-bits, communication timeout; poor connection of the bus cable to the frequency inverter terminals; bus terminal resistance settings on the last frequency inverter has not been performed.
Process communication KNX	B	23	Communication error between control unit and HMI-SG controller (KNX bus)
Room unit 1 - Temperature	B	24	Disconnected or damaged HMI-SG1 controller
Room unit 2 - Temperature	B	24	1) Disconnected or damaged HMI-SG2 controller 2) Wrong HMI-SG2 controller communication address setting (the same address with the HMI-SG1 controller)
Outdoor temperature	B	25	Disconnected or damaged outdoor temperature sensor
Room temperature	B	26	Disconnected or damaged room temperature sensor
Outlet temperature	B	28	Disconnected or damaged outlet temperature sensor
Inlet temperature difference	B	32	Information message on the difference between inlet and required temperatures, providing the Inlet and Required Temperature Difference Monitoring has been activated (in the data point 201). If the temperature difference is higher than pre-set Maximum Difference (data point 801) or if the inlet temperature drops below the pre-set minimum threshold (data point 803), an information message is displayed.
Room temperature difference	B	33	Information message on the difference between room/outlet and required temperatures, providing the Inlet and Required Temperature Difference Monitoring has been activated (in the data point 201). If the temperature difference is higher than pre-set Maximum Difference (data point 807) or if the room/outlet temperature drops below the pre-set minimum threshold (data point 809), an information message is displayed.

List of Failures (HMI-SG controller) (continuation)

Failure Description	Failure Class	Failure Number	Failure Causes
Outdoor temperature dependent heat pump blocking	B	35	Information message – The heat pump blocked due to outdoor temperature
Heat pump	B	36	Heat pump failure – contact
Humidification	B	37	Humidifier failure - contact
Filters	B	39	Filter failure - contact
Fan operating hours	B	40	The pre-set fan operating hours have been exceeded; operating hours are set using the HMI-DM, TM or HMI@Web controllers.
Cooling	B	41	Cooling failure (direct expansion evaporation, inverter condensing unit) -contact
ZZT (antifreeze protection)	B	42	1.) Lost communication between control unit and ROV frequency inverter - inverter internal error; wrong settings of the frequency inverter data points (bus communication protocol, data transfer rate, parity, number of stop-bits, communication timeout; poor connection of the bus cable to the frequency inverter terminals; bus terminal resistance on the last frequency inverter has not been performed) 2.) Antifreeze protection ROV/DEV has been activated due to drop in temperature below the pre-set value (data point 516).
ZZT (ROV)	B	43	Belt - rotary heat exchanger
Inlet air relative humidity	B	46	1.) Inlet air humidity sensor disconnected or damaged 2.) Humidity > 100%
Outdoor air relative humidity	B	47	1.) Outdoor air humidity sensor disconnected or damaged 2.) Humidity > 100%
Room air relative humidity	B	48	1.) Room air humidity sensor disconnected or damaged 2.) Humidity > 100%
Air quality (CO, CO ₂)	B	49	1.) Air quality sensor disconnected or damaged 2.) Air quality > 3000 ppm
Back draught protection (TH)	B	55	Back draught protection for the chamber after cooling – thermostat TH 167 or ES3M-T3.
Flue-gas high temperature, heater shut down	B	56	Flue-gas temperature sensor disconnected or damaged
Flue-gas high temperature, VZT shut down	A	57	1.) Flue-gas temperature sensor disconnected or damaged 2.) Flue-gas temperature is higher than the pre-set temperature (data point 472).
Burner failure	A	58	Burner internal failure - contact
Electric preheater	A	59	Temperature behind the electric pre-heater < -50°C
	B	59	1.) Temperature sensor behind the electric heater disconnected or damaged 2.) Electric pre-heater failure - thermostat
Temperature in the inlet	A	60	1.) Inlet air sensor disconnected or damaged 2.) Inlet air temperature is higher than the pre-set temperature (data point 442) – water heating antifreeze protection (PMO) is active.
Heat exchanger freezing	B	61	Temperature sensor behind ROV disconnected or damaged
Electric heating	A	62	Electric heater failure - thermostat

List of Failures (HMI-SG controller) (continuation)

Failure Description	Class	Failure Number	Failure Causes
Electric reheating	A	63	Electric after-heater failure - thermostat
Water heater pump	A	65	Water heater pump failure - contact
Water heating additional antifreeze protection (PMO)	A	65	Electric heating additional PMO - thermostat
Inlet fan	A	66	Backup inlet fan error - thermo-contact
Inlet fan (air-flow failure)	A	66	1.) Backup inlet fan error - flow sensor
			2.) Single-speed fan error - flow sensor
Outlet fan	A	67	Backup outlet fan error - thermo-contact
Outlet fan (air-flow failure)	A	67	Backup outlet fan error - flow sensor
Air flow sensor (pressure) - inlet fan	A	69	Unconnected or damaged air flow sensor (pressure) - inlet fan
Air flow sensor (pressure) - outlet fan	A	70	Unconnected or damaged air flow sensor (pressure) - outlet fan
Fan (inlet, outlet)	A	71	1.) Communication error between control unit and the inlet/outlet fan frequency inverter (Modbus data bus) - inverter internal error; wrong settings of the frequency inverter data points – bus communication protocol, data transfer rate, parity, number of stop-bits, communication timeout; poor connection of the bus cable to the frequency inverter terminals; bus terminal resistance settings on the last frequency inverter has not been performed.
			2.) Inlet/outlet fan error - thermo-contact
Fan (inlet, outlet) – flow failure	A	72	1.) Lost communication between control unit and fan frequency inverter - inverter internal error; wrong settings of the frequency inverter data points - bus communication protocol, data transfer rate, parity, number of stop-bits, communication timeout; poor connection of the bus cable to the frequency inverter terminals; bus resistance terminal settings on the last frequency inverter has not been performed.
			2.) Inlet/outlet fan error - flow sensor
Water pre-heating	A	74	1.) Temperature sensor disconnected or damaged
			2.) Water temperature in the water heat exchanger return pipe > 140 °C, or water temperature in the water heat exchanger return pipe < 5 °C
Outlet temperature-dependent fire alarm activation	A	81	Fire alarm triggered due to exceeded pre-set outlet air temperature (data point 820)
Inlet temperature-dependent fire alarm activation	A	81	Fire alarm triggered due to exceeded pre-set inlet air temperature is (data point 821)
Fire alarm (external failure)	A	81	1.) Fire alarm triggered by the fire dampers - contact
			2.) External failure - contact
Water heater return water	A	82	1.) Temperature sensor disconnected or damaged
			2.) Water temperature in the water heat exchanger return pipe > 140 °C, or water temperature in the water heat exchanger return pipe < 8 °C

Remak Mobile App

Introduction

REMAK Application is a touchscreen application for mobile phones (smartphones) and tablets running Google Android (v. 4.1 and higher) or Apple iOS (v. 12.2 and higher). In installations / applications where you can use Wi-Fi LAN and / GSM mobile data to connect to the Internet.

Mobile applications such as HMI to VCS serve as a user-friendly driver for basic HVAC control - triggering desired mode (+ switching off), setting (user-friendly parameters only) and simple operation overview (feedback).

Function

Mobile application brings control/monitoring capabilities easily and from anywhere- where a mobile device can be connected via wifi or GSM mobile data to a computer network, of the Internet (ie provided the network's functionality (availability) is no longer necessary, and no other operating mode is required). It does not include full service setup/commissioning, but with the mobile application, the standard HMI @ WEB interface is also available - including via the mobile application menu (but standard sign-in required) - which must be used for commissioning of the whole device and basic network communication and password settings for the safe operation of the mobile application to control the HVAC.

An example of a mobile application for setting the setpoints is shown in Figure 22.

Note: The VCS control unit must be equipped (factory-configured) with a LAN connection, incl. License (or Configuration ID) to use Remak - Inthouse.

If the application licence is ordered = configured in the project, configuration IDs (two "codes") for the mobile application and the licence for the respective VCS, or controller, are included in the accompanying VCS documentation and printed on the stickers attached directly to the controller.

Security

Use of the application is security with an adjustable password in the controller. Security against unauthorized access to the LAN must be provided with standard IT resources (see also on page 54 of this manual).


Note: Setting your own PLC password for Remak (as well as JSON communication) as well as for HMI@ EB is one of the necessary safeguards against unauthorized operation!

Further, the application (in the Settings menu) provides an extended log-in option for the "Advanced" user role using a "special" constant password (this is not a security password) allowing some specific elements for experts, i.e., more detailed information about automatic operation or the control mode (otherwise accessible on the HMI@WEB interface) to be displayed. This information can be rather confusing for ordinary users. Note: The RMKDEV user role is not intended for standard use, it is used only for development/test purposes of the manufacturer.

Additional information

Additional user information (basic features, questions and answers, application installation information) can be found on the product web page: <https://www.remak.eu>

Figure 21 – mobile app GUI



Control (HMI-DM,HMI-TM controllers)

HMI-DM (HMI-TM) control devices ensure communication between the VCS control unit and the user. They are intended for air-handling device control, handling and service. The HMI control device can be connected to the POL4xx or POL6xx controllers. During controller operation, a single HMI control device can be connected or disconnected and alternatively (in sequence) used to control multiple control units (controllers).

Connection


The HMI-DM controller can be connected using a serial interface (4-wire, twisted pair) with two RJ45 connectors. The cable length is 1.5 m (the cable is included in the delivery). When installed on a wall, the HMI-DM controller can be connected using a shielded 8-wire UTP cable with two RJ45 connectors. The maximum distance is up to 50 m.

The HMI-TM controller can be connected to the control unit using a 4-wire cable (twisted pair) with one RJ45 connector and one slim connector. The cable length is 2.5 m (the cable is included in the delivery).

Warning

After connecting the controller to the control unit, it is necessary to route the cable through the PG16 grommet. This degree of protection IP20 is ensured. If a higher level of protection of the distribution board casing is required, the grommet will have to be resealed. An optional grommet with an RJ 45 connector can be used to make it easy to connect (disconnect) the HMI controller (an extra order is required, not included in the standard delivery). Then the RJ45 connector must be connected to the RJ45 socket on the controller. For the socket marking, see the figure.

Figure 22



HMI-DM controller

Operating conditions

Degree of protection: IP 31. Permissible ambient temperature: -40 °C to 70 °C. Relative humidity <95 %.

Device Description

The controller consists of two separate parts – the face plate with a display and the rear plate. Dimensions of the HMI-DM controller are 144x96x26 mm and the integrated LCD display resolution is 208x96 pixels. The display can show 8 lines. The HMI-DM controller is equipped with three function buttons, **INFO**, **FAILURE** and **ESC**, and one **scrolling knob**. The scrolling knob and buttons are used to navigate within the menu and to change the parameters and control values. The **INFO**, **FAILURE** and **ESC** buttons are equipped with LEDs to indicate operating states.

The controller can also be delivered in a version for free location. The magnets on the rear side of the HMI enable the controller to be attached to metal parts (e.g. the air-handling unit).

Figure 23 – HMI-DM controller




For fixed mounting, the controller is equipped with threaded holes on its rear side to screw it to the mounting plate.

Table 1 – Function Buttons

Button (Name)	Activity	Description
Scrolling knob	Turning	- Selection from the menu - Selection from the parameters or change to a value
	Press	- Selection/confirmation
Esc	Hold	- When logged in, press and hold for at least 3 s to go to the log-in/log-out page. - When not logged in at any access level, the log-in page is displayed.
	Press	- Cancels the change to the parameter value - Returns to the upper level of the menu/previous page - Returns to the last active page before accessing the Password Administration page - Returns to the last active page before accessing the Home page using the Info button.
Info	Hold	- Goes to the Start Menu
	Press	- Goes to the Main Menu from the current menu page - Goes to the Start Menu page from the Main Menu
	Flashing green	- Air-handling unit start-up sequence
Failures	Green light	- Air-handling unit operation
	Press	- Every time you press this button, you will cycle through the following pages → List of Failures → History of Failures → Alarm Settings (failure confirmation and reset)
	Flashing red	- Active unconfirmed failures
	Red light	- Active confirmed failures

Control (HMI-DM,HMI-TM controllers)

Figure 24 – Installation on a Wall



HMI-TM controller

Operating conditions

Degree of protection: IP 65 (version with magnetic fixation).
Permissible ambient temperature: -20 °C to 60 °C. Relative humidity: 5 % to 95 %.

Device Description

Dimensions of the HMI-TM controller are 173x95.5x21.6 mm. The LCD display resolution is 128x96 pixels. The HMI-TM controller is equipped with 6 function buttons, **INFO**, **FAILURE**, **ESC**, **UP**, **DOWN** and **ENTER**. The **INFO**, **FAILURE** and **ESC** buttons simultaneously indicate operating states (Stop – failure, operation). The **UP**, **DOWN** and **ENTER** buttons are used to navigate through the menu. The magnetic plate on the rear side of the HMI enables free attachment to metal objects.

Figure 25 – HMI-TM controller





Table 2 – Function Buttons

Button (Name)	Activity	Description
Up	Press	- Scrolling the list upwards - Increases the parameter value
	Hold	- Hold this button longer than 1.5 s to speed up the list scrolling upwards - Increases the parameter values in higher grades
Down	Press	- Scrolling the list downwards - Decreases the parameter values
	Hold	- Hold this button longer than 1.5 s to speed up the list scrolling downwards - Decreases the parameter values in higher grades
Enter	Press	Selection/confirmation
	Hold	- When logged in, press and hold for at least 3 s to go to the log-in/log-out page. - When not logged in at any access level, the log-in page is displayed.
Info	Press	- Goes to the Main Menu from the current menu page - Goes to the Start Menu page from the Main Menu
	Flashing green	- Air-handling unit start-up sequence
	Green light	- Air-handling unit operation
Failures	Press	- Every time you press this button, you will cycle through the following pages → List of Failures → History of Failures → Alarm Settings (failure confirmation and reset)
	Flashing red	- Active unconfirmed failures
	Red light	- Active confirmed failures
Esc	Press	- Cancels the change to the parameter value - Returns to the upper level of the menu/previous page - Returns to the last active page before accessing the Password Administration page - Returns to the last active page before accessing the Home page using the Info button.
	Hold	- Moves to the HMI Settings page

Control (HMI-DM,HMI-TM controllers)

Display Layout

Figure 26 – LCD isplay



- a The user log-in is graphically indicated by the key symbol in the page heading. The access levels are distinguished by the following symbols.

Table 3 – access levels

User	Icon
GUEST	
USER	
ADMINISTRATOR	
SERVICE	

- b Page Heading
- c Current line from the total number of lines on the page
- d The page also includes the line above the current display
- e The page also includes the line below the current display
- f Access to the Main Menu from the current menu page
- g Current line of the selection

Access to the Submenu

The cursor marks the selection of parameters on a corresponding line. The arrow indicator in the right part of the display indicates the option to access a submenu.

- Turn the knob (or use the Up and Down buttons) to select the required line.
- Press the knob (Enter) to access the submenu.



If only the value description is highlighted on the line, the value on the line is intended only to be displayed, refer to Temperatures.



Value Settings

If the description and value of the parameter is highlighted on the line, the highlighted value can be changed.

- Turn the knob (or use the Up and Down buttons) to select the line.
- Press the knob (Enter) to confirm the page selection.
- Turn the knob (or use the Up and Down buttons) to change the parameter values.
- Press the knob (Enter) to confirm the value change.
- Press the Esc button to exit the page.



Setting the Selection from Multiple Parameters

- The current parameter selection is marked.
- Turn the knob (or use the Up and Down buttons) to select a new parameter.
- Press the knob (Enter) to confirm the selection or press the Esc button to retain the original value as valid.



Setting the Continuous Value using the Knob

The scale displays minimum and maximum values.

- Set the arrow on the respective number
- By turning the wheel, the number can be changed from 0 to 9.
- The cursor is moved to the following item automatically
- Press the knob to confirm the selection or press the Esc button to retain the original value as valid

Setting the Continuous Value using the Up and Down Buttons

- Press (hold) the Up or Down button to set the required value.
- Press Enter to confirm the selection or press the Esc button to retain the original value as valid.



Control (HMI@Web – Connection to PC and LAN/WAN)

Installation and Connection to PC and LAN/WAN

Basic Requirements

The HMI@Web controller is intended to operate the VCS control unit using an internet browser. This controller is a more convenient variant of HMI DM, TM controllers featuring remote control and PC control. However, it is not equipped with comfort features like data collection and filing, e-mail messages on system failure events. User access is the same as with HMI DM, TM controllers. No administration of users or their roles is created.

The PC must be equipped with an Ethernet network card with the RJ-45 connector, or connected to the LAN network - the HMI@Web system can be connected directly to (one) PC or integrated into the LAN, resp. WAN network, and is accessible from any computer (access authorization is needed) in the network. The TCP/IP protocol must be installed on your PC (to install the TCP/IP protocol, refer to your operating system manual).

Notice – Proxy server settings

To ensure proper interoperability of the internet browser on your PC directly connected to the HMI@Web unit, it is necessary to disable proxy server!

In Internet Explorer 8: Go to "Tools" / "Internet Options" >> "Connections" >> button / "Local network options" / "Specify" ... lower half of the window = "Proxy server" box – must not be checked (see figure).

Warning

Before putting the HMI@Web controller operated by PC, respectively via LAN network, into operation, the installation of the controlled air-handling unit must be checked to see whether it has been performed in accordance with its Installation and Operating Instructions (installation, inspections, safety precautions, heating media, etc.)! Refer to "Location and Installation".

Default HMI@Web IP Address Setting

During production, the HMI@Web unit was assigned the fixed IP address: **192.168.1.199**, mask 255.255.255.0, and the default port 0.0.0.0.


Notice

If this address cannot be used in LAN, it is necessary to change the setting from the computer (directly connected PC as described below) before connecting it to the network.

HMI@Web controller Start-up Procedure

1. Step: HMI@Web controller connection:

Figure 28 – HMI@Web unit connected directly to PC



HMI@Web + stand-alone PC = HMI@Web controller connected directly to PC

Using the Ethernet crossed cable* (UTP cable, RJ-45 connectors) connect the HMI@Web unit ("LAN" socket on the upper side of the controller) to the network card of your computer.



Figure 29



Attention: Connector RJ-45 marked BSP, BUS cannot be used! It is intended for HMI controller – refer to "HMI Controller Operating Instructions". Max. length of the cable between the HMI@Web and computer can be 100 m; however, we recommend 80 m. Switch

the HMI@Web main switch on. If a greater distance between the PC and the VCS control unit controlled by the HMI@Web controller is desired, it will be necessary to use a structured network (Ethernet) including active network elements – see below, or contact a specialized PC and IT supplier.

Figure 27 – Network connection settings



* This cable is not part of delivery.

Control (HMI@Web – Connection to PC and LAN/WAN)

Connection of the VCS control unit with the HMI@Web controller to the LAN

Warning

If the default IP address of the HMI@Web unit cannot be used in the LAN network – i.e. a different address range is used in the LAN network (e.g. 10.0.0..., 192.168.10....), or the existing PC within the LAN network has already been assigned the IP address...199 (can be verified by the "ping + IP address" command) which must be retained - it is necessary to change the HMI@Web IP address setting from the computer (as described above) before connecting it to the network.


If you are not an administrator of the LAN network, you will have to contact your LAN administrator. The same applies if you are not an administrator of your computer.

Using the Ethernet cable (not included in the HMI@Web delivery) connect the HMI@Web unit to the LAN network connecting point in the same way as any other LAN device. The same conditions as in step 1 (connecting points, cable lengths) apply for connection to LAN.

To set the addresses, it is possible to use other controllers like HMI SG, TM and DM. Maximum HMI@Web unit distance from an active network element must comply with the Ethernet network conditions.

Notice: The HMI@Web unit can also be connected to the LAN network via the wi-fi access point in the client mode, etc. – consult your network administrator.

Figure 30 – HMI@Web connected to local network



To be able to operate the HMI@Web unit, a unique IP address within the network range (see fig. # 8) must be assigned to the HMI@Web unit. Go to "Connection" >> "LAN connection" (refer to Step 4: Activation).

Always restart the HMI@Web unit after assigning a new IP address – the new setting is applied after restart.

Attention! Always consult your network administrator if connecting the HMI@Web to LAN.

2. Step: Computer Configuration - TCP/IP Settings

Warning


In this step, settings of the PC using Microsoft Windows® 7 are described; if you use other operating systems you will have to perform corresponding settings of your computer in accordance with your operating system user manual, or ask an expert for help. This setting procedure is needed only for a permanent direct connection to PC, or to change the HMI@Web settings before its integration into the LAN network.

After setting the HMI@Web unit (following the below described procedure), and when the HMI@Web default address complies with network addressing, it is only necessary to enable new hardware in the infrastructure administration – there is no need to make any other adjustments to individual PCs.

Adjust PC network card settings in Windows:

Go to "Start" >> "Settings" >> "Control Panel" >> "Network connection". Click (right mouse button) on "Local network connection", then on "Properties", and display "Internet protocol (TCP/IP)" properties".

Figure 31 – TCP/IP settings



If the protocol is not found in the list of items (it is not installed), add the item to the system. Click the "Install" button, select the "Internet protocol (TCP/IP)", and follow the instructions on the screen.

Select item "Use the following IP address". Type "192.168.1.3**" into the "IP address" box and "255.255.255.0" into the "Network mask" box.


Do not type anything into the item boxes of the second part of the window (leave them blank).

If you are prompted by the system to restart, confirm the restart immediately.

Connection, resp. TCP/IP Protocol Verification

To verify the settings and connection, type the HMI@Web address into the URL box of the internet browser (the HMI@Web system must be switched on); it should start functioning in 0.5 – 3 minutes - the time needed to initialize the webserver.

Figure 32 – IP address entry



After sending the request, and if the settings and connecting are correct, the HMI@Web unit is ready to be configured, and the login window is displayed on the screen requesting the user name and password.

** Any number from 1 to 254 except 199 (which is assigned to the HMI@Web controller) can be used in the first place of the IP address.

Control (HMI@Web – Connection to PC and LAN/WAN)


3rd Step Setting the Web@HMI for Connection

The Web@HMI controller can be configured from the web interface (the same one which serves for normal operation of the system). Enter the following IP address `http://192.168.1.199` in the address field in the web browser and confirm with the "Enter" button. Note: The Web@HMI configuration for the connection itself is not dependent on the browser used. Enter log-in data in the fields of the Web Server dialog box – see the figure:

User name: WEB (or ADMIN)*
Password: SBTAdmin!


* ADMIN only if the WEB log-in is non-functional (for older systems)

Figure 33 – Web Server dialog box



There is an account for one user on the HMI@Web Web Server. The Web Server user log-in name and password can be changed in the menu: Connection >> LAN Connection. Upon successful log-in to the HMI@Web Web Server, the Start screen is displayed.

Figure 34 – Start screen



To access the Main Menu, it is necessary to log in at the corresponding access level. Upon selecting the link on the first line the log-▶ dialog box to enter the password is displayed. The input field for entering the password is at the bottom of the browser. Enter log-in data to the fields of the dialog box – see the figure above; enter password – 4444. (factory pre-set access password to the HMI@Web – for the first start-up.

Figure 35 – Log-in screen



Figure 36 – Password dialog box



Attention – it is only valid until changed.

These log-in data correspond to the highest level user authorization (role: service) – they should only be reserved for the supplier performing the installation or the service provider.

It is advisable to change the log-in data as soon as upon first log-in (Passwords >> Password change – actual or lower access level password change is offered). The dialog box to enter a new password is displayed at the bottom of the browser. Press the Save button to confirm and save the changes to the settings.

Warning

Once the changes have been made, it will no longer be possible to use the original data to log in. Keep your log-in data safely stored (keep them confidential). If you lose them, contact the manufacturer or authorized service representative.

Apart from the service log-in data, it is also necessary to modify other user pre-set log-in data to enable access to the HMI@Web for the operating staff – rename them according to the actual authorised users and change the corresponding passwords:

Role	Pwd	Level number
SERVICE	4444	2
ADMINISTRATOR	3333	4
USER	2222	6
GUEST	0000	8


Note: If the user settings are not performed within this phase of commissioning, it is necessary to perform them at the latest during training of the operating staff or device handover to the end user.

Control (HMI@Web – Connection to PC and LAN/WAN)

4th Step: How to Change the HMI@Web Controller IP Address

The HMI@Web controller IP address for operation in your network can be changed from the following page: Connection >> LAN connection

Figure 37 – LAN connection settings



The lines allowing entries of values are marked with a red button.

Once the button of the respective line has been activated, enter the new value in the dialog box at the bottom of the browser. Press the **Save** button to confirm and save the changes.

Progressively enter and save all the items "Enter ..." (Address, Mask or Gate).

Finally, restart the HMI@Web controller using the option "Apply + Reset". After the restart, the device starts reporting on the new address (once the initiation has been completed – it takes about 3 minutes).** To resume communication (if the network segment has been changed), it may be necessary to readjust the network connection settings on your PC so that they are compatible with the HMI@Web controller (respectively LAN); the HMI@Web controller with the modified setting can be alternatively connected to the LAN. It is necessary to enter the correct network address in the browser to enable log-in.

5th step: LAN Connection Setting Warning

Any changes to the settings must be performed cautiously and carefully at each step. Each modifiable parameter (Address, Mask or Gate) must be carefully checked and saved separately.

Obrazek 38 – password setup for LAN connection



Then it is necessary to send (plan) the change entry – after that, the settings must be finished using the option "Apply + Reset". (Warning: Do not perform the restart by switching off or disconnecting the device – when saving the changes using the "Apply + Reset" option, the settings are simultaneously stored in an archive which is needed for restart of the device after a power supply failure - otherwise, there is a risk of uncontrolled changes to the settings.)

Note: Control start-up after device restart takes several seconds – it does not do anything with the Web Server initiation. That is because of the standard start-up sequences that are being performed during the connected air-handling system start-up, i.e. opening of dampers, pre-heating and fan start. We strongly recommend not using the configuration with the address assigned by the DHCP server; instead, use the fixed IP address.

Warning

If the IP address of the given device happens to get lost (e.g. once the LAN setting have been changed) and it is not possible to establish the connection (no response to the "ping" command, etc.), it is possible to use the HMI-DM or HMI-TM controllers to set the required parameters and restart the device directly.

Note: In extreme cases, the device can be looked up within the network using the MAC address (indicated on the name plate) – contact the network administrator.

Internet Integration


By connecting the WebClima system to the local network via the above-mentioned setting of the IP address and authorization of users, the basic (direct-interactive) monitoring and operating possibilities within the local network or by PC are enabled.

To enable access to the WebClima system via internet, it is necessary to ensure direct access to the device from internet.

Notice: This is necessary especially if supervision (operation, service) outside the company is required.

To connect your HMI@Web unit to the internet, contact your network administrator.

Figure 39 – connection to the WAN network



Control (HMI@Web – Connection to PC and LAN/WAN)

In doing so, we recommend the following:

- Implement the HMI@Web unit into the secured inner network after the router / network firewall. The direct access to the unit must be ensured by further directing.
- To increase security, we recommend locating the device in the reserved network (DMZ) which is not a part of the company's LAN network, or accessing the device via the company's VPN.

Setting the Network Elements to enable HMI@Web Access via Internet

Ask your local network administrator to perform these activities!

The network administrator in this case has at their disposal 2 public static IP addresses for the HMI@Web control unit: 88.100.1.1 and 88.100.1.2

The administrator can set the IP address translation at the router, for example, as follows:

Public IP address	Inner IP address
88.100.1.1	192.168.1.4
88.100.1.2	192.168.1.5

or (to minimize the need for public addresses) leading through only one public IP address and communication port.

Warning to the network administrator

To enable access via internet it is necessary to enable access to the inner IP address via port 80 (http).

Other communication ports must be DISABLED to keep the operation secure!

REMAK does not bear any responsibility for any misuse of the HMI@Web software (Windows CE) or unauthorized penetration of the inner LAN network due to insufficient inner network security.

Internet Browser Settings to operate the HMI@Web controller

Support of JavaScript and cookies must be enabled to ensure correct functioning of the browser interface on each PC connected to the HMI@Web controller. JavaScript is used to update values in the right (information) panel and for programming time schedules, and cookies are used for login. Further, file opening in new windows must also be enabled.

As the parameters are measured on-line, we also recommend adjusting the temporary files retention (cache settings) in the internet browser (this is essential especially for MS Internet Explorer). The browser must verify the actual page version in every access to the page. Otherwise, saved not current values of parameters can be presented. If you have any doubts whether the read data are correct, refresh the page by clicking on the refresh icon on the browser menu bar, or use shortcut keys CTRL+F5 – forced page loading outside cache.

The HMI@Web graphic user interface is optimized for Microsoft Internet Explorer 6.0/7.0 and FireFox 2.0.



Other web browsers' settings must be checked in accordance with the following instructions.

Internet Explorer browser

Internet Explorer JavaScript Support:

Go to the Internet Explorer menu "Tools" / "Internet Options" >> "Security" >> "Custom Level" >> "Scripting" – must be enabled.

Figure 40 – JavaScript support settings




Control (HMI@Web – Connection to PC and LAN/WAN)

Internet Settings (Explorer Cookies):

Go to the Internet Explorer menu "Tools" / "Internet Options" >> "Privacy" >> "Advanced" >> "Accept Cookies" (see fig. # 16)


Figure 41 – Cookies settings (IE)



Temporary Files' Settings


Go to the Internet Explorer menu "Tools" / "Internet Options" >>, "General >> "Temporary Internet files" >> "Settings...".

Figure 42 – Temporary Files' Settings (IE)



In the following window "Setting" >> "Check for newer versions of stored files" >> select "Every visit to the page" >> set "Amount of disk space to use:" to the minimum (8 MB). Then save the settings clicking the "OK" button.

Figure 43 – Temporary Files' Settings (IE)



Mozilla Firefox

Mozilla Firefox JavaScript support

By default, Javascript in Firefox is enabled and no additional installation is required for it.

Cookies settings check in Mozilla Firefox

Cookies are enabled by default.

Other browsers can be set similarly (however, the HMI@Web manufacturer does not guarantee their proper functionality).

Proxy servers

The proxy servers must be disabled if direct connection PC <-> HMI@Web is used.

Disabling proxy servers - Internet Explorer: Go to "Tools" / "Internet Options" >> "Connections" >> "Local network options" >> uncheck the box "Proxy server"

Disabling proxy servers - Firefox: Go to menu "Tools" / "Options" >> ... >> "Expanded" >> bookmark "Network" >> Settings >> check the "Direct network connection".

If access is made within LAN, contact your LAN/PC administrator to perform the settings.

Control (HMI@Web – Connection to PC and LAN/WAN)

HMI@Web Environment Description

The Web controller HMI@Web is controlled using the following buttons:

Button/Icon	Description
	Press: - Go to Main menu from the current page in the menu - Go to the Home Menu page from the Start menu Flashes green - Startup sequence for HVAC Glows green - HVAC Run
	The Info icon icon indicates the access level to which the user is logged in after the correct password; the icon is a link to opt-out from the HMI @ Web menu
	Trouble-free status; the icon is the link to go to the malfunctions page
 <i>Note: glows red</i>	Signaling one or more alarms after a fault has been acknowledged (the bell does not move); the icon is the link to go to the malfunctions page
 <i>Note: flashes red</i>	Signaling a new fault before confirming it (the bell moves); the icon is the link to go to the malfunctions page
	Link to main menu page from anywhere in the menu
	Go back one step, return to the previous page in the menu
	Reload the current page in the menu
 <i>Note: Icon with green tinting</i>	Go to the next page in the menu
 <i>Note: Icon with red tinting</i>	Set value or selection from the menu
	Cancel the newly entered value or parameter selections before her confirmation - remains original value or selection
	Confirm new value or selection from the menu


Basic HMI@Web Operation Settings – Recapitulation

The basic HMI@Web system commissioning settings to prepare it for operating staff:

- Assigning authorization groups to users and their setting before putting the unit into operation (to ensure unit security against unauthorized access).
- System time setting*

Required Settings in Temperature Modes:

Required temperature settings are performed from the page Settings >> Temperature Modes.



Clicking the red ▶ button at the respective temperature you will display a dialog box for a new temperature entering.




Save the new temperature using the **SAVE** button.

To return to the previous page in the menu, click the **CANCEL** button. To go to the Main Menu, click the **HOME** button.

Weekly (Daily) Time Schedule Settings

Weekly time schedule can be set from the page Settings >> Time Modes >> Time Schedule.

An exception time schedule can also be set in the weekly time schedule.



Control (HMI@Web – Connection to PC and LAN/WAN)

An exception time schedule can also be set in the weekly time schedule. It is possible to set maximum 6 time changes and program states for each day of the week. Clicking the red ► button you will display a dialog box at the bottom of the browser window:

Save the new time value using the **SAVE** button. Each time is assigned with a desired program state (fan speed stages and temperature mode). The program state can be entered using the dialog box displayed after clicking the red ► button on the row of the respective program state:

Confirm the new program state using the **SAVE** button.

The time assigned with *:* characters and Stop program state will not be applied. For the detailed description of the time schedule settings, refer to the chapter "Temperature and Time Modes".

SCADA VCS – control (visualization and data collection)

it is a tool that extends the user's ability to control HMI @ Web. SCADA (Supervisory Control and Data Acquisition) "Dispatch Control and Data Collection". SCADA VCS enables above all the comfort and control of the HVAC equipment.

- clear list of failures / history
- visualization of HVAC devices
- Clear schedules and calendar settings
- Tracking HVAC behavior using trends (current / archive)
- includes the HMI @ WEB driver (access to all data points)


The VCS is equipped with a web server running SCADA VCS. Just connect the VCS to the LAN / WAN and then use the Internet browser to connect to the VCS control unit with the SCADA.

The connection is done in the same way as for HMI @ WEB control, part of the manual - Controls (HMI @ Web - connection and installation to PC and LAN / WAN).

Login credentials for access verification to the SCADA server:

user name: WEB
password: SBTAdmin!

This tool will be appreciated by service and assembly companies to regulate the operation of HVAC equipment. Users will quickly orient themselves in the HVAC device assembly and appreciate the ease of setting user parameters.



* HMI@Web controller automatically switches between summer and winter time according to European customs.

List of Data Points (HMI-DM, HMI-TM and HMI@WEB controllers)

Menu		Meaning		Factory settings			
				Value	Min	Max	Units
Monitor							
Current modes		Monitor					
ActStateEquipment		Current modes					
FanStageExtCnt		Current device state					
FanStatus		Fan output stage (external control)					
Actual time schedule		Fan state					
	CalendarWeek	Current time schedule					
	CalendarExcept	Weekly time schedule					
	CalendarOff	Exception time schedule					
		Switch-off time schedule					
		Current number of failures					
Temperatures		Temperatures					
Supply		Inlet air temperature					°C
Room		Room temperature					°C
Room unit 1		Temperature (HMI-SG1)					°C
Room unit 2		Temperature (HMI-SG2)					°C
Return air		Outlet air temperature					°C
Outdoor		Outdoor air temperature					°C
Return water heat		Return water temperature from the water heater					°C
Air heat exchanger		Outlet air temperature behind the heat exchanger					°C
Air electric preheat		Temperature behind the electric pre-heater					°C
ReturnWaterPreheating		Return water temperature from the water pre-heater					°C
ExtraElectricHeating		Temperature behind the electric after-heater					°C
Flue gas		Flue gas temperature					°C
ValidRegulationRoom		Room temperature (for control)					°C
Humidity		Humidity					
Supply air relative		Inlet - relative					%r.H.
Supply air absolut		Outlet - absolute					g/kg
Supply air enthalpy		Inlet - enthalpy					kJ/kg
Room relative		Room - relative					%r.H.
Room absolut		Room - absolute					g/kg
Room enthalpy		Room - enthalpy					kJ/kg
Outs air relative		Outdoor - relative					%r.H.
Outs air absolut		Outdoor - absolute					g/kg
Outs air enthalpy		Outdoor - enthalpy					kJ/kg
Flow (Pressures)		Flow (Pressures)					
SupplyPress		SupplyPress					Pa
ReturnPress		ReturnPress					Pa
SupplyFlow		SupplyFlow					m3/h
ReturnFlow		ReturnFlow					m3/h
Air quality		Air quality					
	CO2 (VOC,CO)			CO2 (VOC, CO)			ppm
Outputs		Performances					
Fan supply output		Inlet fan output					%
Fan exhaust output		Outlet fan output					%
Fan additional output		Auxiliary fan output					%
ExtraElectricalHtgPos		Outlet level for the electric reheater					%
Heating valve		Heating mixing set valve position					%
Cooling valve		Cooling valve position					%
Cooling 2		Cooling valve position 2					%
Cooling 3		Cooling valve position 3					%
Electrical preheating		Electric pre-heater outlet position					%
ElectricalHeatingValve		Electric reheater outlet position					%
Heat pump output		Heat pump outlet position					%
Heat Pump 2		Heat pump outlet position 2					%
Heat Pump 3		Heat pump outlet position 3					%
Mixing section position		Heat pump outlet position 2					%
Heat exchanger position		Heat pump outlet position 3					%
Gas heating out level		Outlet position to the mixing damper					%
BypassDamperPosition		Heat exchanger control outlet position					%
Request humidity		Outlet level for the gas heater					%
Request dehumidity		Outlet position for gas heater's BP damper					%
		Request for humidification					%
		Request for dehumidification					%
Working states		Operating states					
FanSupplyStatus		Inlet fan state					
FanExhaustStatus		Outlet fan state					
FanAdditionalStatus		Auxiliary fan state					
ElectPreheat		Electric pre-heater state					
WaterPreheat		Water pre-heater pump state					
ElectReheating		Electric re-heater state					
PumpOfWaterHeating		Pump of water heating					
StateHeatExchanger		Rotary exchanger State					
PrehtgFunctionsWaterHtg		Pre-heating functions (water heating)					
WaterCoolPump		Water cooler pump state					
CoolingStDXCool		Cooling stage (2S)					
CoolInverter		Cooling stage (inverter)					
ChlaziInverter 2		Cooling stage (inverter) 2					
ChlaziInverter 3		Cooling stage (inverter) 3					
CoolStep		Cooling stage (1 St + inverter)					
HeatPump		Heat pump state					
ElectricHeater		Electric heater state					
GasHeater		Gas heater state					

List of Data Points (HMI-DM, HMI-TM and HMI@WEB controllers)

Menu HMI-DM, HMI-TM a HMI@WEB						
Settings	Menu	Meaning	Factory settings			
			Value	Min	Max	Units
	StateHumidifier	Humidifier state				%
		Settings				
			Date and time			
	Date and Time	System time validity				
	TimeValidity	Temperature modes				
		Comfortable heating	22.6	0	99	°C
		Comfortable cooling	24.6	0	99	°C
		Economy heating	20.6	0	99	°C
		Economy cooling	28	0	99	°C
		Extra required inlet air temperature	20	0	99	°C
		Manual mode				
		Time modes				
		Weekly time schedule				
		Exception time schedule				
		Switch-off time schedule				
		Humidity control				
	DehumSpvRel	Dehumidification required relative value	60	0	100	%r.H.
	DehumSpvAbs	Dehumidification required absolute value	12	0	100	g/kg
	HumMaxSpv	Maximum humidity required value	80	0	100	%r.H.
	ActualValueHum	Current humidity value				
	ActCascSpvDeh	Calculated current dehumidification required value in cascade control				
	HumMaxCtrl	Maximum humidity				%
	HumidityCtrl	Humidification output				
	DeHumidityCtrl	Dehumidification output				%
	Dewpoint	Dew point current value				°C
	DewpointDedZone	Dew point deviation	1	-64	64	°C
		Fans				
	RegulFans-Flow(Press)	RegulFans-Flow(Press)				
		SupplyPrsRangeSnsr				
		ReturnPrsRangeSnsr				
		SupplyFlowRangeSnsr				
		ReturnFlowRangeSnsr				
		SupplyKFactor				
		ReturnKFactor				
		NmbrOfSplyFans				
		NmbrOfRtrnFans				
		Enable - K Factor				
	FanSupplyOutputSetpointVal	Inlet fan output				
		Output settings St1				
		Output settings St2				
		Output settings St3				
		Output settings St4				
		Output settings St5				
	FanExhaustOutputSetpointVal	Outlet fan output				
		Output settings St1				
		Output settings St2				
		Output settings St3				
		Output settings St4				
		Output settings St5				
	FanAddOutputSetpointVal	Additional fan output				
		Output settings St1				
		Output settings St2				
		Output settings St3				
		Output settings St4				
		Output settings St5				
	TRN Correct	Outlet fan speed TRN correction				
		For all stages				
		ValueOfCorrection				
		FanOutputSt1				
		FanOutputSt2				
		FanOutputSt3				
		FanOutputSt4				
		FanOutputSt5				
	Back-up supply fan	Single-speed inlet fan backup				
		Failure flow evaluation time-out after main fan start-up	180	0	9999	s
		Failure flow evaluation time-out after backup fan start-up	180	0	9999	s
		Active main fan backup				
	Back-up exhaust fan	Single-speed outlet fan backup				
		Failure flow evaluation time-out after main fan start-up	180	0	9999	s
		Failure flow evaluation time-out after backup fan start-up	180	0	9999	s
		Active main fan backup				
	Fan run-out to DEW	Fan run-out according to DEV				
		Enable run-out				
		Blocking by the MIN outdoor temperature	-15	-64	64	°C
		Blocking by the MAX outdoor temperature	5	-64	64	°C
		Fan run-out	5	1	60	min
	Fan run-out	Fan run-out	180	0	9999	s
	MinStOnTimeTrans	Time transition to 2St speed - two-speed fans	15	0	999	s

List of Data Points (HMI-DM, HMI-TM and HMI@WEB controllers)

Menu HMI-DM, HMI-TM a HMI@WEB					
Menu	Meaning	Factory settings			
		Value	Min	Max	Units
RoundownTmTrans	Time transition to 1St speed - two-speed fans	12	0	99	s
BlickHighSpeedFan	Outdoor temperature-dependent fan speed interlocking	-60	-64	64	°C
ForceStrtTmOn1St	Forced fan start-up to 1St speed (TRN - damper output absent)	20	0	99	°C
DelayStartFan	Fan start-up delay (after damper)	20	0	9999	s
FanRunDwn	Fan run-out	180	0	9999	s
FlowActDelayStrtErr	Failure flow activation delay (at fan start-up)	45	0	600	s
FlowActDelayRunErr	Failure flow activation delay (during fan run)	5	0	600	s
TherContActDelayTmErr	Thermo-contact (TK) failure activation delay (fans)	2	0	600	s
FreqInvActSetDelayTmErr	Frequency inverter failure activation delay	2	0	600	s
Control Parameters	Control parameters				
ValueOfTemperatureRegulation	Temperature control values				
MaxDevRmSplyTemp	Maximum difference between room and inlet temperatures	5	0	64	°C
MinDevRmSplyTemp	Min. difference between room and inlet temperatures	5	0	64	°C
ActCascSpvHeating	Calculated required temperature for heating with cascade control				°C
ActCascSpvCooling	Calculated required temperature for cooling with cascade control				°C
ActMainSpvHeating	Calculated required temperature for heating				°C
ActMainSpvCooling	Calculated required temperature for cooling				°C
ActualTempControlMode	Current temperature-dependent control (inlet, room, outlet)				
SplyTempLimitation	Inlet temperature limitation				
SplyMinLimit	Minimum inlet air temperature	15	0	64	°C
SplyMaxLimit	Maximum inlet air temperature	35	0	64	°C
Sequences	Sequence				
WaterHtgWithFunctionPreHtg	Water heating with pre-heating function				
PmpStrtOutTmP	Outdoor temperature-dependent pump start-up in the AHU Stop and Run mode	5	-64	64	°C
PmpMinRunTime	Minimum pump run time	180	0	9999	s
PmpKickTm	Pump downtime to the pump turning activation	168	0	9999	h
PmpKickTmOn	Active pump turning time	60	0	9999	s
PreHtgTm	Active water pre-heating operation time	120	0	600	s
PreHtgTmOff	Function blocking time between AHU unit shut-down and restart	5	0	30	min
PreHtgEquCurX1	Water heater circuit heating curve setting at the AHU start-up X1	-10	-30	5	°C
PreHtgEquCurY1	Water heater circuit heating curve setting at the AHU start-up Y1 (%)	100	0	100	%
PreHtgEquCurX2	Water heater circuit heating curve setting at the AHU start-up X2	10	0	50	°C
PreHtgEquCurY2	Water heater circuit heating curve setting at the AHU start-up Y2 (%)	10	0	100	%
StrtDelaySwchAntiFreeze	Stop to Run mode switching delay AP trigger value	60	0	600	s
StrtAntiFreezeInRun	Water heat exchanger dependent AP trigger value - AHU in Run mode	15	0	50	°C
StrtAntiFreezeInStop	Water heat exchanger dependent AP trigger value - AHU in Stop mode	30	0	50	°C
DlyEvalSplyAntiFreeze	Inlet air dependent AP evaluation enabling delay after the unit start-up	60	0	600	s
StrtSplyAntiFreezeAlma	Inlet air temperature dependent AP start-up - failure alarm A	6	-64	64	°C
StrtSplyAntiFreeze	Inlet air temperature dependent AP start-up	8	-64	64	°C
MaxTempReturnWater	Maximum return water temperature	70	20	120	°C
Electric heating	Electric Heating				
ActiveElectricalHtg	Electric heating switching on - request for heating	20	0	100	%
HystOffElectricalHtg	Electric heating hysteresis	10	1	100	%
Gas heating	Gas heating				
EnableSequenceCool	Cooling sequence enabling				
MinOnTime	Minimum burner run time	150	0	600	s
MinOffTime	Minimum burner downtime	150	0	600	s
BlickTmAgainStrt1StBurner	Burner restart protection time (burner Stage 1)	150	0	600	s
RampModulationBurner	Modulation burner opening/closing speed (%/s) (burner Stage 1)	5	0	20	%/s
MinLoadOff2StBurner	Heating request value for the burner Stage 2 switch-off (%)	40	10	100	%
SetPointAlarmTmFlueGas	Maximum flue-gas alarm temperature	230	210	400	°C
MaxTempFlueGas	Maximum flue-gas temperature	210	160	230	°C
SetPointTempFlueGas	Requested flue-gas temperature	160	150	210	°C
MinTmFlueGas	Minimum flue-gas temperature	150	150	160	°C
Electrical preheating	Electric pre-heating				
SetPointPreHtgTmP	Required temperature for pre-heating	-20	-50	10	°C
BlickEIPreHtgOutTmP	Outdoor dependent electric pre-heating blocking	-30	-50	10	°C
ActiveEIPreHtg	Heating request-dependent electric pre-heating switch-on	20	0	100	%
HystOffPreHtg	Hysteresis for electric pre-heater switch-off	10	0	100	%
Water preheating	Water pre-heating				
PreHeatPumpStpt	Outdoor dependent pre-heating (pump) start-up	5	-50	15	°C
PmpKickTm	Pump downtime to the pump turning activation	168	0	9999	h
PmpKickTmOn	Active pump turning time	30	0	9999	s
PmpMinRunTime	Minimum pump run time	30	0	9999	s
Extra electrical heating	Electric reheating				
St1 heating request dependent electric re-heating start-up	St1 heating request dependent electric re-heating start-up	20	0	100	%
HystOffExtraElHeating	Hysteresis for electric re-heating switch-off	10	1	100	%
MaxPowExtraHtgForFanSt1	Fan St1 dependent outlet limitation	100	0	100	%
MaxPowExtraHtgForFanSt2	Fan St2 dependent outlet limitation	100	0	100	%
MaxPowExtraHtgForFanSt3	Fan St3 dependent outlet limitation	100	0	100	%
MaxPowExtraHtgForFanSt4	Fan St4 dependent outlet limitation	100	0	100	%
MaxPowExtraHtgForFanSt5	Fan St5 dependent outlet limitation	100	0	100	%
Heat Pump, H, Heat Pump 2, Heat Pump 3					
HeatPump - heating	Heat pump - heating				
StptBlickOutTmP	Outdoor temperature dependent heat pump blocking	5	-45	35	°C
StpthysOutTmP	Temp. hysteresis for outdoor temperature dependent heat pump unblocking	3	1	10	°C

List of Data Points (HMI-DM, HMI-TM and HMI@WEB controllers)

Menu HMI-DM, HMI-TM a HMI@WEB						
Menu	Meaning	Factory settings				
		Value	Min	Max	Units	
	MinRunTm	60	0	9999	s	
	BkckTmAgainStrt	120	5	600	s	
	ActiveHeatPump	20	0	100	%	
	HysOffHeatPump	10	1	100	%	
HeatPump - cooling	AlarmFromOutTmP	Information - outdoor temperature dependent heat pump heating blocking				
	StartAnalogVal	30	0	50	%	
		Heat pump - cooling				
	StptBkckOutTmP	14	-45	35	°C	
	StpthysOutTmP	3	1	10	°C	
	MinRunTm	60	0	9999	s	
	BkckTmAgainStrt	120	5	600	s	
	ActiveHeatPump	20	0	100	%	
	HysOffHeatPump	10	1	100	%	
	AlarmFromOutTmP	Information - outdoor temperature dependent heat pump cooling blocking				
StartAnalogVal	30	0	50	%		
HeatPump - special		HeatPump - special				
	Invert signal heating	Signal inversion - HeatPump heating mode				
	Invert signal cooling	Signal inversion - HeatPump cooling mode				
	DaikinSpec0-10V	0-10V special signal switching (Daikin)				
	DifferSt1-St2SigDaikin	40	0	100	%	
	ChangeTimeToMaxSigDaikin	120	0	500	s	
	StartAnalogVal	30	0	50	%	
Heat recovery		Heat recovery				
	HeatExFreeZAlarm	1	-64	64	°C	
	HeatExTmPMaxSpeed	15	-64	64	°C	
	HeatExTmMaxSpeed	60	0	600	s	
	SetStartRequestHeatEx	38	0	100	%	
	SetHysHeatEx	5	0	100	%	
	InfoStrtAntiFreez	Information - antifreeze protection start-up				
Mixing		Mixing				
	MinFreshAir	20	0	100	%	
	MinFreshAir - Comfort	20	0	100	%	
	MinFreshAir - Economy (pool unit)	20	0	100	%	
	MixDampTempFullOp	15	-64	64	°C	
	MixDampTmFullOp	60	0	600	s	
	ValueOfMixing	100	0	100	%	
	ActMaxFrsHrAirLim	Information about the Max. limit of fresh air activation (vent. unit)				
	MaxFrsHrAir	Max. limit of fresh air according to T outdoor (vent. unit)				
	ToutActMaxFrsHrAir	T outdoor from which the Max. limit of fresh air is activated (vent. unit)				
Cooling		Cooling				
	CigBkckOutTmP	12	-64	64	°C	
	MinRunTmPump	180	0	9999	s	
	PmpKickTm	168	0	9999	h	
	PmpKickTmOn	60	0	9999	s	
	MinRunTm1StDXClg	60	0	9999	s	
	BkckTmAgainStrtDXCool	120	5	600	s	
	TmRemainIn1StDXCool	360	5	600	s	
	DXCoolStage1On	20	0	100	%	
	DXCoolStage2On	70	0	100	%	
	DXCoolHysOffSt2	10	0	20	%	
	MinRunTmInverter	10	0	9999	s	
	BkckTmAgainDXCool-Inv	60	0	300	s	
	Cooling signal inversion	Signal Inversion for Heat Cooling Pump				
	OmezDvHlkPrst	65	0	100	%	
		Cooling limited by room air humidity				
	Cooling 2	NastBlokOdVenkTep	12	-64	64	°C
		MinDobaProvCerpadia	180	0	9999	s
		Inverze signal chlazeni	Signal Inversion for Heat Cooling Pump			
	Cooling 3	NastBlokOdVenkTep	12	-64	64	°C
MinDobaProvCerpadia		180	0	9999	s	
Cooling signal inversion		Signal Inversion for Heat Pump Cooling				
Compensation	DemandHtg	Heating Water Source Switching				
	StpTmDemandHtg	15	5	25	°C	
	StpDlyStrtSeq	120	10	600	s	
	RequestTemperatur	Required temperature compensation				
	CigCompStart	25	-64	64	°C	
	CigCompEnd	35	-64	64	°C	
	MaxValCompCig	2	-64	64	dK	
	ActShiftReqTempCig	0	-64	64	°C	
	CompHStart	0	-64	64	°C	
	CompHEnd	-20	-64	64	°C	
MaxCompHtg	-1	-64	64	dK		
ActShiftReqTempHtg	-64	-64	64	°C		
FanCompensation	OutTemperature	Outdoor temperature-dependent fan speed compensation				
	CigCompStart	25	-64	64	°C	
	CigCompEnd	30	-64	64	°C	
	MaxValCompStgCig	0	-100	100	%	
	ActValComStgFanCig	0	-100	100	%	
	CompHStart	5	-64	64	°C	
		Heating initial point (outdoor temperature)				

List of Data Points (HMI-DM, HMI-TM and HMI@WEB controllers)

Menu HMI-DM, HMI-TM a HMI@WEB						
Menu	Meaning	Factory settings				
		Value	Min	Max	Units	
FanCompensationRoomExhaustTmp	CompHEnd	Heating end point (outdoor temperature)	-20	-64	64	°C
	MaxValCompStgHtg	Maximum heating compensation (speed)	0	-100	100	%
	ActValCompStgFanHtg	Current heating speed compensation	0	-100	100	%
FanCompensationSequenceHtg	Room (Outlet) Temperature-Dependent Fan Speed Compensation	Room (Outlet) Temperature-Dependent Fan Speed Compensation				
	Compensation function setting	Compensation function setting				
	Required room temperature	Required room temperature	20	0	99	°C
FanCompensationSequenceClg	Actual compensation	Actual compensation				
	Heating dependent fan speed compensation	Heating dependent fan speed compensation				
	Heating temperature hysteresis (°C)	Heating temperature hysteresis (°C)	1	0	20	°C
Compensation air quality	Heating compensation display (%)	Heating compensation display (%)				
	Cooling dependent fan speed compensation	Cooling dependent fan speed compensation				
	Cooling temperature hysteresis (°C)	Cooling temperature hysteresis (°C)	1	0	20	°C
Humidity fan compensation	Cooling compensation display (%)	Cooling compensation display (%)				
	Air quality dependent compensation (damper position/fan speed)	Air quality dependent compensation (damper position/fan speed)				
	Compensation function setting (according to the sensor characteristics)	Compensation function setting (according to the sensor characteristics)				
Humidity hrec Damp compensat	Required (allowable) value of the CO ₂ , VOC, (CO) concentration	Required (allowable) value of the CO ₂ , VOC, (CO) concentration	800(50)	0	3000	ppm
	CO ₂ , VOC, (CO) sensor range setting	CO ₂ , VOC, (CO) sensor range setting	2000(300)	0	3000	ppm
	CO ₂ , VOC (CO) compensation rate display, %	CO ₂ , VOC (CO) compensation rate display, %				%
TemperatureStart	Humidity-dependent fan speed compensation	Humidity-dependent fan speed compensation				
	Humidity required value for compensation	Humidity required value for compensation	50	0	100	%r.H.
	Fan speed compensation function	Fan speed compensation function				
Night Cooling	Compensation display	Compensation display				%
	Humidity-dependent mixing damper compensation	Humidity-dependent mixing damper compensation				
	Fan speed compensation function	Fan speed compensation function				
Boost	Compensation display	Compensation display				%
	Optimized start	Optimized start				
	Pre-set interval before time program start-up	Pre-set interval before time program start-up	60	0	999	min
Night kick	Required room temperature - inlet-dependent control	Required room temperature - inlet-dependent control	22	-64	64	°C
	Temperature hysteresis	Temperature hysteresis	3	0	64	°C
	Minimum outdoor temperature setting	Minimum outdoor temperature setting	12	-64	64	°C
AntiFreezeRetWatHeat	Outdoor temperature and room temperature difference	Outdoor temperature and room temperature difference	5	1	64	°C
	Minimum operating time	Minimum operating time	30	0	999	min
	Required room temperature, inlet-dependent control	Required room temperature, inlet-dependent control	22	-64	64	°C
SetpointTempWaterHeating	Temperature hysteresis	Temperature hysteresis	3	0	64	°C
	Required room temperature - inlet-dependent control	Required room temperature - inlet-dependent control	20	-64	64	°C
	Temperature hysteresis	Temperature hysteresis	0.5	-64	64	°C
Electrical heating	Required temperature for heating	Required temperature for heating	25	-64	64	°C
	Required cooling temperature	Required cooling temperature	15	-64	64	°C
	Night turning	Night turning				
Bypass damper	Turning time	Turning time				
	Time to next turning (h)	Time to next turning (h)	3	0	9999	h
	Active turning time (s)	Active turning time (s)	300	0	9999	s
PropFactor	Control constants	Control constants				
	Proportional factor	Proportional factor	10			
	Integrating factor	Integrating factor	1200			s
IntegFactor	Derivative factor	Derivative factor	20			
	Return water AP factors	Return water AP factors				
	Proportional factor	Proportional factor	90			s
DifferFactor	Integrating factor	Integrating factor	0			s
	Derivative factor	Derivative factor	0			s
	Inlet air AP factors	Inlet air AP factors				
AntiFreezeSplyTemp	Proportional factor	Proportional factor	50			
	Integrating factor	Integrating factor	0			s
	Derivative factor	Derivative factor	0			s
MaxRetWatHeat	Maximum return water temperature factors	Maximum return water temperature factors				
	Proportional factor	Proportional factor	-3			
	Integrating factor	Integrating factor	300			s
PropFactor	Derivative factor	Derivative factor	0			s
	Water heating required temperature factors	Water heating required temperature factors				
	Proportional factor	Proportional factor	5			
IntegFactor	Integrating factor	Integrating factor	150			s
	Derivative factor	Derivative factor	0			s
	Electric heating factors	Electric heating factors				
DifferFactor	Proportional factor	Proportional factor	5			
	Integrating factor	Integrating factor	120			s
	Derivative factor	Derivative factor	0			s
BurnerFactors	Gas burner factors	Gas burner factors				
	Proportional factor	Proportional factor	5			
	Integrating factor	Integrating factor	60			s
PropFactor	Derivative factor	Derivative factor	0			s
	Gas heater bypass damper factors	Gas heater bypass damper factors				
	Proportional factor	Proportional factor	-5			
IntegFactor	Integrating factor	Integrating factor	120			s
	Derivative factor	Derivative factor	0			

List of Data Points (HMI-DM, HMI-TM and HMI@WEB controllers)

Menu HMI-DM, HMI-TM a HMI@WEB					
Menu	Meaning	Factory settings			
		Value	Min	Max	Units
GasHeatingMaximalTempFlueGas	Maximum temperature of flue gas				
	Proportional factor	10			
	Integrating factor	120			s
GasHeatingMinimumTempFlueGas	Derivative factor	0			s
	Minimum temperature of flue gas				
	Proportional factor	-10			
Electrical preheating	Integrating factor	120			s
	Derivative factor	0			s
	Electric pre-heating factors				
Extra electrical heating	Proportional factor	5			
	Integrating factor	120			s
	Derivative factor	0			s
Heat pump - heating	Electric after-heating factors				
	Proportional factor	1			
	Integrating factor	60			s
Heat pump - cooling	Derivative factor	0			s
	Heat pump factors - heating				
	Proportional factor	5			
Heat pump 2 - heating	Integrating factor	300			s
	Derivative factor	0			s
	Heat pump factors - cooling				
Heat pump 2 - cooling	Proportional factor	-5			
	Integrating factor	300			s
	Derivative factor	0			s
Heat pump 3 - heating	Heat pump factors 2 - heating				
	Proportional factor	5			
	Integrating factor	300			s
Heat pump 3 - cooling	Derivative factor	0			s
	Heat pump factors 2 - cooling				
	Proportional factor	-5			
Heat recovery	Integrating factor	300			s
	Derivative factor	0			s
	Heat recovery RHE/BP PE				
Heat exchanger freeze	Proportional factor	3			
	Integrating factor	60			s
	Derivative factor	1			s
Mixing	Heat recovery AP factors				
	Proportional factor	-20			
	Integrating factor	150			s
Cooling	Derivative factor	0			s
	Mixing factors				
	Proportional factor	7			
Humidification	Integrating factor	45			s
	Derivative factor	15			s
	Cooling factors				
Dehumidity	Proportional factor	-5			
	Integrating factor	60			s
	Derivative factor	0			s
Humidity cascade	Humidification factors				
	Proportional factor	5			
	Integrating factor	120			s
FanCompensationSequenceHtg	Derivative factor	0			s
	Dehumidification factors				
	Proportional factor	-2			
FanCompensationSequenceClg	Integrating factor	240			s
	Derivative factor	0			s
	Humidity cascade control factors				
FanCompensationRoomExhaustTmp	Proportional factor	4			
	Integrating factor	0			s
	Derivative factor	0			s
FanCompensationHumidity	Heating-dependent fan speed compensation factors				
	Proportional factor	5			
	Integrating factor	120			s
FanCompensationRoomExhaustTmp	Derivative factor	0			s
	Cooling-dependent fan speed compensation factors				
	Proportional factor	-10			
FanCompensationHumidity	Integrating factor	120			s
	Derivative factor	0			s
	Room (outlet) temperature-dependent fan speed compensation factors				
FanCompensationHumidity	Proportional factor	20			
	Integrating factor	0			s
	Derivative factor	0			s
FanCompensationHumidity	Humidity-dependent fan speed compensation factors				

List of Data Points (HMI-DM, HMI-TM and HMI@WEB controllers)

Menu HMI-DM, HMI-TM a HMI@WEB					
Menu	Meaning	Factory settings			
		Value	Min	Max	Units
	Proportional factor	-5			
	Integrating factor	0			s
	Derivative factor	0			s
HrecDampCompHumidity	Humidity-dependent mixing damper position compensation factors				
	Proportional factor	-2			
	Integrating factor	45			s
	Derivative factor	0			s
CompensationAirQuality	Air quality CO2(VOC,CO)-dependent compensation (damper position/fan speed) factors				
	Proportional factor	-0.3			
	Integrating factor	300			s
	Derivative factor	0			s
SplyFanVarCtrl	SplyFanVarCtrl				
	PropFactor	-0.3			
	IntegFactor	30			s
	DifferFactor	0			s
ExhFanVarCtrl	ExhFanVarCtrl				
	PropFactor	-0.3			
	IntegFactor	30			s
	DifferFactor	0			s
Device configuration	Device configuration				
Application info	Application information				
Device Info	Device information				
	Unit °C → °F				
	Version OS				
	InternTempRegulator				
	Operating Hours				
	Type of device				
Inputs configuration	Inputs configuration				
	HeatPumpAlm				
	Cooling alarm				
Output configuration	Output configuration				
	Signal type heating				
	Signal type cooling				
	Signal type mix damper				
	SignalTypByPassHeatRec				
	SignalTypeByPassBurn				
RegulationSupplyFan	Type of regulation supply fan				
RegulationExhaustFan	Type of regulation exhaust fan				
RegulationAdditionalFan	Type of regulation additional fan				
Heating	Heating				
Heat pump	Heat pump				
Gas heat type	Type of gas heating				
GasHeaterByPassDamp	Bypass damper gas heater				
Cooling	Cooling				
Heat recovery	Heat recovery				
Mixing	Mixing				
Preheating	Preheating				
Extra heating	Extra heating				
TemperatControlMode	Temperature control mode				
HumidityControlMode	Humidity control mode				
RemoteFault-ClassFault	Remote fault - choice class fault				
Version SW-HMI	SW-HMI version				
AdditionalOperModeAndFunction	Additional operating modes, functions				
TemperatureMeasurePointSelect	Room temperature measuring point selection				
FanCompensationOutTemperature	Outdoor Temperature-Dependent Fan Speed Compensation				
Fan compensation sequence	Heating/cooling dependent fan speed compensation				
Fan compensation air quality	Air quality-dependent fan speed compensation				
FanCompensationRoomExhaustTmp	Room (outlet) temperature-dependent fan speed compensation				
Temperature deviation alarm	Difference between required and actual temperature monitoring				
AntiFreezeDEV	DEV Water Heater Antifreeze Protection Variant				
HeatRecoveryCompensationAirQ	Air quality-dependent damper position compensation				
Heat recovery cooling	Cooling using ZZT (ROV, BP, DEV, mixing damper)				
	Heating/cooling dependent fan speed compensation-cooling sequence (fan, cooler)				
Fan cooling sequence					
HeatRecovery-DamperSequence	Mixing heating sequence (damper, heater)				
Night cooling	Night chilling				
Temperature start-up	Temperature start-up				
Boost	Time mode start optimization				
BlockedDamper-AndExhaustFan	Damper and outlet fan blocking				
Type correct TRN exhaust fan	Outlet fan correction type (TRN controllers)				
LimitationDehumidificationForHeating	Limitation of dehumidification during heating				
Humidity fan compensation	Humidity-dependent fan speed compensation				
Humidity HrecDampCompensation	Humidity-dependent mixing damper position compensation				

List of Data Points (HMI-DM, HMI-TM and HMI@WEB controllers)

	ActiveMaxFrshAirDHrec		Function activation - Max. limit of fresh air according to T outdoor (vent. unit)					
	Apply - Reset		Reset after configuration of additional modes/functions					
HMI-SG	DisplayedRoomTemp		HMI-SG					
	SetpointRangeCorr		Room temperature display, combined or inlet temperature					
	SetpointIncrement		Required value compensation setting +/-	3	0	12	°C	
	TimeFormat		Required temperature increment setting (0.5/0.1) (°C)	0.1	0.1	0.5	°C	
External Control			Displayed time format (12h/24h)	24	12	24	h	
	ToggFuncInp1		External control					
	DelayOfTmToAUTO		External contact function definition (Ext. control 1 contact)					
	FanOutputStg1		Transition time from ext. control mode to AUTO mode (Ext. control 1 contact)	0	0	23	h	
	FanOutputStg2		Fan output stage setting (Ext. control 1 contact or 2 contacts)					
	TmpMod1		Fan output stage setting "Higher" (Ext. control 2 contacts)					
	TmpMod2		Temperature mode setting (Ext. control 1 contact or 2 contacts)					
	FanStageExtCnt		Temperature mode setting "Higher" (Ext. control 2 contacts)					
Identification device			Fan output stages (external control)					
	Name of device		Device identification					
	Number of devices		Equipment name					
	Location of the installation		Device number					
Checks			Device location					
	Save / Restore		Checks					
	UpgradeStart		Saving and recovery					
	SaveDataOnSDCard		Application loading from SD card					
	SaveDataFromSDCard		Data saving to SD card					
	RestoreFactorySetting		Factory loading from SD card					
	Restore settings		Factory settings recovery					
	Save settings		Settings recovery					
Operating hours			Save settings					
	Supply fan		Operating hours					
	Exhaust fan		Operating hour counter - inlet fan					
	Additional fan		Operating hour counter - outlet fan					
	Operating hours settings fans		Operating hour counter - 3rd auxiliary fan					
		OperationHoursAlm	Fan operating hours settings					
		EnbOperHoursAlm	Fan operating hour alarm state					
		OperHoursLimit	Alarm enable fan operating hour	17520	0	99999	h	
	Water preheating		Operating hours for alarm activation					
	ElectricPreheating		Operating hour counter - water pre-heating					
	Heating water		Operating hour counter - electric pre-heating					
	Electrical heating		Operating hour counter - water heating					
	Cooling water		Operating hour counter - electric heating					
	CoolingCondensUnit		Operating hour counter - water cooling					
	ChlazKond.Jednotka 2		Operating hour counter - condensing unit					
	ChlazKond.Jednotka 3		Operating hour counter - condensing unit 2					
	ExtraElectricalHtg		Operating hour counter - condensing unit 3					
	TepCerpadlo-ohfев		Operating hour counter - electric after-heating					
	TepCerpadlo-chlaz		Operating hour counter - Heating Pump - heating					
	TepCerpadlo2-ohfев		Operating hour counter - Heating Pump - cooling					
	TepCerpadlo2-chlaz		Operating hour counter - Heating Pump 2 - heating					
	TepCerpadlo3-ohfев		Operating hour counter - Heating Pump 2 - cooling					
	TepCerpadlo3-chlaz		Operating hour counter - Heating Pump 3 - heating					
			Operating hour counter - Heating Pump 3 - cooling					
SetpointAndSupplyTmpDeviation			Difference between required and inlet air temperature monitoring.					
	MaxDeviation		Maximum difference (±°C)	10	0	99	°C	
	MinLimit		Minimum limit (°C)	10	0	99	°C	
	DlyOnTmEvalAfterStart		Time delay evaluation after AHU start-up (s)	60	0	9999	s	
SetpointAndRoomTmpDeviation			Difference between required and room (outlet) air temperature monitoring.					
	MaxDeviation		Maximum difference (±°C)	10	0	99	°C	
	MinLimit		Minimum limit (°C)	10	0	99	°C	
	DlyOnTmEvalAfterStart		Time delay evaluation after AHU start-up (s)	600	0	9999	s	
FireAlarmActivityFans			Fan behaviour during fire alarm					
FireAlarmFansOutSpv			Fan output during fire alarm	80	0	100	%	
SplyTmpFireLmt			Fire alarm activation inlet temperature	70	0	99	°C	
ExhstTmpFireLmt			Fire alarm activation outlet temperature	50	0	99	°C	
Connection			Connection					
Modbus Master			ModbusMaster					
	AdrFreqInv1SplyFan		Frequency inverter 1 address, inlet fan	1				
	AdrFreqInv2SplyFan		Frequency inverter 2 address, inlet fan backup or second inlet fan	2				
	AdrFreqInv3SplyFan		Frequency inverter 3 address, inlet fan twin backup	3				
	AdrFreqInv4SplyFan		Frequency inverter 4 address, inlet fan twin backup	4				
	AdrFreqInv5ExhFan		Frequency inverter 5 address, outlet fan	5				
	AdrFreqInv6ExhFan		Frequency inverter 6 address, outlet fan backup or second outlet fan	6				
	AdrFreqInv7ExhFan		Frequency inverter 7 address, outlet fan twin backup	7				
	AdrFreqInv8ExhFan		Frequency inverter 8 address, outlet fan twin backup	8				
	AdrFreqInv9AddrFirst		Frequency inverter 9 address, 3rd auxiliary fan	9				
	AdrFreqInv10AddrSec		Frequency inverter 10 address, second 3rd auxiliary fan	10				
	AdrFreqInv11RotHeatExch		Frequency inverter 11 address, rotary heat exchanger	11				
	ResistiveTerminatBus		Control unit Modbus resistance terminal					
	NumberRepeatErrMess		Number of message repeating during error transfers	2				
	NumberOfErrMess		Number of error transfers for communication failure evaluation	6				
LAN Connection			LAN connection					
	DHCP		DHCP					
	ActIPAddr		Current IP address					
	ActMaskAddr		Current mask address					

List of Data Points (HMI-DM, HMI-TM and HMI@WEB controllers)

	ActGatewayAdr		Current gate address				
	GivenIPAdr		IP address input				
	GivenMaskAdr		Mask address input				
	GivenGateAdr		Gate address input				
	HostName		Host name				
	MACAddress		MAC address				
	Web user name		HMI@WEB user name:				
	Apply-Reset		HMI@WEB password				
LON			Apply-Reset				
	OutTmpCommunicat		LON				
	ExtAlarmCommunicat		Outdoor temperature from the bus				
Modbus - CommModul			External failure form the bus				
LON - CommModul			Modbus communication module				
	OutTmpCommunicat		LON communication module				
	ExtAlarmCommunicat		Outdoor temperature from the bus				
BACnet/IP			External failure form the bus				
Language			BACnet/IP communication module				
	Current Language		Language				
Passwords			Current language				
	Login		Passwords				
	Log Out		Log-in				
	Change password		Log-out				
		Password:SERVICE	Password change				
		Level:SERVICE	Password: SERVICE				
		Password:ADMIN	Level: SERVICE				
		Level:ADMIN	Password: ADMINISTRATOR				
		Password:USER	Level: ADMINISTRATOR				
		Level:USER	Password: USER				
		Password:GUEST	Level: USER				
		Level:GUEST	Password: GUEST				
			Level: GUEST				
Function button							
- Fault							
1x	Alarm list detail		Last failure digital description				
2x	Alarm list:		List of failures				
	Acknowledge		Failure reset				
3x	Alarm history:		Error history				
	Acknowledge		Failure reset				
4x	Alarms		Failures				
	Alarm list:		List of failures				
	Reset		Reset				
	Alarm history:		Error history				
	Reset		Reset				

List of failures (HMI-DM, HMI-TM and HMI@WEB controllers)

Failure name	Failure Description
SupplyTmpSnsr	Inlet air temperature sensor
RoomTmpSnsr	Room air temperature sensor
HMI-SG1	Local HMI-SG1 controller
HMI-SG2	Local HMI-SG2 controller
ReturnAirTmpSnsr	Outlet air temperature sensor
OutTmpSnsr	Outdoor temperature sensor
HtgFrstTmpSnsr	Return water temperature sensor
FrostTmpSnsrHeatEx	Antifreeze protection temperature sensor
PreElHtgTmpSnsr	Temperature sensor after the el. pre-heater
PreWtrHtgTmpSnsr	Pre-heating antifreeze protection temperature sensor
ExtraSupplyTmp	Temperature sensor after the el. after-heater
BrrrFlueTmpSnsr	Flue gas temperature sensor
AirQualitySnsr	Air quality sensor
SupplyHumSnsr	Inlet air humidity sensor
RoomHumSnsr	Room air humidity sensor
OutHumSnsr	Outdoor air humidity sensor
Supply fan	Inlet – 1st fan
SplyFanInfBckUp	Inlet fan backup information
SplyFanBckUpOrTwn	Backup or twin – 2nd inlet fan
TwnSplyFanActBckUp	Twin inlet fan backup information
SplyFanBckUpFrsTwn	1st inlet fan twin backup
SplyFanBckUpSecTwn	2nd inlet fan twin backup
Exhaust fan	Outlet fan – 1st fan
ExhFanActBckUp	Outlet fan backup information
ExhFanBckUpOrTwn	Backup or twin - 2nd outlet fan
ExhFanBckUpFrsTwn	Twin backup – 1st outlet fan
TwnExhFanActBckUp	Twin outlet fan backup information
ExhFanBckUpSecTwn	Twin backup – 2nd outlet fan
Fan additional	Auxiliary 3rd fan
FanTwinAdditional	Auxiliary 3rd twin fan
Supply fan - flow	Supply fan air-flow fault
Exhaust fan - flow	Exhaust fan air-flow fault
AdditionalFan-Flow	Additional fan air-flow fault
WaterHeatingPump	Water heat pump fault
Heat pump	Heat pump fault
BlockHeatPumpFromOutTmpHeating	Blocking the heat pump from outer temperature - heating
BlockHeatPumpFromOutTmpCooling	Blocking the heat pump from outer temperature - cooling
Fan	Fan
Filter	Filter fouling
Electric heating	Electric heater
Fire	Fire
OverHeatFlueGas	Flue gas temperature exceeded
HighFlueGasTemp	High flue gas temperature

List of failures (HMI-DM...)

Failure name	Failure Description
BackdraftProtec	Gas heater thermostat switching ON
Burner	Gas heater
ElectricPreheating	Electric pre-heating
ExtraElectricalHtg	Electric after-heating
CondensingUnit	Condensing unit
FreqInvRotHeatEx	ROV failure
AntiFreezeHeatEx	Heat exchanger antifreeze protection
SplyFanMainTK	Main inlet fan - Thermocontact
SplyFanBckUpTK	Backup inlet fan - Thermocontact
SplyFanMainDifPr	Main inlet fan - pressure defERENCE sensor
SplyFanBckUpDifPr	Backup inlet fan - pressure defERENCE sensor
SupplyFanBack-up	Active inlet fan twin backup
ExhFanMainTK	Main outlet fan - Thermocontact
ExhFanBckUpTK	Backup outlet fan - Thermocontact
ExhFanMainDifPr	Main outlet fan - pressure defERENCE sensor
ExhFanBckUpDifPr	Backup outlet fan - pressure defERENCE sensor
ExhaustFanBack-up	Active outlet fan twin backup
CommunicatioModbus	Modbus communication
FanOperHours	Fan operating hours
StptSplyTmpDev	Difference between required and inlet air temperature monitoring.
StptRoomTmpDev	Difference between required and room (outlet) air temperature monitoring.
HeatPumpDefrost	Heat pump defrosting function
Inlet Pressure	Unconnected or damaged pressure sensor - inlet fan
Outlet Pressure	Unconnected or damaged pressure sensor - outlet fan
Inlet Air Flow	Unconnected or damaged flow sensor - inlet fan
Outlet Air Flow	Unconnected or damaged flow sensor - outlet fan
Humidifier	Humidifier fault
Reduced humidification output	Reduced humidification output due to the temperature priority (swimming-pool unit) – an information message

Other Ways of Control

External control

This enables the control unit to be connected to other technology using **single-** or **two-contact** control. The Auto operating state of the air-handling unit is always the default state for external control.

Single-Contact Control

This type of control can be performed in two ways (Start (default) or Start and Stop functions) depending on the data point setting.

Start function: By activating the switch (switching 1/0), the air-handling unit is put into the Run operating state (fan output stage and temperature mode). The control unit time in the Run state is always given by the timer settings. Another activation of the switch will prolong the control unit time in the Run state for a pre-set time in the timer. Once the pre-set time has elapsed, the unit will go into the Auto operating state. If the timer is set to zero, the contact input is ready for the switch action (on-off, switching 1) – if the switch is in the "On" position, the air-handling unit is in the Run operating state; after switching to the "Off" position, the air-handling unit will go into the Auto state.

Start and Stop function: By activating the switch "Start function" (switching 1/0), the air-handling unit is put into the Run operating state (fan output stage and temperature mode) for the timing period. Upon activation of the switch "Stop function" in the active timing interval, the pre-set operating mode will be stopped and the unit will go into the Auto state. The air-handling unit will also go into the Auto state once the timing interval has elapsed. If the timer is set to zero, the contact input is ready for the switch action (on-off, switching 1) – if the switch is in the "On" position, the air-handling unit is in the Run operating state; after switching to the "Off" position, the air-handling unit will go into the Auto state.

Two-Contact Control

This enables the selection of two Run mode operating states (Higher and Lower). Each Run operating state is set in a different temperature mode and fan speed stage. By combining the Stop or Auto operating modes, it is possible to set the required state of the Run mode. The contact states can be combined as follows:

Operating mode	1st contact	2nd contact
Auto	Off	Off
Lower stage	On	Off
Higher stage	Off	On
Stop	On	On

Setting of the Run operating state (temperature mode and fan output stage) and timer (only for one specific device) is performed using the HMI-SG controller in the List of Data Points in the section Settings – External Devices.

The two-contact control is also used (factory setting) for the use of REMAK ORe2 series wall-mounted controllers and ORe1 (this controller series does not use one of the manual stages).

Connection to the Master System (LonWorks Standard)

Remote Signalling

The VCS Control unit can optionally be equipped with one or two outputs for remote signalling.

Depending on the configuration, the following:

- Only failure (non-potential contact, max. load 230 V/1 A)
- Failure and operation (2 non-potential contacts, max. load 230 V/1 A).

LonWorks Network

The VCS control unit enables integration of the centralized BMS (Building Management System) using the LonWorks communication bus. Using the suitably integrated system, it is possible to control the air-handling device operating state. For a specific description of the variables to be used for the integration, refer to the section "Description of Pre-defined Variables in the LONWorks Network". The final functionality, monitoring and control options will be dependant on the integrator used to ensure connection to the master BMS system.

Network Interface

Connection to the network is ensured by a galvanically separated FTT-10A transceiver. This Free Topology Transceiver has been designed for the LonWorks network with a TP/FT-10 type transmission channel.

This transmission channel uses a free topology network, a twisted pair and baud rate of 78 kbps.

Applicable network topologies to be used along with the FTT-10A transceiver:

- Free topology (including the star and circular topology)
 - Free topology
- Bus topology
 - Line (Bus) topology

Each device in the LonWorks network is identified by a unique neuron ID identifier. The unique neuron ID identifier assigned by the manufacturer can always be found on the Climatix controller which is a part of the VCS control unit.

For more information on the LonWorks Standard refer to: www.echelon.com www.lonmark.org

Data Point Settings for Application of Some Network Input Variables

Using the controllers along with the VCS control system, it is possible to make changes in the assignment of the functions to some network input variables (SNVT). For some input variables like outdoor temperature and fire alarm (external failure), it is necessary to select if the value is to be used from the communication or from the application in the Controller Menu. Thus it can be determined if the outdoor temperature sensor is connected directly to the VCS control unit or its temperature reading is sent through the communication (LonWorks).

Description of Pre-defined Variables in the LonWorks Network

This section includes description of SNVT variables (Standard Network Variable Types) according to assigned REMAK data points. The list below includes specifications of variables for all the VCS control system variants. For example, if the VCS control system (air-handling device) was not equipped with gas heating it is not possible to use these variables.

Input Variables

Network Variable:	nviTemps
Description:	Req. heating temperature (Comfort) Req. cooling temperature (Comfort) Req. heating temperature (Economy) Req. cooling temperature (Economy) Minimum supply air temperature Maximum supply air temperature
Object:	SNVT_temp_Setpt
Remark:	Structured Variable

Network Variable:	nviTemp01
Description:	Not used
Object:	SNVT_temp_p

Network Variable:	nviTemp02
Description:	Outdoor temperature
Object:	SNVT_temp_p

Network Variable:	nviAHum00
Description:	Humidification Reference Value
Object:	SNVT_abs_humid
Remark:	For absolute and relative

Network Variable:	nviAHum01
Description:	Dehumidification Reference Value
Object:	SNVT_abs_humid
Remark:	For absolute and relative

Network Variable:	nviPpm00
Description:	Air quality Reference Value
Object:	SNVT_count

Network Variable:	nviPress_Flow00
Description:	Not used
Object:	SNVT_count

Network Variable:	nviPress_Flow01
Description:	Not used
Object:	SNVT_count

Network Variable:	nviPress_Flow02
Description:	Not used
Object:	SNVT_count

Network Variable:	nviPress_Flow03
Description:	Not used
Object:	SNVT_count

Network Variable:	nviPress_Flow04
Description:	Not used
Object:	SNVT_count

Connection to the Master System (LonWorks Standard)

Network Variable: nviPress_Flow05
 Description: Not used
 Object: SNVT_count

Network Variable: nviResetAlarm
 Description: Failure reset
 Object: SNVT_switch
 Values:

	0	Normal
	1	Reset
	>1	Not defined
State:	0:	Inactive
	1:	Active
Default:	Value:	0
	State:	0
Remark:	The State must be set to "1" to be used for the Value	

Network Variable: nviOpMode
 Description: Stav zařízení požadovaný z BMS
 Object: SNVT_switch
 Values:

	0	Auto (interní časový program)
	1	Stop
	2	Economy, 1St
	3	Comfort, 1St
	4	Economy, 2St
	5	Comfort, 2St
	6	Economy, 3St
	7	Comfort, 3St
	8	Economy, 4St
	9	Comfort, 4St
	10	Economy, 5St
	11	Comfort, 5St
	>11	Not defined
State:	0:	Inactive
	1:	Active
Remark:	The State must be set to "1" to be used for the Value	

Network Variable: nviControl
 Description: External control
 Object: SNVT_state (16 bit)
 Bits:

Bit [0 ...15]	Binary:	*Reverse:	
	0	15	
External control 1	1	14	
External control 2	2	13	
	3	12	
	4	11	
	5	10	
	6	9	
Fire alarm	7	8	"0"=Fault, "1" No fault
	8	7	
	9	6	

Bit [0 ...15]	Binary:	*Reverse:	
	10	5	
	11	4	
	12	3	

	13	2
	14	1
	15	0

Remark: *The bit name order can be reversed in some LON software tools.

Output Variables

Network Variable: nvoTemps
 Description: Req. heating temperature (Comfort)
 Req. cooling temperature (Comfort)
 Not used
 Req. heating temperature (cascade, inlet)
 Req. cooling temperature (cascade, inlet)
 Not used
 Object: SNVT_temp_Setpt
 Remark: Structured Variable

Network Variable: nvoTemp01
 Description: Inlet temperature
 Object: SNVT_temp_p

Network Variable: nvoTemp02
 Description: Return water temperature
 Object: SNVT_temp_p

Network Variable: nvoTemp03
 Description: Outdoor temperature
 Object: SNVT_temp_p

Network Variable: nvoTemp04
 Description: Room temperature (for control)
 Object: SNVT_temp_p

Network Variable: nvoTemp05
 Description: Outlet temperature
 Object: SNVT_temp_p

Network Variable: nvoTemp06
 Description: Temperature behind the heat exchanger
 Object: SNVT_temp_p

Network Variable: nvoTemp07
 Description: Flue gas temperature
 Object: SNVT_temp_p

Network Variable: nvoTemp08
 Description: Temperature behind electric pre-heating or Return water temperature form the water heater
 Object: SNVT_temp_p

Network Variable: nvoPpm00
 Description: Air quality
 Object: SNVT_count

Connection to the Master System (LonWorks Standard)

Network Variable: nvoPress00
 Description: Inlet pressure
 Object: SNVT_press_p

Network Variable: nvoPress01
 Description: Outlet pressure
 Object: SNVT_press_p

Network Variable: nvoPress02
 Description: Not used
 Object: SNVT_press_p

Network Variable: nvoPress_Flow00
 Description: Current request for the inlet fan
 Object: SNVT_flow
 Remark: %, Pa or l/s

Network Variable: nvoPress_Flow01
 Description: Current request for the outlet fan
 Object: SNVT_flow
 Remark: %, Pa or l/s

Network Variable: nvo_Flow00
 Description: Inlet air-flow
 Object: SNVT_flow

Network Variable: nvo_Flow01
 Description: Outlet air-flow
 Object: SNVT_flow

Network Variable: nvoPerc00
 Description: Heater output
 Object: SNVT_lev_count

Network Variable: nvoPerc01
 Description: Cooling output
 Object: SNVT_lev_count

Network Variable: nvoPerc02
 Description: Heat exchanger output
 Object: SNVT_lev_count

Network Variable: nvoPerc03
 Description: Mixing output
 Object: SNVT_lev_count

Network Variable: nvoPerc04
 Description: Not used
 Object: SNVT_lev_count

Network Variable: nvoPerc05
 Description: Electric heater output
 Object: SNVT_lev_count

Network Variable: nvoPerc06
 Description: Inlet fan output
 Object: SNVT_lev_count

Network Variable: nvoPerc07
 Description: Outlet fan output
 Object: SNVT_lev_count

Network Variable: nvoPerc08
 Description: Not used
 Object: SNVT_lev_count

Network Variable: nvoPerc09
 Description: Air humidity in the inlet
 Object: SNVT_lev_count

Network Variable: nvoPerc10
 Description: Air humidity in the room
 Object: SNVT_lev_count

Network Variable: nvoPerc11
 Description: Outdoor air humidity
 Object: SNVT_lev_count

Network Variable: nvoPerc12
 Description: Humidification output
 Object: SNVT_lev_count

Network Variable: nvoPerc13
 Description: Dehumidification output
 Object: SNVT_lev_count

Network Variable: nvoPerc14
 Description: Electric after-heater output
 Object: SNVT_lev_count

Network Variable: nvoAHum00
 Description: Absolute humidity in the inlet
 Object: SNVT_abs_humid

Network Variable: nvoAHum01
 Description: Absolute humidity in the outlet
 Object: SNVT_abs_humid

Network Variable: nvoOpMode
 Description: Current device state
 Object: SNVT_switch

- Values:
- 0 Stop
 - 1 Operation (Comfort)
 - 2 Operation (Economy)
 - 3 Not used
 - 4 Optimized start
 - 5 Night chilling
 - 6 Temperature start-up
 - 7 Night turn-over
 - 8 Not used
 - 9 Fire
 - 10 Safety stop
 - 11 Fan run-down
 - 12 Start
 - >12 Not defined

State:
 0: Inactive :Mode Auto
 1: Active :Mode OS

Default: Value: 0

Connection to the Master System (LonWorks Standard)

State:	0
Network Variable:	nvoSwitch00
Description:	Current fan state
Object:	SNVT_switch
Values:	0 Stop
	1 1St
	2 2St
	3 3St
	4 4St
	5 5St
	>5 Not defined
State:	0: Inactive
	1: Active

Network Variable:	nvoState
Description:	Alarm classes, Control mode
Object:	SNVT_state_64 (64 bit)
Bits:	
Bit [0 ...63]	Binary: *Reverse:
Alarm class - danger (A)	0 63
Alarm class - critical (A)	1 62
Alarm class - low (B)	2 61
Alarm class - warning (B)	3 60
	4 59
	5 58
	6 57
	7 56
	8 55
	9 54
	10 53
Current control temperature - room	11 52
Current control temperature - outlet	12 51
Current control temperature - inlet	13 50
Current control humidity - room	14 49
Current control humidity - inlet	15 48
	.
	.
	.
	63 0

Remark: *The bit name order can be reversed in some LON software tools

Network Variable:	nvoDO
Description:	Digital outputs
Object:	SNVT_state_64 (64 bit)
Bits:	
Bit [0 ...63]	Binary: *Reverse:
Inlet damper	0 63
Outlet damper	1 62
Fire damper	2 61
	3 60
Inlet Fan - Run	4 59
Inlet Fan - Stop	5 58
	6 57
	7 56
	8 55
Outlet Fan - Run	9 54
Outlet Fan - Stop	10 53

	11 52
	12 51
	13 50
	14 49
	15 48
Cooling - pump	16 47
Cooling DX, Stop	17 46
Cooling DX, 1st	18 45
Cooling DX, 2st	19 44
	20 43
	21 42
Heat recovery	22 41
	23 40
Water heating - pump	24 39
	25 38
Electric heating, Stop	26 37
Electric heating, 1st	27 36
	28 35
	29 34
	30 33
	31 32
Heat pump DO 2	32 31
	33 30
	34 29
	35 28
	36 27
	37 26
Heat pump DO 1	38 25
	39 24
Electric after-heating, Stop	40 23
Electric after-heating, 1st	41 22
	42 21
	43 20
	44 19
Request for humidification	45 18
Humidifier pump	46 17
	47 16
	48 15
	49 14
Gas heating, st1	50 13
Gas heating, st2	51 12
Gas heating, Mod+	52 11
Gas heating, Mod-	53 10
	54 9
	55 8
Alarm output (A failures)	56 7
Alarm output (B failures)	57 6
	58 5
	59 4
	60 3
Request for boiler room	61 2
Water pre-heating	62 1
Electric pre-heating	63 0
Remark:	*The bit name order can be reversed in some LON software tools.

Connection to the Master System (LonWorks Standard)

Network Variable:	nvoDI	
Description:	Digital Inputs	
Object:	SNVT_state_64 (64 bit)	
Bits:		
Bit [0 ...63]	Binary:	*Reverse:
	0	63
External input 1	1	62
External input 2	2	61
	.	.
	.	.
	.	.
	63	0

Remark: *The bit name order can be reversed in some LON software tools

Network Variable:	nvoAlarm	
Description:	Alarms	
Object:	SNVT_state_64 (64 bit)	
Bits:		
Bit [0 ...63]	Binary:	*Reverse:
Dampers	0	63
Fire dampers	1	62
Burner failure	2	61
Inlet fan	3	60
Outlet fan	4	59
Fans - operating hours	5	58
Back-up inlet fan	6	57
Back-up outlet fan	7	56
Cooling	8	55
Flue-gas high temperature - AHU shut down	9	54
Heat recovery	10	53
	11	52
Heat recovery (antifreeze protection)	12	51
	13	50
Mixing	14	49
Flue-gas high temperature - heater shut down	15	48
Heating, pump	16	47
Water heating	17	46
Electric heating	18	45
Back draught protection (TH)	19	44
Heat pump Cooling	20	43
	21	42
Heat pump, heating	22	41
	23	40
Electric after-heating	24	39
	25	38
Humidifier, pump	26	37
Humidification	27	36
	28	35
Fire	29	34
Electric pre-heating	30	33
Filters	31	32
Outdoor temperature	32	31
Inlet temperature	33	30
Return water temperature	34	29
Room temperature 1	35	28
Room temperature 2	36	27

Outlet temperature	37	26
	38	25
	39	24
	40	23
	41	22
	42	21
	43	20
	44	19
Temperature, HMI SG 1,2	45	18
Inlet temperature difference	46	17
Room temperature difference	47	16
Pressure differences (air-flow), inlet	48	15
Pressure differences (air-flow), outlet	49	14
	50	13
Outdoor air humidity	51	12
Air humidity difference, inlet	52	11
Air humidity difference, room53	10	
Dew point	54	9
	55	8
Air quality	56	7
	57	6
	58	5
	59	4
	60	3
	61	2
	62	1
	63	0

Remark: *The bit name order can be reversed in some LON software tools

Connection to the Master System (ModBus Standard)

Modbus (BMS)

The VCS control unit enables integration of the centralized BMS (Building Management System) using the Modbus communication bus ((Modbus RTU and/or ModbusTCP). Using a suitably integrated system, it is possible to control the air-handling device operating state. Specifications of the variables (data points) used for integration are described in the section Description of Pre-defined Variables in the Modbus Network. The final functionality, monitoring and control options will be dependent on the integrator used to ensure connection to the master BMS system.

Generally

Modbus is a worldwide recognized standard defined by Modbus Organization, Inc.

The Modbus Organization is a group of independent suppliers of automation devices. The Modbus Organization administers and develops communication systems for distributed automation systems. It also provides information to obtain and share information about the protocols, their application and certification to simplify implementation by users with the aim to reduce expenses for communication. For detailed information on the Modbus protocol, refer to www.modbus.org.

Trademarks and Copyright

The trademarks used in this document are listed on the back page, including their owners. These trademarks are quoted from Siemens materials.

Modbus RTU

The Modbus communication protocol works using the Master/Slave principle. The Slave function is used for the VCS control unit communication with the master system. Thus, the VCS control unit behaves like a Slave during communication and expects requests from the Master (master system).

There are two variants of the Modbus protocol serial transfer mode. The VCS control unit uses the RTU (Remote Terminal Unit) mode. Therefore, a unique Modbus RTU identification is very important.

The RS 485 standard is used to transfer the data through a half-duplex twin-lead.

The transfer lead (cable) must be selected depending on this standard and other conditions. For more information, refer to www.modbus.org

Correct wiring must be carried out to ensure proper operation – 115/230 VAC must be strictly isolated from 24 V SELV AC. There are three terminals, "+", "-", and reference voltage terminal "REF", available in the control unit to connect the VCS control unit to the bus.

To ensure correct functioning of the bus, the first and last device on the bus must be fitted with a terminal resistor. Therefore, it is possible to perform software settings of the terminal resistor in the VCS control unit for the Modbus Slave (see the Data Points in the VCS Installation and Operating Instructions).

It is also necessary to set other communication parameters in the VCS control unit data points (section – Communication with Modbus RTU Master System).

Default values of the data points for the Slave Modbus RTU:

- Slave address – 1
- Baud rate – 9600 Bd
- Parity - None
- Number of stop bits – 2
- Response time limit – 5 s

For more information, refer to the List of Data Points Note: Once these data points have been set, the device must be restarted. After the restart, the device is ready to communicate in accordance with the set parameters.

Modbus TCP

This is the second Modbus communication option available with the VCS control system. In this case, Ethernet (TCP/IP) is used for data transfer and works on Client/Server principle. For communication with the parent system, VCS is a Server function.

VCS default settings:

Fixed IP (DHCP is possible), address: 192.168.1.199, mask 255.255.255.0, gateway 0.0.0.0, Modbus TCP – port 502 (fixed).

The settings can be made by see. appropriate paragraph according to the used driver (eg HMI TM, DM, Web - Connection - LAN connection menu).

Note: you must restart the device after setting these data points. After this restart, VCS is ready to communicate according to the set value.

Modbus Registers

The Modbus registers are divided according to their properties. For a general description and explanation of the registers, refer to the table below:

Table 8 – Modbus registers

ModbusType	Reference	Description
Coil Status	0xxxx	Read/Write Discrete Outputs or Coils.
Input Status	1xxxx	Read Discrete Inputs.
Input Register	3xxxx	Read Input Registers.
Holding Register	4xxxx	Read/Write Output or Holding Registers.

Data types used to transfer the values:

16-bit for real values (Unsigned Word)

16-bit for status values (Signed Word)

1-bit for status values like 0=Off (switched off) and 1=On (switched on)

1-bit for alarm values like 0=Alarm and 1=Normal (OK)

Divisor (Multiplier):

The so-called Divisor (Multiplier) is used for values which need the decimal numbers to be transferred. For example, for temperatures the value Divisor (Multiplier) of 10 is used to enable a one decimal place value to be transferred.

For example, a temperature of 23.2°C is transferred by the Modbus as 232. The number must be divided by 10 to get the correct value. For information indicating this fact, refer to the note for a particular data point.

Connection to the Master System (ModBus Standard)

Description of Pre-defined Variables in the Modbus Network

This section includes a description of variables (registers) according to the assigned REMAK data points. The list below includes specifications of variables for different VCS control system variants at the discretion of REMAK a.s.

For example, if the VCS control system (air-handling device) has not been equipped with gas heating, it will not be possible to use these variables.

Coil status (Read/Write)

Adress	Description	Values/Units	Remarks
0x0001	Alarm acknowledge	0-1	Off*On
0x0002			
0x0003			
0x0004			
0x0007			
0x0011			
0x0012	Ext control input 1	0-1	Off*On
0x0013	Ext control input 2	0-1	Off*On
0x0014			
0x0015	Fire alarm	0-1	OK*Alarm

Input states (Read)

Adress	Description	Values/Units	Remarks
1x0001	Alarm class danger (A)	0-1	Off*On
1x0002	Alarm class critical (A)	0-1	Normal*Alarm
1x0003	Alarm class low (B)	0-1	Normal*Alarm
1x0004	Alarm class warning (B)	0-1	Normal*Alarm
1x0005			
1x0011			
1x0012	Ext control input 1	0-1	Off*On
1x0013	Ext control input 2	0-1	Off*On
1x0014			
1x0015			
1x0020			
1x0021			
1x0022			
1x0023			
1x0024			
1x0026	Fan alarm	0-1	OK*Alarm

Connection to the Master System (ModBus Standard)

Input states (Read) *(continuation)*

Adress	Description	Values/Units	Remarks
1x0027	Supply fan alarm	0-1	OK*Alarm
1x0028	Supply fan fdbk	0-1	OK*Alarm
1x0029	Sply fan deviation	0-1	Passive*Active
1x0030	Exhaust fan alarm	0-1	OK*Alarm
1x0031	Exhaust fan fdbk	0-1	OK*Alarm
1x0032	Exhaust fan deviation	0-1	Passive*Active
1x0033	Fan op hours alarm	0-1	Passive*Active
1x0036	Cooling DX alarm	0-1	OK*Alarm
1x0037			
1x0038	Cooling pump alarm	0-1	OK*Alarm
1x0039	Ice build-up on the heat pump evaporator	0-1	OK*Alarm
1x0040	Heat recovery alarm	0-1	OK*Alarm
1x0041			
1x0042			
1x0043	Hrec frost monitor	0-1	OK*Alarm
1x0044			
1x0045	Water heat pump alarm + auxiliary PMO CAP	0-1	OK*Alarm
1x0046			
1x0047	Htg frost monitor	0-1	OK*Frost
1x0048	El htg alarm	0-1	OK*Alarm
1x0049	Heat pump blocking by outdoor temperature	0-1	Passive*Active
1x0050	Heat pump blocking by pressure in the plate heat-exchanger	0-1	Passive*Active
1x0051	Heat pump operation blocking	0-1	OK*Alarm
1x0052			
1x0053			
1x0054			
1x0055			
1x0056	El heating 2 alarm	0-1	OK*Alarm
1x0057	Sply tmp deviation	0-1	Passive*Active
1x0058	Room tmp deviation	0-1	Passive*Active
1x0059			
1x0062			
1x0063			

Input states (Read) *(continuation)*

Adress	Description	Values/Units	Remarks
1x0064			
1x0065			
1x0066			
1x0067			
1x0070	Filter alarm	0-1	OK*Alarm
1x0071	Supply filter alarm	0-1	OK*Alarm
1x0072	Exh filter alarm	0-1	OK*Alarm
1x0073	Fire alarm	0-1	OK*Alarm
1x0074	Supply tmp fire alm	0-1	OK*Alarm
1x0075	Exh tmp fire alarm	0-1	OK*Alarm
1x0076	Inlet temperature (antifreeze protection)	0-1	OK*Alarm
1x0077			
1x0078	Modbus comm alarm	0-1	OK*Alarm
1x0080	Outside air temp	°C	OK*Alarm
1x0081	Supply air temp	°C	OK*Alarm
1x0082	Heating frost tmp	°C	OK*Alarm
1x0083	Room temperature	°C	OK*Alarm
1x0084	Room temperature 2	°C	OK*Alarm
1x0085	Return air temp	°C	OK*Alarm
1x0086	Exhaust air temp	°C	OK*Alarm
1x0087			
1x0088			
1x0089			
1x0090			
1x0091			
1x0092	Outdoor air humidity relative)	%r.H.	OK*Alarm
1x0093	Inlet air humidity (relative)	%r.H.	OK*Alarm
1x0094	Room air humidity (relative)	%r.H.	OK*Alarm
1x0095	Inlet air flow rate	m3/h	OK*Alarm
1x0096	Outlet air flow rate	m3/h	OK*Alarm
1x0097	Inlet air pressure	Pa	OK*Alarm
1x0098	Outlet air pressure	Pa	OK*Alarm
1x0099			
1x0100	Air quality	ppm	OK*Alarm

Connection to the Master System (ModBus Standard)

Input states (Read) *(continuation)*

Address	Description	Values/Units	Remarks
1x0101			
1x0102	RmUTmp1	°C	OK*Alarm
1x0103	RmUTmp2	°C	OK*Alarm
1x0104	BmrFlueTmp	°C	OK*Alarm
1x0105	PreElHtgTmp	°C	OK*Alarm

Input register (Read)

Address	Description	Values/Units	Remarks
1x0106	PreEtrHtgTmp	°C	OK*Alarm
			Unsigned Word
3x0001	General status (Word 1)	0-65535	0-1 for each bit or counted binary to a decimal number
Bit0	Alarm class danger (A)		
Bit1	Alarm class critical (A)		
Bit2	Alarm class low (B)		
Bit3	Alarm class warning (B)		
Bit4			
Bit5			
Bit6			
Bit7			
Bit8			
Bit9			
Bit10			
Bit11	Actual control temp, room		
Bit12	Actual control temp, exh		
Bit13	Actual control temp, sply		
Bit14			
Bit15			
			Unsigned Word
3x0005	Digital inputs (Word 1)	0-65535	0-1 for each bit or counted binary to a decimal number
Bit0			
Bit1	External control 1		
Bit2	External control 2		
Bit3			
Bit4			
Bit5			

Connection to the Master System (ModBus Standard)

Input register (Read) (continuation)

Address	Description	Values/Units	Remarks
Bit6			
Bit7			
Bit8			
Bit9			
Bit10			
Bit11			
Bit12			
Bit13			
Bit14			
Bit15			
3x0006	Digital inputs (Word 2)	0-65535	0-1 for each bit or counted binary to a decimal number
Bit0			
Bit1			
Bit2			
Bit3			
Bit4			
Bit5			
Bit6			
Bit7			
Bit8			
Bit9			
Bit10			
Bit11			
Bit12			
Bit13			
Bit14			
Bit15			
			Unsigned Word
3x0009	Digital outputs (Word 1)	0-65535	
Bit0	Supply (Exhaust) dampers		
Bit1			
Bit2			
Bit3			
Bit4	Supply fan, running		
Bit5	Supply fan, off		

Connection to the Master System (ModBus Standard)

Input register (Read) *(continuation)*

Adress	Description	Values/Units	Remarks
Bit6			
Bit7			
Bit8			
Bit9	Exhaust fan, running		
Bit10	Exhaust fan, off		
Bit11			
Bit12			
Bit13			
Bit14			
Bit15			
3x0010	Digital outputs (Word 2)	0-65535	0-1 for each bit or counted binary to a decimal number
Bit0	Cooling pump		
Bit1	Cooling DX, off		
Bit2	Cooling DX, stage 1		
Bit3	Cooling DX, stage 2		
Bit4			
Bit5			
Bit6			
Bit7			
Bit8	Heating pump		
Bit9			
Bit10	Electrical heating, off		
Bit11	Electrical heating, st.1		
Bit12			
Bit13			
Bit14			
Bit15			
3x0011	Digital outputs (Word 3)	0-65535	0-1 for each bit or counted binary to a decimal number
Bit0	Heat pump DO 2		
Bit1			
Bit2			
Bit3			
Bit4			
Bit5			

Connection to the Master System (ModBus Standard)

Input register (Read) (continuation)

Adress	Description	Values/Units	Remarks
Bit6	Heat pump DO 1		
Bit7			
Bit8	Extra el heating, off		
Bit9	Extra el heating, stage 1		
Bit10			
Bit11			
Bit12			
Bit13	Request for humidification		
Bit14			
Bit15			
3x0012	Digital outputs (Word 4)	0-65535	0-1 for each bit or counted binary to a decimal number
Bit0			
Bit1			
Bit2	Burner heating, st1		
Bit3	Burner heating, st2		
Bit4	Burner heating, Mod+		
Bit5	Burner heating, Mod-		
Bit6			
Bit7			
Bit8	Alarm output, high		
Bit9	Alarm output, low		
Bit10			
Bit11			
Bit12			
Bit13	Heating demand		
Bit14	PreWtrHeating		
Bit15	PreEl.Heating		
			Unsigned Word
3x0013	Alarms (Word 1)	0-65535	
Bit0			
Bit1			
Bit2	Burner failure		
Bit3	Supply fan		
Bit4	Exhaust fan		
Bit5	Fan operating hours		
Bit6	Supply back up		

Connection to the Master System (ModBus Standard)

Input register (Read) (continuation)

Adress	Description	Values/Units	Remarks
Bit7	Exhaust back up		
Bit8	Cooling		
Bit9	OverHeat Burner heating		
Bit10	Heating recovery		
Bit11			
Bit12	Heating recovery frost		
Bit13			
Bit14	Heating recovery damper		
Bit15	Flue-gas high temperature, heater shut down		
3x0014	Alarms (Word 2)	0-65535	0-1 for each bit or counted binary to a decimal number
Bit0	Heating pump		
Bit1			
Bit2	Electrical Heating		
Bit3	Burner fan overrun TH		
Bit4	Heat pump cooling		
Bit5			
Bit6	Heat pump heating		
Bit7			
Bit8	Extra Electrical Heating		
Bit9			
Bit10			
Bit11	Humidification		
Bit12	PreWtrHeating		
Bit13	Fire Alarm (external alarm)		
Bit14	Electric pre-heating		
Bit15	Filter Alarm		
3x0015	Alarms (Word 3)	0-65535	0-1 for each bit or counted binary to a decimal number
Bit0	Out temperature		
Bit1	Supply temperature		
Bit2	Heating frost temperature		
Bit3	Room1 temperature		
Bit4	Room2 temperature		
Bit5	Exhaust temperature		
Bit6	Extract temperature		
Bit7			

Connection to the Master System (ModBus Standard)

Input register (Read) (continuation)

Adress	Description	Values/Units	Remarks
Bit8			
Bit9			
Bit10			
Bit11			
Bit12			
Bit13	Room unit 1,2 - temperature		
Bit14	Supply temperature deviation		
Bit15	Room/Exh temp deviation		
3x0016	Alarms (Word 4)	0-65535	0-1 for each bit or counted binary to a decimal number
Bit0	Supply press/flow deviation		
Bit1	Exhaust press/flow deviation		
Bit2			
Bit3	Outdoor air humidity		
Bit4	Inlet air humidity		
Bit5	Room air humidity		
Bit6	Dew point		
Bit7			
Bit8	Air quality		
Bit9			
Bit10			
Bit11			
Bit12			
Bit13			
Bit14			
Bit15			
			Unsigned Word
3x0017	Act operating mode	0-12	Present value
	0=Off		
	1=On/Comfort		
	2=Economy		
	3=Na		
	4=Osstp		
	5=NightClg		
	6=UnOcc		
	7=NightKick		
	9=Fire		

Connection to the Master System (ModBus Standard)

Input register (Read) (continuation)

Address	Description	Values/Units	Remarks
	10=Stop		
	11=OverRun		
	12=StartUp		
	12=Start		
3x0018	Act fan step	0-5	Off*Stage1*Stage2*Stage3*Stage4*Stage5
3x0019			
3x0020	Op mode man st/tmp	0-11	Auto*Off*Eco St1*Comf St1*Eco St2*Comf St2*Eco St3*Comf St3*Eco St4*Comf St4*Eco St5*Comf St5
3x0021			
3x0022	TSP steps/tmp	0-10	Off*Eco St1*Comf St1*Eco St2*Comf St2*Eco St3*Comf St3*Eco St4*Comf St4*Eco St5*Comf St5
3x0023	Act Opmode ext ctrl	0-6	Auto*Off*Stage 1*Stage 2*Stage 3*Stage 4*Stage 5
3x0024			
3x0025	Supply (Exhaust) air damper cmd	0-1	Off*On
3x0026			
3x0027			
3x0028	Supply fan cmd	0-6	Off*Stage 1*Stage 2*Stage 3*Stage 4*Stage 5
3x0029	Sply fan outp sign	0-100%	
3x0030	Exhaust fan cmd	0-6	Off*Stage 1*Stage 2*Stage 3*Stage 4*Stage 5
3x0031	Exh fan outp signal	0-100%	
3x0032			
3x0033	Cooling outp signal	0 - 100%	
3x0034	Cooling pump cmd	0-1	Off*On
3x0035	Cooling DX cmd	0-2	Off*Stage 1*Stage 2
3x0036	Hrec outp signal	0 - 100%	
3x0037			
3x0038	Hrec dmpr outp sign	0 - 100%	
3x0039	Inlet/outlet damper swimming pool unit	0 - 100%	
3x0040	Heating outp signal	0 - 100%	

Connection to the Master System (ModBus Standard)

Input register (Read) (continuation)

Adress	Description	Values/Units	Remarks
3x0041	Htg pump cmd	0-1	Off*On
3x0042	El htg outp signal	0 - 100%	
3x0043	El heating cmd	0-1	Off*On
3x0044	Heat pump Cooling	0 - 100%	
3x0045	Heat pump	0 - 100%	
3x0046	Heat pump state	0-2	None*Cooling*Heating
3x0047	Heat pump Heating	0 - 100%	
3x0048	Heat pump (heating)	0-1	None*Heating
3x0049	El htg 2 outp sign	0 - 100%	
3x0050	El heating 2 cmd	0-1	Off*On
3x0051			
3x0052	Humidification	0 - 100%	
3x0053	Humidification (state)	0-1	Off* On
3x0054			
3x0055	Dehumidification	0 - 100%	
3x0057			
3x0058			
3x0059			
3x0060	Alarm output	0-1	Normal*Alarm
3x0061			
3x0062			
3x0064	Act airquality comp	0 - 100%	
3x0065	Act fan clg value	0 - 100%	
3x0066	Act fan htg value	0 - 100%	
3x0067	Act fan comp tmp	0 - 100%	
3x0068	Current fan speed compensation (humidity)	0 - 100%	
3x0069			
3x0070			
3x0071	Current mixing compensation (humidity)	0 - 100%	
3x0072	Outside air temp	$^{\circ}\text{C}$	(factor 10)
3x0073	Supply air temp	$^{\circ}\text{C}$	(factor 10)
3x0074	Heating frost tmp	$^{\circ}\text{C}$	(factor 10)
3x0075	Valid room tmp	$^{\circ}\text{C}$	(factor 10)
3x0076	Return air temp	$^{\circ}\text{C}$	(factor 10)
3x0077	Exhaust air temp	$^{\circ}\text{C}$	(factor 10)

Connection to the Master System (ModBus Standard)

Input register (Read) (continuation)

Adress	Description	Values/Units	Remarks
3x0078			
3x0079			
3x0080			
3x0081			
3x0082			
3x0083			
3x0084	Outdoor air humidity - relative	%r.H.	
3x0085	Outdoor air humidity - absolute	`-x.y - +x.y g/kg	(divider 10)
3x0086	Outdoor air humidity - enthalpy	`-x.y - +x.y kJ/kg	(divider 10)
3x0087	Inlet air humidity - relative	%r.H.	
3x0088	Inlet air humidity - absolute	`-x.y - +x.y g/kg	(divider 10)
3x0089	Inlet air humidity - enthalpy	`-x.y - +x.y kJ/kg	(divider 10)
3x0090	Room air humidity - relative	%r.H.	
3x0091	Room air humidity – absolute	`-x.y - +x.y g/kg	(divider 10)
3x0092	Room air humidity - enthalpy	`-x.y - +x.y kJ/kg	(divider 10)
3x0093	Dew point	`-x.y - +x.y g/kg	(divider 10)
3x0095	Inlet air flow rate	0 - x m ³ /h	
3x0096	Outlet air flow rate	0 - x m ³ /h	
3x0097	Inlet air flow rate	0 - x Pa	
3x0098	Outlet air pressure	0 - x Pa	
3x0099			
3x0101	Air quality	0 – x ppm	
3x0102			
3x0104	Act heating stpt	`-x.y - +x.y °C	
3x0105	Act cooling stpt	°C	
3x0106	Act sply htg stpt	°C	
3x0107	Act sply clg stpt	°C	
3x0108	Current required value of humidity - humidification	0 - x.y %r.H.	(divider 10)
3x0109	Current required value of humidity - dehumidification	%r.H.	(divider 10)
3x0110	Current humidification required value for cascade control	%r.H.	(divider 10)
3x0111	Current dehumidification required value in cascade control	%r.H.	(divider 10)
3x0112	Act sply fan stpt	0-100% (0 - x l/s)	

Connection to the Master System (ModBus Standard)

Input register (Read) (continuation)

Address	Description	Values/Units	Remarks
3x0113	Act exh fan stpt	0-100% (0 - x l/s)	
3x0114			
3x0115			
3x0116			
3x0117			
3x0120	Hour		
3x0121	Minute		
3x0122	Second		
3x0123	Year		
3x0124	Month		
3x0125	Day		
3x0130	Burner flue temp	°C	(factor 10)
3x0131	PreEl. heating temp	°C	(factor 10)

Holding register (Read/Write) [03:H]

Address	Description	Values/Units	Remarks
3x0132	PreWater heating temp	°C	(factor 10)
3x0133	Burner damper	0-100%	
3x0200	RoomUnitsActRmUMode	0-3	Auto*Comf*StBy*Eco
3x0210	RoomUnitsActSpvShift	°C	
3x0211	RmUTmp1	°C	
3x0212	RmUTmp2	°C	
			Unsigned Word
4x0001	Control bits	0-65535	
Bit0			
Bit1	External control 1		
Bit2	External control 2		
Bit3			
Bit4			
Bit5			
Bit6			
Bit7	Fire alarm (external alarm)		
Bit8			
Bit9			
Bit10			
Bit11			
Bit12			

Connection to the Master System (ModBus Standard)

Holding register (Read/Write) [03:H] (continuation)

Adress	Description	Values/Units	Remarks
Bit13			
Bit14			
Bit15			
			Unsigned Word
			Present value
4x0005	Control state required by BMS (variant without air temperature conditioning)	0-6	Auto*Off*St1*St2*St3*St4*St5
4x0006	Device state – BMS request	0-11	Auto*Off*Eco St1*Comf St1*Eco St2*Comf St2*Eco St3*Comf St3*Eco St4*Comf St4*Eco St5*Comf St5
4x0007			
4x0008	Control state required by Manual control (variant without air temperature conditioning)	0-6	Auto*Off* St1* St2* St3* St4* St5
4x0009	Op mode man st/tmp	0-11	Auto*Off*Eco St1*Comf St1*Eco St2*Comf St2*Eco St3*Comf St3*Eco St4*Comf St4*Eco St5*Comf St5
4x0010			
4x0011			
4x0012			
			Signed Word
			PresentValue
4x0020			(factor 10)
4x0021			
4x0022	Comfort htg stpt	°C	
4x0023	Comfort clg stpt	°C	
4x0024			
4x0025			
4x0026	Economy htg stpt	°C	
4x0027	Economy clg stpt	°C	(factor 10)
4x0028			
4x0029			
4x0030			
4x0031			
4x0032			

Connection to the Master System (ModBus Standard)

Holding register (Read/Write) [03:H] (continuation)

Adress	Description	Values/Units	Remarks
4x0033			
4x0034			
4x0035			
4x0036	Sply max limit	`-x.y - +x.y °C	(factor 10) Higt limit
4x0037	Sply min limit	`-x.y - +x.y °C	(factor 10) Low limit
4x0039	Set-point of relative humidity - Comfort	0 - x %r.H.	
4x0040	Dehumidification relative set-point - Comfort	0 - x %r.H.	
4x0041	Set-point of relative humidity - Economy	0 - x %r.H.	
4x0042	Dehumidification relative set-point - Economy	0 - x %r.H.	
4x0043			
4x0044			
4x0045			
4x0046			
4x0047			
4x0048			
4x0049			
4x0050	Sply fan st1 stpt	0 - x l/s	%, Pa or l/s
4x0051	Sply fan st2 stpt		
4x0052	Sply fan st3 stpt		
4x0053	Sply fan st4 stpt		
4x0054	Sply fan st5 stpt		
4x0055			
4x0056	Exh fan st1 stpt	0 - x l/s	%, Pa or l/s
4x0057	Exh fan st2 stpt		
4x0058	Exh fan st3 stpt		
4x0059	Exh fan st4 stpt		
4x0060	Exh fan st5 stpt		
4x0061			
4x0062	Air quality stpt CO	0 - x ppm	
4x0063	Air quality stpt CO2, VOC	0 - x ppm	
			TrackingValueCOM
4x0064	Outside air temp	`-x.y - +x.y °C	(factor 10)
4x0065	Air relative humidity - room	%r.H.	(divider 10)
4x0066	Room temperature	°C	
4x0067			

Connection to the Master System (ModBus Standard)

Holding register (Read/Write) [03:H] (continuation)

Address	Description	Values/Units	Remarks
Advanced mode			
			Signed Word
			PresentValue
4x0070			
4x0071			
4x0072			
4x0073			
4x0074			
4x0075			
4x0076			
4x0077			
4x0078			
4x0079			
4x0080			
4x0081			
4x0082	CaseFlowLimtMinDev	°C	(factor 10)
4x0083	CaseFlowLimtMaxDev	°C	(factor 10)
4x0084			
4x0085			
4x0086			
4x0087			
4x0088			
4x0089			
4x0090	Minimum fresh air flow rate (%) - Economy	0 - 100%	
4x0091	Minimum fresh air flow rate (%) – Comfort	0 - 100%	
4x0092			
4x0093			
4x0094			
4x0095			
4x0096			
4x0097			
4x0098			
4x0099			
4x0100			
4x0101			
4x0102			
4x0103			

Connection to the Master System (ModBus Standard)

Holding register (Read/Write) [03:H] (continuation)

Adress	Description	Values/Units	Remarks
4x0104			
4x0105			
4x0106			
4x0107			
4x0108			
4x0109			
4x0110			
4x0111			
4x0112			
4x0113			
4x0114			
4x0115			
4x0116			
	Control constants		
4x0201	Cooling	(factor 100)	Gain - Signed Word
4x0202	Cooling	0 - x sec	Integral - Unsigned Word
4x0203	Cooling	0 - x sec	Differential - Unsigned Word
4x0204	Heat recovery	(factor 100)	Gain - Signed Word
4x0205	Heat recovery	0 - x sec	Integral - Unsigned Word
4x0206	Heat recovery	0 - x sec	Differential - Unsigned Word
4x0207	Hrec frost protect	(factor 100)	Gain - Signed Word
4x0208	Hrec frost protect	0 - x sec	Integral - Unsigned Word
4x0209	Hrec frost protect	0 - x sec	Differential - Unsigned Word
4x0210			
4x0211			
4x0212			
4x0213	Hrec damper	(factor 100)	Gain - Signed Word
4x0214	Hrec damper	0 - x sec	Integral - Unsigned Word
4x0215	Hrec damper	0 - x sec	Differential - Unsigned Word
4x0216	Water heating	(factor 100)	Gain - Signed Word
4x0217	Water heating	0 - x sec	Integral - Unsigned Word
4x0218	Water heating	0 - x sec	Differential - Unsigned Word
4x0219	Htg frost protect	(factor 100)	Gain - Signed Word
4x0220	Htg frost protect	0 - x sec	Integral - Unsigned Word
4x0221	Htg frost protect	0 - x sec	Differential - Unsigned Word
4x0222	Electrical heating	(factor 100)	Gain - Signed Word

Connection to the Master System (ModBus Standard)

Holding register (Read/Write) [03:H] (continuation)

Adress	Description	Values/Units	Remarks
4x0223	Electrical heating	0 - x sec	Integral - Unsigned Word
4x0224	Electrical heating	0 - x sec	Differential - Unsigned Word
4x0225	Burner	(factor 100)	Gain - Signed Word
4x0226	Burner	0 - x sec	Integral - Unsigned Word
4x0227	Burner	0 - x sec	Differential - Unsigned Word
4x0228	Burner Damper	(factor 100)	Gain - Signed Word
4x0229	Burner Damper	0 - x sec	Integral - Unsigned Word
4x0230	Burner Damper	0 - x sec	Differential - Unsigned Word
4x0231			
4x0232			
4x0233			
4x0234	El. reheating (El. heating 2)	(factor 100)	Gain - Signed Word
4x0235	El. reheating (El. heating 2)	0 - x sec	Integral - Unsigned Word
4x0236	El. reheating (El. heating 2)	0 - x sec	Differential - Unsigned Word
4x0237			
4x0238			
4x0239			
4x0240			
4x0241			
4x0242			
4x0243			
4x0244			
4x0245			
4x0246			
4x0247			
4x0248			
4x0249			
4x0250			
4x0251			
4x0252			
4x0253			
4x0254			
4x0255	Supply fan	(factor 100)	Gain - Signed Word
4x0256	Supply fan	0 - x sec	Integral - Unsigned Word
4x0257	Supply fan	0 - x sec	Differential - Unsigned Word
4x0258	Exhaust fan	(factor 100)	Gain - Signed Word
4x0259	Exhaust fan	0 - x sec	Integral - Unsigned Word

Connection to the Master System (ModBus Standard)

Holding register (Read/Write) [03:H] (pokračování)

Adress	Description	Values/Units	Remarks
4x0260	Exhaust fan	0 - x sec	Differential - Unsigned Word
4x0261	Humidification	(divider 100)	Gain - Signed Word
4x0262	Humidification	0 - x sec	Integral - Unsigned Word
4x0263	Humidification	0 - x sec	Differential - Unsigned Word
4x0264			
4x0265			
4x0266			
4x0267	Dehumidification	(divider 100)	Gain - Signed Word
4x0268	Dehumidification	0 - x sec	Integral - Unsigned Word
4x0269	Dehumidification	0 - x sec	Differential - Unsigned Word
4x0270	Air quality	(factor 100)	Gain - Signed Word
4x0271	Air quality	0 - x sec	Integral - Unsigned Word
4x0272	Air quality	0 - x sec	Differential - Unsigned Word
4x0273	Casc controller tmp	(factor 10)	Gain - Signed Word
4x0274	Casc controller tmp	0 - x sec	Integral - Unsigned Word
4x0275	Humidity cascade control	(Factor 10)	Gain - Signed Word
4x0276	Humidity cascade control	0 - x sec	Integral - Unsigned Word
4x0277	HeatPumpHtg	(factor 100)	Gain - Signed Word
4x0278	HeatPumpHtg	0 - x sec	Integral - Unsigned Word
4x0279	HeatPumpHtg	0 - x sec	Differential - Unsigned Word
4x0280	HeatPumpClg	(factor 100)	Gain - Signed Word
4x0281	HeatPumpClg	0 - x sec	Integral - Unsigned Word
4x0282	HeatPumpClg	0 - x sec	Differential - Unsigned Word
4x0283	ElPreHtg	(factor 100)	Gain - Signed Word
4x0284	ElPreHtg	0 - x sec	Integral - Unsigned Word
4x0285	ElPreHtg	0 - x sec	Differential - Unsigned Word
4x0283	WtrPreHtg	(factor 100)	Gain - Signed Word
4x0284	WtrPreHtg	0 - x sec	Integral - Unsigned Word
4x0285	WtrPreHtg	0 - x sec	Differential - Unsigned Word

Connection to the Master System (BacNet Standard)

BACnet/IP (BMS)

The VCS control unit enables integration of the centralized BMS (Building Management System) using the BACnet/IP communication standard. Using a suitably integrated master system, it is possible to control the air-handling device's operating state.

Generally

BACnet is a standard communication protocol for Building Automation and Control Networks developed by ASHRAE (American Society of Heating, Refrigerating and Air-conditioning Engineers). The main goal was to create a protocol which enables the integration of systems from different manufacturers intended for building automation. For detailed information on the BACnet protocol, refer to the following websites:

www.bacnet.org
www.bacnetinternational.net

BACnet/IP Protocol

There are several variants of the BACnet protocol. The VCS control system uses BACnet/IP for the Ethernet network. The BACnet communication protocol works using the Master/Slave principle. The Server function is used for VCS unit system communication with the master system. This means that the VCS control unit behaves like a Server in the communication.

Protocol settings can be performed using one of the following controllers: HMI, DM, TM or Web. Switching on and off,

restart and other settings of the BACnet server can be carried out through the web page (calling the address set in the VCS control unit). For detailed information on the BACnet/IP Standard (EDE file and others) settings and application, refer to the Siemens BACnet/IP Communication Module documentation available on the REMAK website.

The following table includes a list of basic data points which can be used for this communication and their description. The list includes specifications of variables for different VCS control system variants.

For example, if the VCS control system (air-handling device) has not been equipped with gas heating, it will not be possible to use these variables. The final functionality, monitoring and control options will be dependent on the integrator used to ensure connection to the master BMS system.

List and Description of Basic Data Points

Data point name	Meaning
Device	Device
Diagnostic	Diagnostics
SystemClock	System time
AirQuality	Air quality
RoomTmp	Room temperature
RmUTmp1	HMI-SG1
RmUTmp2	HMI-SG2
ValidRoomTmp	Temperature in the room after control
ReturnAirTmp	Outlet air temperature
SupplyTmp	Inlet air temperature
OutTmp	Outdoor temperature
HtgFrstTmp	Return water temperature (water heater)
ExhaustTmp	Outlet air temperature after the heat exchanger
PreElHtgTmp	Temperature, electric pre-heating
PreWtrHtgTmp	Return water temperature (water pre-heating)
BmrFlueTmp	Flue gas temperature
RoomHum	Air humidity in the room - relative
SupplyHum	Inlet air humidity - relative
OutHum	Outdoor air humidity - relative
RmHumAbs	Absolute air humidity in the room
SplyHumAbs	Absolute inlet air humidity
OutHumAbs	Absolute outdoor air humidity
RmEnth	The room - enthalpy
OutEnth	Outdoor enthalpy
ActOpMode	Current state of the device
ActFanStep	Current state of the fans
OpModeAutoManSt.Swtch	Manual mode (control)
OpModeAutoManStTmp.Swtch	Manual mode (control)

Connection to the Master System (BacNet Standard)

List and Description of Basic Data Points ((*continuation*))

OpModeBmsTimeSt.Swtch	BMS control mode (control, master system)
OpModeBmsTimeStTmp.Swtch	BMS control mode (control, master system)
TmpSpv.CoSpvHtg	Required value for heating - Comfort
TmpSpv.CoSpvClg	Required value for cooling - Comfort
TmpSpv.EcSpvHtg	Required value for heating - Economy
TmpSpv.EcSpvClg	Required value for cooling - Economy
HumSpvRel.SpvHum	Required value for humidification (relative)
HumSpvRel.SpvDehum	Required value for dehumidification (relative)
AirQSpv	Required value for air quality
ScheduleSt	Weekly time schedule
ScheduleStTmp	Weekly time schedule
CalendarEx	Exception time schedule
CalendarOff	Switch-off schedule
ActCascSpvHtg	Current required heating temperature (cascade)
ActCascSpvClg	Current required cooling temperature (cascade)
ActCascSpvDeh	Current required value for dehumidification (cascade)
ActCascSpvHum	Current required value for humidification (cascade)
Heating.Pos	Heating node valve outlet position
ElectricalHtg.Pos	Electric heating outlet position
Cooling.Pos	Cooling valve outlet position
ExtraEHtg.Pos	Electric after-heating outlet position
Hrec.Pos	Heat exchanger control outlet position
HrecDamp.Pos	Mixing damper outlet position
aoHeatPumpHtg.Pos	Heat pump outlet position - heating
aoHeatPumpClg.Pos	Heat pump outlet position - cooling
HumidityCtrl.Pos	Humidification current value
DeHumidity.PrVal	Dehumidification current value
AirQComp.PrVal	Air quality compensation current value
SplyFan.Cmd.St	Current stage, inlet fan
ExhFan.Cmd.St	Current stage, outlet fan
Heating.Pmp.Cmd.OnOff	Heating pump state
ElectricalHtg.Cmd.St.St	Electric heater state
ExtraEHtg.Cmd.St.St	Electric after-heater state
Cooling.Pmp.Cmd.OnOff	Water cooler pump state
Cooling.CmdDx.St	Cooling state, inverter cooling unit
Damper.Exh.OnOff	Damper, outlet
Damper.Sply.OnOff	Damper inlet
AlmOutHigh	Alarm, output A
AlmOutLow	Alarm, output B
AlmCl0	Alarm, class A
AlmCl1	Alarm, class A
AlmCl2	Alarm, class B
AlmCl3	Alarm, class B
FireAlm	External alarm
AckAlmPls	Failure release

POOL UNITS – description of control

The VCS also allows the control of air-conditioning units designed to ventilate swimming pools (swimming pools, water parks, rehabilitation complexes with water procedures, etc.). As the ventilation needs of these spaces are different from the needs of ventilation of common areas (offices, restaurants, etc.), the control system needs to be optimized according to these requirements. Therefore, the behavior of the control system has been modified to create a unique control and control system for pool units.

This section of the manual supplements the VCS control system information from the perspective of HVAC pool control. Regarding regulation, pool units are divided into two basic variants. S and without integrated heat pump. The unit without a "ventilating" heat pump only uses outside air to achieve the desired humidity. The integrated heat pump unit uses both the outdoor air and the circulation mode and the integrated heat pump to achieve the desired humidity.

Other modifications only complement these two basic variants. For example, additional cooling, reheater, etc.).

Unit operation modes

- **Comfort** (used for normal operation of air conditioning systems to provide a comfortable environment for people in the wind). In this mode, the minimum amount of fresh air is preset to 30%.

- **Economical** (used for HVAC mode to ensure economical operation when there is no need to provide comfortable conditions - there are no persons in the ventilated area).

In this mode, the minimum amount of fresh air is preset to 0%. For each mode, the set room temperature, the maximum humidity in the room and the minimum amount of fresh air are set separately.

The behavior of the control system is also different in these modes and is optimized for maximum energy-efficient operation of the unit. In Comfortable mode, emphasis is placed on reaching the desired values with respect to the need to supply fresh air for people in the ventilated area. In Economical mode, people are not expected to be in the windspace. That is why other management procedures can be used in this mode to achieve the desired values for economical operation and energy savings.

Temperature control

For pool units, room temperature control with limitation of supply air temperature is used. The set room temperature is set to Comfort and Economy. The supply air temperature is not directly regulated but its intervention in the regulation is in case of deviation from the set limits. The minimum and maximum supply air temperature values are set in the control. See Settings. list of data points.

Temperature control is superior to humidity control. In some situations, the dehumidification performance may exceptionally be reduced due to the higher priority of temperature control. This state is signaled on the controllers.

Humidity control (Dehumidification)

For pool units, room moisture control is used. Desired humidity is achieved in various ways according to the type of HVAC pool units.

Pro-Vapor Pool Unit (Units without Integrated Heat Pump)
- The required humidity is achieved by mixing. By supplying a sufficient amount of outdoor dry air. In addition, fan speed control is used to increase the required power.

Pool unit with integrated heat pump and circulation flap - the method of achieving the desired humidity varies according to the selected unity mode:

Comfort Mode

1st stage of dehumidification - mixing + 2nd stage of fan speed
2nd degree of dehumidification - 100% mixing + 3rd stage of fan speed

Economy Mode

1st dehumidification stage - circulation mode + running of the heat pump + raising the speed to 2 degrees.
2nd stage dehumidification - mixing + 2nd stage of fan speed

Fan speed control:

for pool units, a constant flow rate control is usually used in three preset steps. The transition between stages is fully automated and is controlled according to temperature and humidity requirements. The user has the option to switch the unit on any power level. However, if it switches the unit to maximum speed, it automatically blocks the possibility of increasing the speed and optimizing the operation of the HVAC from an energy point of view. The ability to switch on unity to the maximum speed is primarily possible for service purposes and exceptional operational requirements.

The unit increases fan speed when dehumidifying. It can also increase fan speeds in case of sufficient power of heating components. This increases the heating power.

HVAC components control

regulation of individual components (mixing, water heating, etc.) is based on the standard HVAC control. However, for a pool unit there are some differences that are described below:

- **Mixing damper and inlet/outlet damper**

The dampers are continuously controlled according to the temperature requirement. Furthermore, the position is affected by the requirement for humidity. The mixing valve may no longer be coupled with the inlet / outlet dampers. Their mutual functions may be different in some situations for pool units. For example, when the plate heat recovery is active (pool units with integrated cooling).

Extreme temperature protection - at an outside temperature of $T < -10^{\circ} \text{C}$, the maximum amount of fresh air is limited to 40%. This ensures greater control stability. Settings and signaling see data. mixing points.

POOL UNITS – description of control

■ Circulating damper

Enabled in economy mode heating or dehumidification stage
 1. If the circulation damper is open, the inlet and outlet valves are closed. The outdoor unit is not circulating and 100% circulates it. The mixing valve is further regulated according to temperature and humidity.

■ Heat Pump

Activated and continuously controlled on request from temperature control. However, during circulation, it is not controlled by temperature but is activated based on the requirement of humidity control.

Restriction of operation: Heat pump operation is blocked if one of these situations occurs:

1. outdoor temperature is out of set limits
2. the pressure differential on the heat exchanger is out of range $\Delta P_{\min} - \Delta P_{\text{mid}}$

To set all parameters, see list of data points.

■ Plate Heat Exchanger

Power regulation is ensured by continuous bypass control. Pro-Vapor Pool Unit (Units without Integrated Heat Pump).

Anti-freeze protection – standard (for the plate heat exchanger without integrated mixing):

Intervention and bypass control according to the standard regulation of the standard HVAC based on the measured exhaust air temperature after the recuperator - part of the manual for frost protection of the heat exchange.

Anti-freeze protection – option (for a plate heat exchanger with integrated mixing)

Additionally, over the standard, following is supplemented:

- when activating this bypass, the inlet/outlet dampers are preferably fully opened + the mixing valve is closed
- Reduced speed of the intake fan to stage 1

Pool unit with integrated heat pump and circulation damper:

Anti-freeze protection – standard

is ensured by monitoring the state of the differential pressure transmitter ΔP_{\max} (min. state 60s), while monitoring the outdoor temperature below -5°C and the state when the unit is supplying fresh air. If these conditions occur, the unit will activate the antifreeze protection:

The unit switches to the preset time (default 15 minutes, if ΔP_{\max} lasts longer) to the antifreeze mode (Economy mode, dehumidification of 1st stage - circulation, bypass closed). When the antifreeze mode is complete, re-activation is blocked.

Anti-freeze protection – option

It is used in exceptional cases where the standard is very active and reduces dehumidifying power and fresh air frequently. Switching between variants is possible with HMI. The activation is the same as the standard option. The

intervention is the same, except for the inlet and outlet dampers, which are controlled according to the humidity requirement (Economy mode, dehumidification of the 1st stage - circulation, bypass closed, mixing valve is closed, supply / exhaust flaps regulated).

■ Pump for pool water heating

The pump discharges excess heat that is generated during the dehumidification and operation of the HVAC unit. It is triggered under the condition of dehumidification requirement and sufficient supply air temperature. Furthermore, there is a requirement for dehumidification and the required room air temperatures and active heat pump operation.

Additional control functions

Further, all other features based on the standard HVAC application are fully available. These are described in the relevant paragraphs for a standard application. Like:

- Recovery and mixing at the start of the HVAC
- Start optimization
- Night cooling

Integrated cooling – Controller for Compressor Output Control



Safety Measures

Check the correct supply voltage (see Technical Data) before connecting the device. Do not expose the device to moisture or water. Use the device so that the operating conditions will not be exceeded and the device will not be exposed to abrupt changes in temperatures at high humidity causing air humidity condensation.

Warning: Disconnect all power supply connections before you start any maintenance work on the device.

The sensors must be located out of reach of the end user. Do not disassemble the device. If the device fails or malfunctions, send it back, including a detailed description of the failure.

General Description

The PLC controller controls cooling in the air-conditioned room depending on the signals received from the parent system and pre-set parameters. It measures temperature in the compressor discharge and pressure in the heat exchangers. If the device is fitted with a 4-way valve (Premium" version), it is possible to switch the unit between cooling (in summer) and heating (in winter) modes of the ventilated room, including heat recovery. For a more detailed description of this technology, refer to the User Manual. The device is equipped with preparations for a differential pressostat in the air-handling unit channel, serving as antifreeze protection of the evaporator. The signal received from this switch will start defrosting by directing inlet air to the evaporator's fins. Defrosting starts automatically if the limit evaporation temperature is set below 4°C, when ice build-up is created on the evaporator's surfaces which need to be defrosted. If the differential pressostat is not present, defrosting can also be set for time cycles using the parameters. Evaporation pressure is used to monitor the device and the unit's output is reduced to protect the evaporator against freezing at low evaporation temperatures. Condensation pressure monitoring is another way of providing device protection. When this value is increased, the unit's output is reduced to prevent a failure. The output reduction is signalled by the relay contact – KA7. The output reduction level can also be signalled by 0-10V analogue outputs. One signal's reduction is based on the evaporation temperature and the other one is based on the condensation temperature. The device is able to control condensation pressure using an analogue output. This feature is only available for the "Premium" version.

Process Control

Control is started as soon as the contacts for the unit start are closed. Relay – KA9. If the unit is equipped with reversation, the cooling or heating mode is selected.

The selection is made by the relay – KA11 (closed = heating). Then the unit output is controlled by the 0-10V analogue signal. Operation of the unit is indicated by a dry contact, the same way as an error. The unit is equipped with several protections, protecting the cooling device against damage (pressure switches, outlet temperature monitoring, etc.).

Controller Operation

SET(F4) Shows the user parameters.
In the programming mode, it is used to select the parameter or confirm the operation.

ESC(F2) In the programming mode, it is used to cancel the operation. Cancels the action.
Long hold = Failure reset

▲ (F1) No Function

▼ (F3) No Function

Key combination:

SET(F2) + Esc (F4) Enters the programming mode.

LED	Mode	Function
	On	Unit start is requested
	On	Cooling in operation
	On	Heating in operation
	On	Defrosting in progress
	On	Power valve switched on
	On	Alarm
	On	No function
	On	Measured units
	On	Programming Menu
	Flashes	Remembers the Prog. Menu password for 60 s
	1	FA1 circuit breaker open
	2	FA2 circuit breaker open
	3	Low-pressure pressostat open
	4	High-pressure pressostat open or incorrect phase sequence
	5	Electronic injection valve failure
	6	Output limiting relay closed

Viewing Temperatures and Alarms

Viewing Temperatures

1. Briefly press the SET button to display "Pen".
2. Using the arrows, scroll to "Prb" and press the SET button to confirm.
3. Scroll to the temperature analogue input (Anxx) and press the SET button to confirm.
4. The display shows the temperature of the corresponding sensor.

Viewing Analogue Output Values

1. Briefly press the SET button to display "Pen".
2. Using the arrows, scroll to "AO" and press the SET button to confirm.
3. Scroll to the analogue output (AOxx) and press the SET button to confirm.
4. The display shows the value of the corresponding analogue output.

Viewing Alarms

1. Briefly press the SET button to display "Pen".
2. Using the arrows, scroll to "AL" and press the SET button to confirm.
3. A corresponding alarm is displayed. If more than one alarm is displayed, use the arrows to scroll between them.

Main Functions

Viewing and Changing Basic Parameters

1. Briefly press the SET button to display "USr".
2. Press the SET button to confirm.
3. Using the arrows, scroll to the desired parameter and press the SET button to confirm.
4. Using the arrows, change the value and press the SET button to confirm.
5. To return to the menu, press the ESC button.

Changing Values of any Parameter

Simultaneously press the SET + ESC buttons to switch the device to the programming mode (the indicator comes ON). At the same time, the "Par" is displayed. Press the SET button to confirm.

Using the \triangle or ∇ buttons, select the parameter group and press the SET button to confirm.

Using the \triangle or ∇ buttons, select the parameter.

Press the SET button to display its current value.

Using the \triangle or ∇ buttons, set the new value of the parameter. Press the SET button to save the value.

Exit: To return to the main screen, press the ESC button or wait 60 seconds.

Note: Some parameters require a code to be displayed.

Hidden Parameters

To display hidden parameters, enter a code when opening the programming menu.

1. Simultaneously press the SET + ESC buttons to switch the device to the programming mode (the indicator comes ON). At the same time, "Par" is displayed.

2. Using the \triangle / ∇ buttons, select "PASS" and press the SET button to confirm.
 3. Using the \triangle / ∇ buttons, enter the numerical code required for the parameter group in question (Level 1 or 2) and press the SET button to confirm.
 4. Then proceed in the same way as in point 6.2. Now the parameters are visible.
- Exit: To return to the main screen, press the ESC button or wait 60 seconds.

Parameters

User Parameters (S--)

- **S-00 Pre-set evaporation temperature (-10.0 to 10.0°C):**
A value limiting the unit's output depending on the evaporation temperature.
- **S-01 Pre-set condensation temperature (30.0 to 90.0°C):** A value limiting the unit's output depending on the condensation temperature.
- **S-02 Condenser settings (20.0 to S-01°C):**
A pre-set value of the condensation pressure to control the condenser fans. If used.
- **S-04 Start (Yes/No):** If "Yes" is set, the unit is started at 100 % output regardless of the input signal control value. Level 1 (PASS = 1) – only for service (P--)
- **P-16 Maximum compressor discharge temperature (90.0 to 140.0 °C):** When this temperature is exceeded, the compressor is switched off.
- **P-20 Minimum compressor runtime (5 to 120 sec):**
If the compressor is switched on, it can only be switched off once this time has elapsed. This is a safety value.
- **P-21 Minimum compressor off time (30 to 300 sec):**
If the compressor is switched off, it can only be switched on once this time has elapsed. This is a safety value.
- **P-22 PWM valve switching period (10 to 20 sec):**
Switching period of the digital compressor power valve
- **P-23 Pen HP (3 to 10 sec):**
Allowed number of high-pressure pressostat failures per P-24 time.
- **P-24 Pei HP (15 to 60 sec):**
Time interval for counting high-pressure pressostat failures.
- **P-25 Pen LP (3 to 10 sec):**
Allowed number of low-pressure pressostat failures per P-24 time.
- **P-26 Pei LP (15 to 60 sec):**
Time interval for counting low-pressure pressostat failures. Level 2 (PASS = 2) – only for service (P--)
- **P-01 PID LP Udz:** PID control upper insensitive zone.
- **P-02 PID LP Ldz:** PID control lower insensitive zone.
- **P-03 PID LP Bp:** PID control proportionality zone.
- **P-04 PID LP Ti:** PID control integration constant.
- **P-05 PID LP Td:** PID control derivative constant.
- **P-06 PID LP Arw:** PID control anti-reset lift.
- **P-07 PID LP Speed:** Maximum number of PID output changes per 1 sec.
- **P-10 Hyst UP Ext:** Upper hysteresis for the cooling unit start. When this limit is exceeded, the input analogue signal is accepted.

Integrated cooling – Controller for Compressor Output Control

- **P-17 Coolant:** Used coolant type.
(0= R404A, 1=R22,2=R744, 3 = R290, 4 = R134A, 5 = R407C, 6 = R410A, 7 = R427A, 8 = R507A).
- **P-32 PID HP Udz:** PID control upper insensitive zone.
- **P-33 PID HP Ldz:** Control lower insensitive zone
- **P-34 PID HP Bp:** Control proportionality zone
- **P-35 PID HP Ti:** Control integration constant
- **P-36 PID HP Td:** Control derivative constant
- **P-37 PID HP Arw:** Control anti-reset lift
- **P-38 PID HP Speed:** Maximum number of PID output changes per 1 sec.
- **P-40 Bypass time LP:** Low-pressure pressostat bypass time upon compressor start.
- **P-41 Filter time LP:** Low-pressure pressostat bypass time when the compressor is running.
- **P-42 Bypass time LPA:** Low-pressure sensor failure bypass time upon compressor start.
- **P-43 Filter time LPA:** Low-pressure sensor bypass time when the compressor is running.
- **P-45 Curb Enable:** Output limitation enable from the PID high-pressure controller.
- **P-47 Warning time (0 to 600 sec):**
Time for which the output limitation is signalled.
- **P-50 PID Cond Bp:** PID control proportionality zone.
- **P-51 PID Cond Ti:** Control integration constant
- **P-52 PID Cond Td:** Control derivative constant
- **P-53 PID Cond Udz:** PID control upper insensitive zone.
- **P-54 PID Cond Ldz:** PID control lower insensitive zone
- **P-55 PID Cond Speed:** Maximum number of PID output changes per 1 sec.
- **P-56 PID Cond Arw:** Control anti-reset lift.
- **P-48 Warning value (0 to 100%):**
PID controller limiting value – when exceeded, the output limitation is signalled.
- **P-60 Increment time (10 to 600 sec):**
Additional compressor connection time.
- **P-61 Decrement time (0 to 120 sec):**
Additional compressor switch-off delay time.
- **P-66 Dif. through En.:** Enables use of the differential pressostat information for the cooling heat exchanger. Anti-freeze protection. It starts defrosting.
- **P-67 Swap time:** Cooling/heating mode switching time.
- **P-68 Det time:** Maximum defrosting time.
- **P-69 Dit time:** Defrosting interval.
- **P-70 Switch OFF:**
The compressor is switched off when switching cooling/heating modes.
- **P-71 Switch Cap.:** (0 to 100%)
Compressor output between cooling/heating mode switching.
- **P-74 Defrost LP:** (-10.0 to 2.5°C)
Evaporation pressure limit compared with S-00 below when defrosting is enabled.
- **P-77 Maf:**
Number of cycles for the pressure oscillation mathematical filter.
- **P-79 App:** Application selection.

Application Version	Settings
One compressor with output control, BASIC version	-1
Two compressors, BASIC version	-2
One compressor without output control, PREMIUM version	1
Two compressors, PREMIUM version	2

Viewing Alarms

If a failure occurs during operation, this state is signalled by a flashing symbol Δ . Furthermore, the corresponding alarm can be displayed. For a description, refer to point 5.2.

Alarm Types

Code	Cause	Description
A-01	LP sensor failure	Check 4-20mA current loop.
A-02	Td sensor failure	Check the temperature sensor.
A-03	HP sensor failure	Check 4-20mA current loop.
A-04	Compressor 1 failure 1	Check the compressor protections.
A-05	Compressor 2 failure	Check the compressor protections.
A-06	HP failure	Number of HP pressostat failures exceeded.
A-07	LP failure	Number of LP pressostat failures exceeded.
A-08	Control sig. failure	Check 0-10V signal.
A-09	Expanding module failure	Expanding module does not respond.
A-10	EEV failure	Expansion valve failure.
A-11	Condenser failure	Check the condenser circuit breaker.

Integrated cooling – Controller for Compressor Output Control

Additional Display Views (P-79 parameter)

Code	Description
Outr	The sensor is out of the measuring range.
An06	Digital compressor discharge temperature.
An10	Evaporation temperature
An11	Condensation temperature
An12	Evaporation pressure
An13	Condensation pressure
An14	Inlet temperature 1
An15	Inlet temperature 2
AIL3	Input signal value (0 = 0V, 100 = 10V)
AIL4	LP sensor value (bar)
AIE4	HP sensor value (bar)
AOL3	Limiting value according to Te
AOE3	Limiting value according to Tc
AOE4	Condenser control analogue signal value
FrEE	Electronics Menu active, only for service purposes.

Technical Data

Packaging	Self-extinguishing ABS plastic
Box	Front panel, 32 × 74 mm, depth 80 mm
Panel degree of protection	IP65
Connection	Screw terminal box for wires up to 2.5 mm ² cross-section
Supply voltage	12, 24 V AC
Input power	Max. 6 VA
Display	Four-digit, red LEDs, digit height 14.2 mm
Inlets	Up to 5 sensors NTC (-40 to 110°C)
Additional inputs	6x digital tension-free contact
Relay outputs	4x switching relay, 2A, 250 V AC
Triac outputs	1x triac relay, 2A, 250 V AC
Analogue outputs	1× conf., 2× 0–10V
Data memory	EEPROM
Operating temperature range	-10°C to 55°C
Storing temperature range	-20°C to 85°C
Relative humidity	10 to 90 % (non-condensing)
Measuring and control range	Depending on the sensor used
Accuracy (at ambient temperature 25 °C)	± 0,7 °C ±1 digit

Integrated cooling – Controller for Compressor Output Control

Standard Setting Values

Code	Description	Range:	Def.
S-00	Set Te	-10.0...10.0°C	4.1
S-01	Set Tc	30.0...90.0°C	63.0
S-02	Set Cond	20.0...S-01°C	17.0
S-04	Full output	Yes...No	15.0
P-01	PID LP_Udz	---	0
P-02	PID LP_Ldz	---	0
P-03	PID LP_BP	---	40.0
P-04	PID LP_Ti	---	120.0
P-05	PID LP_Td	---	0
P-06	PID LP_Arw	---	1
P-07	PID LP_Speed	---	0
P-10	Hyst UP	5...20 %	10
P-16	Set Td	90.0...140.0°C	120.0
P-17	Coolant type	0 – 9	5
P-20	Min T on	5...120 sec	30
P-21	Min T off	30...300 sec	60
P-22	PWM period	10...20 sec	10
P-23	Pen HP	3...10	3
P-24	Pei HP	15...60 min	15
P-25	Pen LP	3...10	3
P-26	Pei LP	15...60 min	15
P-32	PID HP_Udz	---	0
P-33	PID HP_Ldz	---	0
P-34	PID HP_BP	---	20.0
P-35	PID HP_Ti	---	100.0
P-36	PID HP_Td	---	0
P-37	PID HP_Arw	---	1
P-38	PID HP_Speed	---	0
P-40	BLP Bypass	--- sec	30
P-41	BLP Filter	--- sec	4
P-42	BLPA Bypass	--- sec	60
P-43	BLPA Filter	--- sec	120
P-45	Curb En	---	Yes
P-47	Warning time	0...600 sec	60
P-48	Warning value	0...100 %	10
P-50	PID Cond BP	---	15.0

P-51	PID Cond Ti	---	100.0
P-52	PID Cond Td	---	0
P-53	PID Cond_Utz	---	0
P-54	PID Cond_Ldz	---	0
P-55	PID Cond Speed	---	0
P-56	PID Cond Arw	---	1
P-60	T inc	10...600 sec	60
P-61	T dec	0...120 sec	10
P-66	DP En	---	No
P-67	Swap time	--- sec	30
P-68	Def time	--- sec	30
P-69	Def interval	--- hod	6
P-70	Switch off	---	Yes
P-71	Switch Cap	0...100 %	30
P-74	Defrost LP	-10,0...2,5 °C	4,0
P-77	Maf	---	100
P-79	App	---	-1

Integrated cooling – Electronic Expansion Valve Overheating Controller



Safety Instructions

Read these Operating Instructions carefully. Incorrect use can result in serious damage to the device and personal injury. Installation can only be performed by a suitably qualified and experienced person.

Before starting the installation, all power supply sources must be disconnected.

Temperatures must be within the specified ranges.

All connections must comply with the applicable electrical regulations in force.

The device must not be connected to voltage until all electrical connections have been connected.

Warning: The EC3-X33 controller is equipped with a renewable backup source containing lead and acids. Therefore, it cannot be disposed along with normal waste – the battery is subject to waste recycling regulations. In any case, it must be recycled in accordance with the applicable regulations in force (98/101/EEC).

Technical Data

Power supply	24 VAC ±10%, 50/60 Hz Class II
Energy consumption	25 VA max. EC3-X32, incl. EX 4-8
Terminal box	Push-in type for 0.14 ... 1.5 mm ² conductors
Grounding	6.3 mm grounding connector
Degree of protection	IP20
Connection to ECD-002	ECC-N** or category 5 conductor with RJ45
Digital Input I	0 / 24V DC/AC for ON/OFF control
NTC input	ECN-N60, output temperatures from the evaporator
Inlet pressure input, 4-20mA	PT5/07M;PT5/18M;PT5/30M Alco Controls
Output 4-20mA	for other controller K 12/24V
Deviation from the input signal	Max. ± 8%
Failure relay H	SPDT 24 V DC/AC 2 A ind
	ON Failure-free operation
	OFF Failure or disconnected power supply

⚠ If the output relay is not used, the user must ensure proper safety regarding power supply breakdown-related failures.

Output for EX4 to 8 valves	at 24 V DC, max. 0.8 A
Teplota okolí	0...60 °C
	1...25 °C (the longest battery service life)
	> 35 °C (battery service life < 2 years)

⚠ To keep the system reliable, it is advisable to change the battery every year.

Location

The EC3-X33 controller can be installed on the DIN bar. The EC3-331 controller is designed to be installed on the DIN bar. Position: On a vertical plate with the output for the step motor situated only on the upper side.

Electrical Connection

Zapojení podle schématu

The device may only be connected to the power supply once all conductors have been connected in accordance with the wiring diagram.

The device cover is grounded to the 6.3 mm terminal.

Warning: To comply with the applicable regulations (especially CEI 107-70), it is necessary to ensure the following: Transformer 24 V AC must be double insulated in Class II. Power supply 24 V AC is not grounded. To eliminate mutual influence and grounding problems, it is recommended to use separate condensers for the EC3 and other devices. **If connected to the mains, the EC3 will be destroyed.**

Integrated cooling – Electronic Expansion Valve Overheating Controller


Digital input I operation according to commands for the compressor/thermostat		
It controls:	Operating conditions	digital input
Compressor	Compressor start	closed/24V (start)
	Compressor stop	opened/0V (stop)
Thermostat	Command (compressor is running)	closed/24V (start)
	No command	opened/0V (stop)

Conductor Marking and Purpose

- E EX valve connection using terminated cable (A white, B black, C brown, D blue)
- F EX8 (respectively EX7) valve connection – only terminal
- G Auxiliary control device
- H Failure relay – no voltage when the power supply is switched off or failure signal received
- I Digital input: 0V = open (stop); 24V = closed (start)
- J Class II transformer – power supply 24V AC/25 VA
- K External controller – usually not ALCO (output from EC3 can be used)

⚠ The basic purpose of this relay is to protect the system when the power supply fails, if the communication interface or ECD-002 is not used.

Wiring Diagram



Commissioning Preparations

Exhaust coolant from the corresponding part of the cooling circuit.


Warning:

The EX valve is delivered in the open position – it must be closed before it is filled with coolant. Connect the EC3 to 24V while the digital input I is open (0V) – the valve will be closed. Once the valve has been closed, the circuit can be filled with coolant.

Warning:

Settings of the EC3 must be performed before the valve is connected to voltage. Digital input I must not be connected to 24V before all the parameters are set. ECD-002 can be connected to EC3 in the G socket using an ECC-Nxx conductor or another common Class 5 cable equipped with RJ 45 connectors.

ECD-002 Display with Buttons (LED Indicators and Settings)



Settings of Main Parameters on ECD-002 (before start)

Make sure the digital input I is without voltage, then it is possible to connect the terminal to 24V.

Important: When the digital input is switched off (0V), the main parameters will be set as follows: Coolant Type (u0), Pressure Sensor Type (uP) and Valve Type (ut).

These parameters must be set at voltage of 0V to prevent damage to the valve or compressor due to the transfer of the setting changes to the controlled element.

To make it easy, the setting procedure is described at the end of this manual. Once these parameters have been set and saved, the other functions can be set during operation.

Start-up

Start the system and verify it for proper overheating settings. The EC3-X33/53 controller can work even without the connected ECD-002 display. The ECD is mainly used to set the desired actions.

Setting Procedure using ECD-002

The device settings are protected by a digital code. The default factory setting is "12". To enter the program, proceed as follows:

- Press and hold the PRG button for more than 5 seconds, 0 will start flashing.

- Using the \square or \square buttons, set 12 as the password and press the SEL button to confirm.

- Then the first parameter (/1) to be set is displayed. Change the settings using the procedure below:

- Using the \square or \square buttons, select the parameter code to be changed.

- Press the \square or \square button to increase or decrease the value.
- Press the SEL button to confirm the new value and continue to the next parameter.

The process still repeats: "press the \square or \square to set on the display..."

To exit the parameter change mode

Press the PRG button to confirm the new values and close the setting process of the newly changed parameters.

To exit without changing any parameter:

Do not touch any button for the next 60 seconds (time for setting will elapse).

Reset – Recovery of Default Factory Settings

- Make sure the digital input is without voltage (0V).
- Simultaneously press the \square and \square buttons for more than 5 seconds, "0" will display.

- Using the \square or \square button, set the password "12" and press the SEL button to confirm.


- If a different password is used, this new password is set and A0 will appear.

- Press the SEL button to reset the device – the default factory settings will be restored.

- Press the PRG button to exit and save the default factory settings

Valve Build-Up Time at Start (parameters uu and u9)

EX4/5/6	≤ 1,5 sec
EX7	≤ 3,2 sec
EX8	≤ 5,2 sec



Integrated cooling – Electronic Expansion Valve Overheating Controller

Main Parameters – change if other settings are desired

Code	Parameter description and options	Min.	Max.	Factory settings	Actual settings
H5	Password	1	199	12	
u0	Coolant:	0	7	1	
	0 = R22 1 = R134a 2 = R507 3 = R404A 4 = R407C 5 = R410A 6 = R124 7 = R744 (subcritical conditions)				
uP	The used sensor type:	0	1	0	
	0 = PT4-07M (for R22/R134a/R507/R404A/R407C/R124) 1 = PT4-18M (for R410A) 2 = PT4-30M (for R744, subcritical)				
ut	The used valve type:	1	5	5	
	1 = EX4 2 = EX5 3 = EX6 4 = EX7 5 = EX8				

Additional properties (set if necessary)

uu	Initial opening of the valve (%)	10	100	50	
u9	Valve opening time (seconds)	1	30	5	
uL	Low overheating reporting	0	2	1	
	0 = N/A (for flooded evaporator) 1 = Yes with auto-reset 2 = No with manual reset switches at 0.5K (if it lasts 1 min); switches immediately at 3K				
u5	Rated overheating (K) If uL used (auto run)	3	30	6	
	If uL not used	0.5	30	6	
u2	MOP function	0	1	1	
	0 = Yes 1 = No				
u3	MOP settings (°C), saturated temperature	*	*	X	
	Set by the manufacturer according to the used coolant. +13°C for R22 +15°C for R134a +7°C for R507 +7°C for R404A +15°C for R407C +15°C for R410A +50°C for R124				
┐5	Used units (only for u3, u5, ┐1)	0	1	0	
	0 = °C, K, bar 1 = °F, R, psig (Psig is divided by 10 - example: displayed 12.5 equals 125 psig)				
┐1	Displayed value	0	4	0	
	0 = measured overheating 1 = measured evaporating pressure, (bar); 2 = valve opening (%), 3 = measured water output temperature 4 = calculated evaporation temperature (°C) from measured pressure				
u4	Overheating control method	0	1	0	
0 = normal, 1 = slow					
b1	Action of the battery if it fails.	0			
	(only for EC3-X33), according to the table:				
	Number	Display	Failure relay	Valve	Reset option after replacement
	0	–	–	controls	–
	1	Ab	–	controls	–
	2	Ab	switches	fully closed	automatically
	3	Ab (flashes)	switches	fully closed	manually

⚠ If b1 is set to 0 or 1, the user must ensure suitable protection to protect the system against failures caused by power supply breakdowns.

*) Maximum and minimum values are dependent on the coolant type

Integrated cooling – Electronic Expansion Valve Overheating Controller


ECD-002 Display Installation

The ECD-002 display can be connected at any time during operation. The EC2-371 is integrated into a 71 x 29mm panel – see dimensional drawing.

Insert the device into the panel (1).

The swivel lugs must be inserted into the device edges. Use the provided Allen wrench and turn the openings in the front face to move the lugs along the guides until they contact the panel wall (2).

Using the wrench, tighten both lags to the back panel wall so that the device cannot move – see figure (3).



⚠ Attention! DO NOT tighten too much to prevent the lugs to be broken.

Troubleshooting

Code	Cause	Function	Relay H	Valve	Remedy	Reset
E0	Pressure sensor failure		closes	closes	Check PT4 sensor and its connection.	Auto
E1	Temperature sensor failure		closes	closes	Check NTC sensor and its connection.	Auto
A	EX valve not connected		closes		Check the valve wiring and power supply.	Auto
Ab	Defective battery	b1=1		working	Low capacity, charge or replace the battery. If the signal is weak once the battery has been charged, replace the battery. This can happen if the battery has not been used for a long time.	
Ab		b1=2	closes	closes		
Ab flashes		b1=3	closes	closes		Manual
Er	Display error				Data for the display are out of its range. Check the sensors.	Auto

Message "----" (no data displayed): Display shows only dashes "----" during start and if no data for display are available.

Note: If more failures occur at the same time, the most serious failure is valued and displayed first before the other less serious failures. Operating data will be displayed once all failures have been resolved.

Check of System Operating Conditions

Data to be permanently displayed on the display can be selected (parameter $\text{r}1$). Temporarily, other data can also be displayed. This function cannot be set during a failure. The display shows numerical values for 1 second (see parameter $\text{r}1$) and then the selected parameter. After 5 minutes, it returns to the selected parameter $\text{r}1$.

Failure	Possible reason	Remedy
Operational overheating differs from pre-set overheating	Defective sensors	- Check the connection. ECN-N60 temperature sensor must be used. - PT4 pressure sensor must be used according to the manual for the given coolant. - The sensor conductors must be routed apart from the power conductors.
Low overheating – wet operation	- Defective sensors - Incorrect el. connection of the EX valve	Check the sensors and connections of the valve - EC3, el. conductor.
The valve does not close	- The digital input I is energized. - Wrong parameters	The valve will close if the input is energized, I = 0V. Check the settings
Unstable overheating – cycling	Unsuitable evaporator	Select higher overheating – find stable settings
The valve performs contrary in relation to the EX3 command	Incorrect el. connection	Connect the conductor colours correctly according to the wiring diagram.
The valve will not open at high pressure difference	Incorrect settings of the "u" parameter	Check and adjust the settings
Overheating change after some time	The motor needs to be synchronized	The digital input must not be permanently energized with 24V, it is necessary to switch off the power 1x per week for 5 seconds if the compressor does not stop.

Integrated cooling – Electronic Expansion Valve Overheating Controller

Illustrative Procedure of EC3-X33 and ECD-002 Settings

0 EC3-X33
SUPPLY DIGITAL
24V AC INPUT
24V
0 V
24 V AC

1 5 sec.

1a 12x

1b HS

1c 12

1d 1-199
88

2

2a 0

2b 5
0 = R22
1 = R134a
2 = R507
3 = R404A
4 = R407C
5 = R410A
6 = R124
R 410A

4 ut

4a 5


4b 4
1 = EX4
2 = EX5
3 = EX6
4 = EX7
5 = EX8
EX7

4c ut


4d -18.8

4e EC3-X33
SUPPLY DIGITAL
24V AC INPUT
24V
24 V AC


Data display



Dimensions



Integrated cooling – KHD-S1_ _R Backup System Wiring Diagram



Note: The 4-way valve is displayed in the "cooling" position (SV without power); the E1 heat-exchanger is in evaporator mode.

Legend:

C1	Cooling compressor
SV1	Power valve
SV	4-way valve
SG	Sight glass
EX	Expansion valves
E1, 2	Evaporator/condenser
Td, Ts	Temperature sensors
Z1-4	Back valves
LP	Low-pressure pressostat
HP	High-pressure safety pressostat
RKJ	Unit power and control distribution board
TA	Room temperature

Function description

Unit start and operating mode (heating/cooling) can be selected by an external signal. The E2 heat exchanger is alternatively used for heating or cooling of fresh air supplied to the air-conditioned object. The heat potential of the outlet air is always used. In winter, the outlet air transfers the heat to the E1 heat exchanger. Thus, heat recovery is achieved. The unit works in heat pump mode. The valve is without power. Cold inlet air is heated in the E2 heat exchanger (condenser).

In summer, fresh air is cooled as needed in the E2 heat exchanger. The SV valve is energized and the 4-way valve is moved to the opposite position. The E2 heat exchanger now works as an evaporator. Relatively cold outlet air exhausted from the building effectively cools the E1 heat exchanger (condenser). Surplus heat is transferred out of the building.

Proper functionality of the system is ensured by the control switchboard (RKJ) with the integrated PLC control system. The application software optimises the unit's operation and protects it against overloading. The heat recovery level can be steplessly controlled (0...10V signal) depending on the inlet air temperature TA (behind the E2 heat exchanger). If the maximum permissible condensation temperature is reached, the output is automatically reduced. The system is also protected against freezing of the evaporator by an automatically limited lowest evaporation temperature.

Unit Activation

Unit Activation

Check the correct interconnection of the control unit and air-handling unit. Check the motors (frequency inverters) - power part, controls, dampers, filter pressure sensors, motors, sensors... - in accordance with the air-handling unit.

Check the locations of the sensors, check the mechanical parts (dampers, motors) for free rotation and sticking.

Fan pressure and differential pressure sensing hoses must be situated so that they will sense static pressure (the end of the hose must not be oriented against the air flow. It must be oriented perpendicularly or in the direction of the air flow). Depending on the operating mode, a large quantity of condensate can be created inside the unit. Before starting the unit, it is advisable to check the condensate drainage circuit, especially the correct height of the siphons (according to the fan pressure), correct interconnection of the siphons – individual siphons must not be hermetically connected, filling of siphons with water and free passage through the piping.

Differential Pressure Sensor Setting Inspection

On the filters: Set the value of the final pressure loss in accordance with the rating plate data.

On the heat exchanger: The values are also indicated on the rating plate. They are derived from the operating pressure loss of the heat exchanger.

If the results of the inspection are OK, connect the distribution board to the power supply but still maintain the STOP mode. Enter the "Inputs" item in the service menu of the controller and check the state and functionality of the digital inputs (by short circuiting the cable ends or disconnecting the cable).

Stay in the "Inputs" item in the service menu of the controller and using the documentation check that the displayed values for the sensors correspond to reality (compare with a calibrated thermometer). If in doubt about the correct sensor, disconnect the sensor and check the displayed value.

Check the position of the dampers (inlet and outlet dampers closed, short-circuit damper open), failure-free operating state. If the system indicates a failure, trace the failure, check the component indicating the failure and remove the failure.

If no failures are indicated, test/simulate possible failures. Attention! Some failures can only be recalled when the device is running, e.g. air flow failure. Reset the failures.

Go to the service menu of the controller and test in sequence individual elements of the unit (dampers, heat exchanger, heater, heat pump, circulation pumps and fans). Switch to manual mode and test functionality (positions of damper, opening of valves, direction of turning of fans). Once the testing is finished, return all items to the AUTO mode.

Note: This way of testing ensures switching off in case of a failure. When testing by direct switching of the outputs, no protection is functional.

Unicon Air Flow Sensor Settings

Sensor operation (Mode) – set to 5.00

Adjust measuring range in Pa (in accordance with max. pressure of the fan).

Set the k-factor in accordance with the fan impeller type, see Table.

Impeller	k-factor
RH 22 C	47
RH 25 C	60
RH 28 C	75
RH 31 C	95
RH 35 C	121
RH 40 C	154
RH 45 C	197
RH 50 C	262
RH 56 C	308
RH 63 C	381
RH 71 C	490
RH 80 C	620
RH 90 C	789
RH 10 C	999
RH 11 C	1233

Unit Activation

To ensure stepless air-flow control using the Unicon sensor and to prevent the fan output cycling, we recommend setting the frequency inverter start-up and run-down ramps to 180 s (Danfoss frequency inverter –parameters 3-41 and 3-42). If the system is equipped with a PLC controller for compressor output control, it is necessary to follow the provided Operating Instructions, especially to check and remove possible failure messages. The controller has already been set and the parameters need not be adjusted, with only some exceptions. Now it is possible to switch the unit to RUN mode (see chapter 4.1 Main Switch).

Check the fan current consumption in each operating mode. If higher than I_{max} (see motor rating plate), it must be decreased (e.g. by decreasing the max. frequency of the frequency inverter).

Current Date and Time Settings

According to the customer's requirements, set the desired temperature and humidity at full operating mode (e.g. 31°C, 50%) and at reduced operating mode (e.g. 28°C, 70%). It is also necessary to set the time schedule for full operating mode (time of swimming pool use, e.g. 9.00-20.00 h).

Outside this time, the unit is operated in reduced operating mode.

If the air-handling unit is equipped with the Unicon constant air flow sensor, set this required air flow in the Carel controller menu.

The swimming-pool unit should be constantly in operation, except for service and maintenance periods.

The system is filled with a calculated quantity of coolant in the factory.

Coolant Handling

The used HFC type coolants (e.g. R404A, R407C, R410A,...) fall into the category of monitored greenhouse substances in accordance with European Parliament and Council Directive EC 842/2006 on F-gases (Art. 3, par. 6) and CZ Act no. 483/2008 Sb on air conservation. The user of a cooling device containing $\geq 3\text{kg}$ of coolant is obliged to keep records on results of periodic leak tests, the so-called Cooling Device Service Book, which must include the following data:

- Volume and type of coolant used during unit installation
- Results of performed preventive checks, especially the results of leakage tests
- Volume of added or drained coolant when performing maintenance or during unit operation or liquidation.

The records must include identification of the personnel or company who performed the maintenance or servicing. Any checks or intervention into the cooling circuit may only be performed by personnel certified by the Ministry of Health of the Czech Republic. On request, the user must submit the logs to the appropriate control authority.

The frequency of checks is determined by the volume of coolant:

- up to 30 kg once a year
- up to 300 kg ... twice a year

If a leak is found, it must be removed immediately. Repeat leakage tests of the circuit must be performed one month after the repair to verify the repair's efficiency.

Other Ways of Control, Checks, Failures

Checks

Temperature Difference Monitoring

This enables the difference between the required and actual supply air or room temperature to be monitored. The monitored temperature is compared with the pre-set tolerance $\pm 0.5^\circ\text{C}$ while simultaneously monitoring the temperature drop below the minimum limit. If the monitored temperature is below the minimum limit or outside the permissible tolerance for more than 1 hour, an informative error will be activated. The optional temperature difference monitoring can be enabled using the HMI controller, refer to the chapter Additional Operating Modes and Function Setting Options. Temperature minimum limit or tolerance can be set using the HMI controller in the List of Data Points in the section Monitored temperature Check Settings, System and Network Setting – Difference Monitoring.

Failures

The VCS unit monitors, evaluates and informs about various types of system failures. Possible failures are indicated, see the chapter of appropriate HMI controller (SG, TM, DM or Web) or Remote Indication. Failure messages identify failed objects/components which need to be inspected, respectively to find and remove the cause of the failure (or confirm absence of any problem) before acknowledging the failure. For failure reset, refer to the chapters of HMI controllers.

Failure Inputs (digital)

All important air-handling unit components (fan motors, electric heaters, etc.) are equipped with failure inputs (contacts) which after being connected to the devoted inputs (terminals) are evaluated by the VCS unit, respectively by the controller. If a failure (incorrect state of the contact) occurs, the VCS control unit will automatically put out an alarm in accordance with an internal algorithm – indicating the faulty object and in case of severe failures stopping the air-handling unit.

Note: In the Stop mode (at the beginning of start-up) the state of the air-flow sensors is indicated as correct. However, it is actually a failure state (contacts open) which, in these situations, is not evaluated by the system as a failure (this evaluation is performed once a pre-set time has elapsed). Similarly, the filter fouling sensor in the Stop mode – without air flow rate – is put into standby mode (contacts closed) which does not correspond with a failure state even though a failure occurred and was indicated during the previous operation (this state will change once the device has been started up – if the filter has not been changed).

Temperature Sensor Failures

Information about temperature sensors are specific failure messages evaluating their state outside the standard working range of measured temperatures. The controller will automatically report a disconnected, open or short-circuited temperature sensor, respectively abnormal value. If the main control sensors (e.g. supply air temperature sensor) or protection sensors (antifreeze protection) fail, the controller will shut down the system.

Outdoor and indoor temperature sensor failures will not shut down the entire system, only the functions related to the required input variable from the sensor. To operate properly, the VCS system requires all sensors according the specification to be operative.

Water Heater Antifreeze Protection Failures

The water heater protection system to prevent a breakdown caused by water freezing during a heating water delivery failure will report a failure if the heating water or air temperatures drop below the pre-set limits. For details about water heater antifreeze protection, refer to the chapter Description of Control and Protection Features.

Possible Causes of Indicated Failures

Antifreeze Protection Alarm

- Low water temperature in the water heat exchanger
- Check water temperature in the water heat exchanger
- Check the heating water source.
- Inspect or clean the SUMX mixing set filter.
- Inspect the heat exchanger's fins for fouling.
- Verify the circulation pump activation and operation.
- Verify functionality of the three-way valve
- Check the NS 130 temperature sensor in the duct.

Electric Heater Failure

- Inspect the electric heater thermo-contacts.
- Check the electric heater switching.
- Check the circuit breaker and EOS(X) electric heater condition.
- Inspect or clean the filter insert.
- Inspect the dampers for opening.
- Verify smooth air flow

Electric Heater Specialities

The EOS series electric heater design provides safe, reliable and long service life. As semiconductor relays (SSR) are used to switch the electric heaters, it is necessary to pay close attention to operating conditions, especially to over-voltage in the wiring and permissible increases in the temperature of the SSR relays.

SSR relays are advanced semiconductor components ensuring electric heater output switching with minimum noise. Due to the SSR relay design technology, the voltage at its poles must not exceed 1200V. As standard, SSR relays are equipped with over-voltage protection. If over-voltage exceeds the values specified by ČSN 330420 for wiring category III, there is a risk of service life shortening or even SSR relay destruction. In these cases, it is necessary to provide the control unit supply line with multistage over-voltage protection. An increased risk of over-voltage exists in the vicinity of 22kV/400V distribution transformers, highly loaded power lines routed in parallel, frequency inverters, etc.

Another danger comes from unacceptable overheating of the SSR relay internal structure above the permissible limit, leading to its destruction. Sufficient cooling of the SSR relay is ensured by placing the SSR cooler in the air duct, where it is cooled by the air flow.

Troubleshooting

Overheating of the SSR relay internal structure can also be caused by increased transition resistance at the poles (terminals), i.e. between the feed conductor and terminal. Therefore, it is necessary to ensure proper tightening of the SSR terminal bolts.

Fan Failures

- Check connections of the thermo-contacts.
- Check the condition of the motor circuit breaker .
- Inspect the V-belt.
- Check the fan for free rotation.
- Check connections of the P33N differential pressure sensor.
- Check the motor current.
- Inspect the frequency inverter

Air-Flow Failure

- Check the condition of the V-belt .
- Check the fan for free rotation.
- Check performance of the differential pressure sensor.
- Check the fan for proper operation and correct direction of rotation.
- Inspect the frequency inverter.

Failure Signalling – Fire, Smoke

- Check the condition of the fire dampers.
- Check the condition of the connected external device.

Fouled Filters

- Check the filter for fouling. Replace if necessary.
- Check the P33N pressure sensor settings.

Cooling Failure

- Check the condition of the connected cooling unit.
- Inoperative cooling – without failure indication
- Verify the water cooler circulation pump activation and operation (at active cooling signal above 20% = 2V)

Antifreeze Protection Sensor Failure

- Check the heating water temperature.
- Check the connections of the NS 130R sensor.
- Replace the sensor

Power indicator does not illuminate

- Inspect the supply voltage.
- Inspect the auxiliary circuit breaker.
- Inspect the power supply source fuses

Troubleshooting

When performing any handling or troubleshooting of the air-handling device, the power supply of the entire distribution board must be disconnected using the main switch. When performing inspections, pay increased attention to the correct functioning of the protection devices (SUMX mixing set, motor thermo-contacts and electric heater thermo-contacts). Verify

the correct functioning of evaluating, protection and switching devices. Check the control signal. Check the terminals for proper tightening, both on the peripheral device side and control unit side.

Regular Inspections

Service inspections of the entire air-handling system must be performed at least twice a year (unit transition from winter to summer operating mode).

In addition to these, extra inspections must also be performed after a unit failure, natural disaster or emergencies.

Maintenance of the control unit includes just regular cleaning and inspection of the screw connections – wires, grounding, component fixing, etc. Internal parts of the unit must be cleaned of dust and any other dirt at the specified maintenance intervals.

If the control unit is equipped with a fan fitted with a filter (outdoor version), change the filter once a year.

If necessary, clean the face panel of the unit's box using a wet cloth. Use common cleaners.

If the control unit is equipped with a filter fan (external version), replace the filter once a year.

When changing over to the summer operating mode, drain the heating water circuit; the mixing set pump must be disconnected. To do so, turn the disconnecter to the "Off" position. (Otherwise, ensure regular turning of the pump to prevent the pump seizing; operating the pump without water can damage it). In the winter operating mode, the pump must be activated using the reverse order of steps, i.e. turned "On" and checked for proper operation.

The same procedure must be performed when the water cooler is being shut down for a season or reactivated. (Note that the water cooler pump does not turn the system).

Spare Parts and Service

Spare parts are not included in the VCS unit delivery.

If any spare parts are needed, they can be ordered from the manufacturer or regional distributor.

Warranty and regular servicing can be ordered from the manufacturer or the authorized service provider (see the list on www.remak.eu).

Spare Parts and Service

Disposal and Recycling



Information for disposal in other countries outside EU

Observe the applicable local environmental protection and waste disposal regulations.

For users from EU countries

When disposing of components and materials, observe the 2012/19/EU Directive, applicable national and local environmental protection and waste disposal regulations.

disposal regulations.

For users from the Czech Republic

Observe the applicable local environmental protection and waste disposal regulations. Active carbon which contains toxic substances, radioactive impurities or PCB must be disposed of in accordance with applicable legal regulations. When disposing of the air-handling unit once its service life has expired, follow Waste Act No. 185/2001 Sb. as amended by Directive No. 352/2005 Sb. (electric waste).

Waste Classification

(in accordance with Directive No. 93/2016 Sb.)

Packaging used:

- 15 01 01 cardboard box
(paper and cardboard packaging)
- 15 01 02 polyester packaging pads
(plastic packaging)
- 15 01 03 pallet (wooden packaging)

Disabled device and its parts:

- 13 02 06 Waste engine, transmission and lubricating oils (synthetic engine, transmission and lubricating oils)
- 16 01 17 Iron metals
- 16 01 18 Non-iron metals
- 15 02 03 Filter material
- 16 02 14 Disposed parts not included under numbers 16 02 09 – 16 02 13
- 16 02 15 Electric parts
(dangerous compounds removed from disposed devices)

Abbreviations

BPDEV	Plate Heat Exchanger Bypass
TČ	Heat Pump
TK	Thermocontact
PMO	Antifreeze Protection
ROV	Rotary Heat Exchanger
VZT	Air-handling Device
ZZT	Heat Recovery
FTT-10A	Free Topology Transceiver for channel type TP/FT-10 (LON)
TP/FT-10	Physical channel to transmit data over Twisted Pair to Free Topology networks
SNVT	Standard Network Variable Type (LON)
LON	Local Operating Network
SCADA	Supervisory control and data acquisition
BMS	Building Management System
ModBus RTU	Communication protocol (Remote Terminal Unit)
Climatix	A series of controllers providing the same features
AHU	Air Handling Unit
SELV	Safety Extra-Low Voltage
HMI	Human Machine Interface – remote controller
BACnet	Building Automation and Control Network
TCP/IP	Transmission Control Protocol, např. Ethernet/Internet



It is always necessary observe local laws!

LonLink™, LON® / LonManager®, LonMark®, LonTalk®, LonWorks®, Neuron® are registered trade marks of Echelon Corporation. Modbus® is registered trade mark of The Modbus Organization. BACnet® is registered trade mark of American National Standard Corporation.

Warning

The manufacturer reserves the right to make changes and amend the documentation due to technical innovations and changes to legislation without prior notice.

Printing and language mistakes are reserved. These Installation and Operating Instructions (as a whole or a part) must not be printed or copied without prior written permission from REMAK a. s., Zuberská 2601, Rožnov pod Radhoštěm, Czech Republic. These Installation and Operating Instructions are the sole property of REMAK a. s. Changes reserved. Issued: 31. 10. 2019

REMAK

REMAK a.s.

Zuberská 2601, 756 61 Rožnov pod Radhoštěm,
tel.: +420 571 877 778, fax: +420 571 877 777,
email: remak@remak.eu, internet: www.remak.eu

